
NEW HOLLAND 555E 575E 655E 675E

(Replaces All Previous Issues)





TO THE OWNER:

The warranty coverage that is extended to your backhoe loader is explained in the Warranty and Limitation of Liability form. Your dealer will provide you with a copy of the warranty and retain a copy which you have signed. After you read the warranty, ask your dealer to explain any points that you may not understand.

This backhoe loader was designed to power and propel itself. It is intended to dig, load and move material in normal and customary applications.

Do not modify or alter or permit anyone else to modify or alter this backhoe loader or any of its components or any backhoe loader function without first consulting an authorized New Holland dealer. If you have any questions regarding backhoe loader modifications, contact New Holland North America, Inc., 500 Diller Ave., New Holland, PA 17557.

Your safety and the safety of those around you depends upon the care and good judgment you use while operating this equipment. Read the safety precautions carefully.

After you have operated the backhoe loader for 50 hours, take your backhoe loader and this manual to your selling dealer. He will perform the factory recommended 50-hour service. You will be responsible for the cost of lubricants, fluids, filters and other items replaced as part of normal maintenance. Prior to taking the backhoe loader to your selling dealer for service, it is recommended that you contact them to determine any other charges for which you may be responsible.

All data given in this book is subject to production variations. Dimensions and weights are approximate only and the illustrations do not necessarily show tractors in standard condition. For exact information about any particular backhoe loader please consult your New Holland dealer.



CAUTION: THIS SYMBOL IS USED THROUGHOUT THIS BOOK WHENEVER PERSONAL SAFETY IS INVOLVED. TAKE TIME TO READ AND FOLLOW THE INSTRUCTIONS. BE CAREFUL!.

CAUTION: PICTURES IN THIS MANUAL MAY SHOW PROTECTIVE SHIELDING OPEN OR REMOVED TO BETTER ILLUSTRATE A PARTICULAR FEATURE OR ADJUSTMENT.

BE CERTAIN, HOWEVER, TO CLOSE OR REPLACE ALL SHIELDING BEFORE OPERATING THE MACHINE.

IMPROVEMENTS

New Holland North America, Inc. is continually striving to improve its products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.



WARRANTY AND LIMITATION OF LIABILITY - INDUSTRIAL PRODUCTS

COVERAGE PROVIDED

New Holland North America, Inc. or New Holland Canada, Ltd., hereinafter called "Company" warrants to the retail purchaser of each new Product (as listed below) that the Selling Dealer will repair or replace any part thereof found to be defective in materials or workmanship within the following periods. This warranty is for the benefit of the original or subsequent purchaser when purchased from an authorized New Holland dealer.

BASIC WARRANTY

DAGIO WAIIIARTI	
Product	Warranty Period (whichever comes first)
Industrial Tractors Industrial Tractors with Loaders Industrial Tractors with Loaders/Backhoes Industrial Tractor Attachments Skid-Steer Loaders and Attachments *Commercial Mower and Attachments	
LIMITATIONS, INCLUDING DISCLAIMER OF IMPLIED WA	RRANTIES AND CONSEQUENTIAL DAMAGES
This warranty gives you specific legal rights and you may or provincial laws.	y also have other rights which vary, depending on state
New Holland North America, Inc. or New Holland Canada for it any other obligation or liability in connection with the IMPLIED WARRANTY OF MERCHANTABILITY OR FITN THE STATED DURATION OF THIS WRITTEN WARRANTY. BE LIABLE FOR LOSS OF THE USE OF THE PRODUCT, OR CONSEQUENTIAL DAMAGES.	ese products. TO THE EXTENT ALLOWED BY LAW, ANY ESS APPLICABLE TO THIS PRODUCT IS LIMITED TO NEITHER COMPANY NOR THE SELLING DEALER SHALL
Some states and provinces do not allow limitations on ho limitation of incidental or consequential damages, so the ab	ow long an implied warranty will last or the exclusion or love limitations or exclusions may not apply to you.
The remedy of repair or replacement of a defective part purchaser's exclusive remedy.	during the warranty period herein specified shall be the
EXTENDED SERVICE PLAN (ESP)	
When offered by the Company, the option to purchase an E	xtended Service Plan has been explained and:
\square I accept and have signed the completed registration for	orm
☐ I decline the Extended Service Plan	
☐ I will consider later (within 180 days)	
PROTECTIVE EQUIPMENT	
Rollover protective structure (ROPS) and seat belts are pro tractors, skid-steer loaders and commercial mowers and to remove or not use this protection do so at their own risk.	
I acknowledge the existence of OSHA regulations pertain	ning to ROPS
A PTO master shield, if applicable, has been installed on	the machine
The correct Operator's Manual has been furnished	
Safety precautions were explained to me by the Selling D	Dealer
ACKNOWLEDGEMENT/WARRANTY TRANSFER	
The blank spaces under "Protective Equipment" have been read and I accept this Warranty and Limitation of Liability.	n filled in and are correct, and I acknowledge that I have
Purchaser	Dealer Code
Address	Address
City State Zip	City State Zip
Model Serial No	Retail Date //
Attachment Model SN	Extended Service Plan Expires on / / / / (Subject to confirmation by NH)
Attachment Model SN	
Purchaser Date	Dealer Date
20528 REV. 5/95 Additional de	•

White—NEW HOLLAND NORTH AMERICA, INC., 1441 DIVISION HWY., NEW HOLLAND PA 17557-9635 Canary—PURCHASER PINK—DEALER

New Holland Warranty Detail

The warranty period will begin on date of original retail sale or date of original use, whichever is earlier.

- The obligation of Company to the purchaser under this warranty is limited to the repair or replacement of defective
 parts by an authorized New Holland dealer and will be done free of charge for both parts and labor using genuine
 New Holland replacement parts. Repair or replacement in accordance with this warranty shall constitute fulfillment
 of all liabilities of Company and the Selling Dealer in respect to such Products.
- Repairs or replacements will be performed by the Selling Dealer, following delivery of the Product by the purchaser
 to the Dealer's place of business. When the purchaser has moved a long distance from the Selling Dealer, or
 the Selling Dealer is no longer in business, any New Holland dealer authorized to sell and service the described
 Products may perform the repair at its dealership.
- The Selling Dealer shall review these warranty provisions with the purchaser prior to retail sale, secure his acknowledgement of delivery of this warranty and record the date of original retail sale or date of original use.
- To obtain warranty service, the purchaser must (1) report the product defect to an authorized New Holland dealer and request repair within the applicable warranty term and (2) present evidence of the warranty start date.

WHAT IS NOT COVERED BY THE WARRANTY?

This warranty shall NOT apply under the following conditions:

- (i) With respect to vendor warranty items such as Deutz engines, tires, tubes, and attachments which shall be warranted by their manufacturer, or local representative thereof.
- (ii) If the unit has been subject to misapplication, abuse, misuse, negligence of proper maintenance or other negligence, fire or other accident.
- (iii) If parts or attachments other than those made or marketed by New Holland North America, Inc. or New Holland Canada, Ltd., have been used in connection with the unit, and in the sole judgment of Company such use affects its performance, stability or reliability.
- (iv) If the unit has been altered or repaired outside of a New Holland dealership in a manner which, in the sole judgment of Company, affects its performance, stability or reliability.
- (v) Batteries are covered by a separate pro rata adjustment warranty. The pro-rata plan covers the battery fully for the basic product warranty period as indicated, with any remaining warranty pro-rated according to the months of service.
- (vi) The purchaser shall be responsible for payment of dealer travel time to the machine or to deliver the machine to the dealer's service shop for repair. New Holland warranty does not cover delivery charges or travel time.
- (vii) The Company shall have no liability for used equipment sold beyond the specified coverage period.
- (viii) No warranty shall apply to damage resulting from accident or damage caused by environment (such as exposure to corrosive material). The Company shall not be responsible for rental equipment used to replace the equipment being repaired.
- (ix) This warranty shall NOT apply to normal maintenance services (such as tune-ups, fuel injection system cleaning or wheel, brake and clutch adjustments), to normal replacement of service items (such as filters and brake or clutch linings), or to normal deterioration due to use or exposure (such as belts and exterior finish). New Holland shall not be responsible for normal replacement parts such as cutting knives, chains, belts, clutches, filters, oil, or other parts which are worn out, unless they are determined to be defective in material or workmanship.
- (x) This warranty shall NOT apply to any New Holland Product which is retailed or distributed by anyone other than New Holland North America, Inc. or New Holland Canada, Ltd., through its authorized dealers. This warranty shall NOT apply to any Product which is normally operated outside of the United States, and/ or Canada.
- (xi) This warranty shall NOT apply if the purchaser, insurance company, or any other entity or individual acting on behalf of the purchaser seeks reimbursement for the dollar value of the repair(s) or replacement(s) covered under this warranty.

RIGHT TO MAKE DESIGN CHANGES

Company reserves the right to make changes in the design and other changes in its products at any time and from time to time without notice and without incurring any obligation with respect to any product previously ordered from it, sold or shipped by it.

TABLE OF CONTENTS

Section 1 – Introduction	
Quick Reference Guide	1-1
Product Identification	1-2
Important Ecological Considerations	1-5
Safety Precautions	1-6
Safety Decals	
Safety Features and Machine Security	1-17
Universal Symbols	
Section 2 – General Information	
Quick Reference Guide	2-1
Machine	
Cab	
Controls and Instruments – Overview and Function	
Transmission	
Loader	
Backhoe	
Towing	
Section 3 –Controls and Operation	
Quick Reference Guide	3_1
Cab Doors and Windows	
Seat Adjustment	
Climate Controls	
Hand and Foot Controls - Pedals and Levers (Power Shuttle)	
Brakes (Power Shuttle)	
Hand and Foot Controls – Pedals and Levers (Power Shift)	
Brakes (Power Shift)	
Front Instrument Panel	
Side Mounted Instrument Panel	
Transmission Controls (4x4 Power Shuttle)	
Transmission Controls (4x2 Power Shift)	
Operating the Engine	
Loader Controls	
Backhoe Controls	
Ballasting and Tires	
Section 4 – Lubrication and Maintenance	
Filling and Service Points	4-1
Warning Lights	
Lubrication and Maintenance Table	
Fuels	
Loader Support	
Daily Service or as required	
Air Cleaner Servicing	
50-hour Service	
300-hour Service	4-19
600-hour Service	4-24
1200-hour/12 Month Service	4-30
1200-hour/24 Month Service	4-34
General Maintenance – As Required	4-35
Bulb Replacement	4-39
Fuses	4-41
Section 5 – Trouble–shooting	5-1
Section 6 – Specifications	
Index	
Predelivery Service	
Delivery Report	
First 50-hour Service	
FILE LOVE HOUR SELVICE	0-29

OWNER ASSISTANCE

We at New Holland and your New Holland dealer want you to be completely satisfied with your investment. Normally any problems with your equipment will be handled by your dealer's Service Department. Sometimes, however, misunderstanding can occur. If your problem has not been handled to your satisfaction, we suggest the following.

- 1. Contact the owner or General Manager of the dealership, explain the problem, and request assistance. When additional assistance is needed, your dealer has direct access to our branch office.
- 2. If you cannot obtain satisfaction by doing this, contact the branch office in your area and provide them with:
 - Your name, address, and telephone number
 - Machine model and serial number
 - Dealership name and address
 - Machine purchase date and amount of use
 - Nature of problem

Atlanta

4727 N Royal Atlanta Dr Suite P Caller Service 105018 Tucker, GA 30085-5018 Telephone: (770) 723-3605 States: AL, FL, GA, KY, MS, NC, SC, TN, VA

Dallas

1340 Walnut Hill Lane Bldg 2 P.O. Box 167528 Irving, TX 75016-7528 Telephone: (972) 756-4919 States: AR, AZ, CA, CO, HI, KS, LA, MO, NM, NV, OK, TX, UT

Minneapolis

6301 W Old Shakopee Rd P.O. Box 1342 Minneapolis, MN 55440-1342 Telephone: (612) 887-4231 States: AK, IA, ID, IL, MN, MT, ND, NE, OR, SD, WA, WI, WY

3. If you need further assistance contact:

Service Department Mail Station 500 New Holland North America, Inc. New Holland, PA 17557

New Holland

200 Commerce St. P.O. Box 527 Mountville, PA 17554-0527 Telephone: (717) 285-8302 States: CT, DE, IN, MA, MD, ME, MI, NH, NJ, NY, OH, PA, RI, VT, WV

Calgary

Suite 220 3030 Third Ave. NE Box 1616, Stn M Calgary, AB CANADA T2P 2M7 Telephone: (403) 569-3208

When contacting your branch office or Service Department, be aware that your problem will likely be resolved in the dealership using the dealer's facilities, equipment, and personnel. So it is important that your initial contact be with the dealer.

A Service Publications Catalog & Order Form is available which lists the operator's and service manuals for many prior model and most current model Ford - New Holland - Versatile tractors, equipment, and consumer products. To obtain a copy of this catalog, please call 1-800-635-4913.

PRECAUTIONARY STATEMENTS

PERSONAL SAFETY

Throughout this manual and on machine decals, you will find precautionary statements ("CAUTION", "WARNING", and "DANGER") followed by specific instructions. These precautions are intended for the personal safety of you and those working with you. Please take the time to read them.



CAUTION: THE WORD "CAUTION" IS USED WHERE A SAFE BEHAVIORAL PRACTICE ACCORDING TO OPERATING AND MAINTENANCE INSTRUCTIONS AND COMMON SAFETY PRACTICES WILL PROTECT THE OPERATOR AND OTHERS FROM ACCIDENT INVOLVEMENT.



WARNING: THE WORD "WARNING" DENOTES A POTENTIAL OR HIDDEN HAZARD WHICH HAS A POTENTIAL FOR SERIOUS INJURY. IT IS USED TO WARN OPERATORS AND OTHERS TO EXERCISE EVERY APPROPRIATE MEANS TO AVOID A SURPRISE INVOLVEMENT WITH MACHINERY.



DANGER: THE WORD "DANGER" DENOTES A FORBIDDEN PRACTICE IN CONNECTION WITH A SERIOUS HAZARD.

FAILURE TO FOLLOW THE "CAUTION", "WARNING", AND "DANGER" INSTRUCTIONS MAY RESULT IN SERIOUS BODILY INJURY OR DEATH.

MACHINE SAFETY

Additional precautionary statements ("ATTENTION" and "IMPORTANT") are followed by specific instructions. These statements are intended for machine safety.

ATTENTION: The word "ATTENTION" is used to warn the operator of potential machine damage if a certain procedure is not followed.

IMPORTANT: The word "IMPORTANT" is used to inform the reader of something he needs to know to prevent minor machine damage if a certain procedure is not followed.

SECTION 1

INTRODUCTION TO THE OWNER

SAFETY

Pages 1-5 through to 1-15 list the precautions to be observed, to ensure your safety and the safety of others. Read the precautions and follow the advice offered BEFORE operating the machine.


SERVICE PARTS

The company would like to point out that 'non-genuine' parts have not been examined and approved by the Company. The installation and/or use of such products could have negative effects upon the design characteristics of your machine and thereby affect it's safety. The Company is not liable for any damage caused by the use of 'non-genuine' parts and accessories.


It is prohibited to carry out any modifications to the machine unless specifically authorized, in writing, by the After Sales Service department of the Company.

QUICK REFERENCE GUIDE

Page	Contents
1-2	. Product Identification
1-5	. Ecological Considerations
1-6	. Safety Precautions
1-14	. Safety Decals
1-17	. Machine Safety and Security
1-18	. On Road Travel Requirements
1-19	. Universal Symbols



1-1



PRODUCT IDENTIFICATION

Your Backhoe Loader and its major components are identified by serial numbers and letters for recognitior in After Sales Service. The following information provides the locations of these identification plates, stamped numbers and examples of what can be found on your machine.

VEHICLE SERIAL NUMBER (1), Figure 1-1.

NOTE: The Serial Number and identification numbers of components may be required by your dealer when requesting parts or service. These numbers will also be required as an aid to identifying the machine if it is ever stolen. Keep them safe.

VEHICLE IDENTIFICATION PLATES (2), Figure 1-1.

The machine identification plates are located on the right-hand loader post, as shown at position (2). Record the data of your machine below.

MODEL/TECHNICAL TYPE	
Example: *655E.699.510.700*	
UNIT SERIAL NO.	
Example: *031005017*	
YEAR	
Evample: *1005*	

ENGINE IDENTIFICATION, Figure 1-2.

The engine identification information is located on the right hand engine sump rail. Record the information below for quick reference.

MODEL NO
Example: *EA5*
SERIAL NO.
Example: *57018*
DATE CODE.
Example:*5J25*=5(1995),J(SEPTEMBER),25(DAY)


1-2

FOUR WHEEL DRIVE IDENTIFICATION,

Figure 1-3

The serial number and axle type is printed on the plate (1), located on the front of the axle housing. Record the information below for quick reference.

AXLE TYPE	
Example: *26-18*	
SERIAL NO.	
Example: *000102*	
ROTATION	
Example: LH = Left Hand RH = Right Hand	
DATIO	
RATIO	




TRANSMISSION IDENTIFICATION, 4x4 POWER SHUTTLE, Figure 1-4

Example: 12.33 to 1 - 12.8 to 1

The serial number and type are printed on the plate (1), on the lower right side of the transmission. Record the information below for quick reference.

MODEL NO.	
Example: *COM-T4-2025*	
SERIAL NO.	
Example: *15647 E95 01*	




1-4

TRANSMISSION IDENTIFICATION 4x2 POWER SHIFT, Figure 1-5


The serial number and type is printed on the plate (1), on the lower part of the rear of the transmission. Record the information below for quick reference.

MODEL NO.	
Example: *11.11 - FT16000-1*	
SEDIAL NO	
SERIAL NO.	



1-5

Example: *PBEA 000201* P=96, BE= Belgium




REAR AXLE IDENTIFICATION, Figure 1-6

The serial number and date codes (1) are stamped on the left side of the rear axle housing. Record the serial number below for quick reference.

MODEL NO.
Example: *85801201*
DATE CODE
Example: 5D05=5(1995), D(APRIL), 05(DAY)

1-6



CAB/ROPS IDENTIFICATION PLATES,

Figure 1-7

The cab or ROPS serial number and details are printed on the certification plate's (1) on the rear left hand window rail on cab units and on the upper left hand roof rail on ROPS units. Record the serial number below for quick reference.

Serial No.	
Date Code	

1-7

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com