


Series 2000 Industrial Tractor



Series 2000 L.C.G. Tractor Dual Rear Wheels and Cushion Seat Optional Equipment

FORD **SERIES 2000 AND 4000 INDUSTRIAL AND L.C.G.** TRACTOR **OWNER'S MANUAL**

Prepared by

TRACTOR AND IMPLEMENT OPERATIONS (U.S.) FORD TRACTOR DIVISION


FORD MOTOR COMPANY

BIRMINGHAM, MICHIGAN

Litho in U.S.A.

SE 8741 A

Tractor Service Policy



At the time of delivery of your new tractor, the Ford Tractor and Implement Dealer presented to you a copy of the Service Policy shown above. This policy certifies that your new Ford Tractor has been properly inspected and prepared for delivery by the dealer.

The policy should be presented to the dealer whenever you request any service which is authorized on it. We recommend, therefore, that you keep the policy in a safe place for ready reference at all times.

FOREWORD

We wish to congratulate you on your choice of the new Ford Tractor. We are happy to have you as a customer and are confident that you will receive unequaled performance from your Ford Tractor.

This manual has been prepared to acquaint you with the many features of your new Ford Tractor. Most of the information presented here is general and applies to both 2000 and 4000 Series industrial and low center of gravity tractors.

Many of the features covered in this manual are optional equipment on some models and standard on others. For further information on optional equipment and accessories, see your Ford Tractor and Implement Dealer.

Read this manual carefully at your first opportunity and keep it in a convenient location for later reference. You will be particularly interested in the "break-in" instructions starting on Page 18, and the maintenance instructions starting on Page 39.

If, at any time, you have a question or problem concerning your new tractor, remember that your Ford Tractor and Implement Dealer is best qualified and equipped to serve your needs. With the proper treatment and service, your Ford Tractor should provide you with a long life of profitable and dependable service.

SAFETY PRECAUTIONS

Your Ford Tractor embodies all the safety features consistent with good performance. Safety features alone, however, will not prevent accidents caused by carelessness. The following safety precautions are suggested to help prevent such accidents.



- 1. Do not permit anyone to ride on the tractor with the operator.
- 2. The operator should never leave the tractor seat when the tractor is in motion.
- 3. Use care when operating on steep grades to maintain proper stability.
- 4. Always drive tractor at speeds slow enough to insure safety, especially when operating over rough ground, near ditches, or turning.
- 5. Keep the tractor in gear when going downhill.
- 6. Always shut off the engine when leaving the tractor.
- Make sure the brake pawls are set when parking the tractor. Select park (P) on Select-O-Speed Tractors.



- 8. Always keep the tractor brakes in proper operating condition.
- 9. Do not refuel the tractor when the engine is overheated or running.



SAFETY PRECAUTIONS

- 10. Never run the tractor engine in a closed garage. Carbon monoxide fumes, expelled from the exhaust system, are very dangerous and cannot be detected because they are odorless.
- 11. Never install or remove the belt while the belt pulley is in motion.
- 12. Never wear loose clothing when operating the belt pulley or power-take-off.
- 13. Always pull from the drawbar. Pulling from the top link or rear axle is dangerous.
- 14. If the front end tends to raise, check for proper weight distribution.
- 15. Safety light equipment should be installed on implements being transported on the highway after dark. See your Ford Tractor and Implement Dealer for safety light equipment that conforms to your State and local regulations.



The Tractor and Implement Division of the Ford Motor Co. being a member of the National Safety Council is privileged to use the Green Cross to denote safety instructions in operator's manuals.

TRACTOR MODEL AND SERIAL NUMBER

When ordering parts or requesting information from your Ford Tractor and Implement Dealer, always specify the Model and Serial Number of your Ford Tractor.

The Model and Serial Number is located on the left front side of the transmission housing and should be recorded immediately in the space provided below.

MODEL	
<u></u>	

SERIAL NO.

6

CONTROLS AND INSTRUMENTS

The controls on your new Ford Tractor are designed to help you do more work with the greatest possible convenience and comfort. All are within easy reach and are simple to operate.

The well-grouped instruments tell you, at a glance, whether the engine is operating efficiently and warn you of the possibility of trouble before it becomes serious.

Before attempting to start or operate your new tractor, familiarize yourself with the location and function of all controls and instruments.



Know your controls and instruments to assure Safe Operation.

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com