Tractors less cab 3230, 3430, 3930, 4630, 5030

For tractors built after June 1, 1994





Reprinted

CONTENTS

	Tractor identification plates	inside front cover
	About this Manual	ii
	Introduction	iii
	Owner assistance	iv
	Warranty forms	v and vii
	ROPS	ix
	Safety decals	x - xi
	Safety precautions	xii – xiv
	Pre-delivery inspection	
	and 50 hour service	xv and xvii
	Universal symbols	xviii
SECTION A	CONTROLS, INSTRUMENTS AND	OPERATION
1 1	Operator's seat	2
	Roll Over Protective Structures (ROP	S) 3
	Instruments and controls	5
	Engine starting/stopping procedure	7
	Parking brake and foot controls	9
	Transmission	10
	Four wheel drive	13
	Power take-off	15
	Three-point linkage	18
	Hydraulic system	22
	Remote control valves	26
	Attaching/detaching equipment	32
	Track adjustment	34
	Tractor weighting	44
	Tire inflation	48
SECTION R	LUBRICATION AND MAINTENANC	CE
	Lubrication and maintenance chart	2
	Routine servicing	2 5
	General maintenance	30
	General maintenance	30
SECTION	SPECIFICATIONS	
	INDEX	

Page

ABOUT THIS MANUAL

This Manual has been prepared to assist you in the correct procedure for break-in, operation and maintenance of your new Ford tractor.

Your tractor has been designed and built to give maximum performance, economy and ease of operation under a wide variety of operating conditions. Prior to delivery, the tractor was carefully inspected, both at the factory and by your Ford New Holland dealer to ensure that it reaches you in optimum condition. To maintain this condition and ensure trouble—free operation, it is important that the routine services, as specified in this Manual, are carried out at the recommended intervals.

The upper portion of pages xv and xvii are pre—delivery inspection sheets. The first sheet (page xv) is the dealers' copy and should be removed by the dealer after the inspection has been carried out. The second sheet (page xvii) is your copy of the service performed. Ensure that you and the dealer sign both copies. After you have operated the tractor for 50 hours, take your tractor, together with this Manual, to your dealer. He will then perform the factory recommended 50 hour service as listed on the lower portion of pages xv and xvii. Ensure that you and the dealer sign both copies.

Read this Manual carefully and keep it in a convenient place for future reference. If at any time you require advice concerning your tractor, do not hesitate to contact your authorized Ford New Holland dealer. He has factory trained personnel, genuine Ford parts and the necessary equipment to carry out all your service requirements.

Ford New Holland policy is one of continuous improvement, and the right to change prices, specification or equipment at any time without notice is reserved.

All data given in this book is subject to production variations. Dimensions and weights are approximate only and the illustrations do not necessarily show tractors in standard condition. For exact information about any particular tractor, please consult your Ford New Holland dealer.

INTRODUCTION

DEAR CUSTOMER - PLEASE READ CAREFULLY

The warranty coverage that is extended to your Ford tractor is explained in the Warranty and Limitation of Liability form, a copy of which forms pages v and vi of this book. A further copy will be provided (pages vii and viii) which your dealer will remove from the book and ask you to sign after you have read it. Ask your dealer to explain any points that you do not understand.

Your tractor was designed to power and propel itself. It is intended for use in normal and customary agricultural applications.

Do not modify or alter or permit anyone else to modify or alter this tractor or any of its components or any tractor function without first consulting a Ford New Holland Dealer. If you have any questions regarding tractor modification contact Ford New Holland, Inc., at one of the addresses shown on the following page.

A Roll Over Protective Structure (ROPS) and seat belt were standard equipment for the tractor at time of factory assembly. If the ROPS was modified by the original customer or has been removed, it is recommended that you equip your tractor with a Roll Over Protection Structure (ROPS) and seat belt. ROPS and seat belts are effective in reducing injuries during tractor overturn accidents. Overturning a tractor without ROPS can result in serious injury or death. Further instructions regarding the care and use of the ROPS will be found on page ix of this book.

A Roll Over Protective Structure (ROPS) and seat belt are available for your Ford tractor. If your tractor is not equipped with a ROPS or safety cab and seat belt see your Ford New Holland Dealer.

Safety and instructional decals should be kept clean and replaced if they become damaged, illegible or are missing. Pictures of the safety decals as well as placement instructions are to be found on pages x and xi of this book.

Your safety and the safety of those around you depends upon the care and good judgment you use while operating this equipment. Read the safety precautions carefully.

PARTS AND SERVICE CATALOGUES AVAILABLE!

Ford New Holland is pleased to announce to owners of Ford tractors and equipment the availability of numerous parts and service catalogues.

To obtain these catalogues merely fill out the order form available from your local authorized Ford New Holland Dealer.

OWNER ASSISTANCE

We at Ford New Holland and your Ford New Holland dealer want you to be completely satisfied with your investment. Normally any problems with your equipment will be handled by your dealer's Service Department. Sometimes, however, misunderstanding can occur. If your problem has not been handled to your satisfaction, we suggest the following:

Contact the owner or General Manager of the dealership, explain the problem, and request assistance. When additional assistance is needed, your dealer has direct access to our branch office. If you cannot obtain satisfaction by doing this, contact the Ford New Holland branch office in your area and provide them with:

- Your name, address, and telephone number
- Machine model and serial number
- Dealership name and address
- Machine purchase date and amount of use
- Nature of problem

Atlanta

2000 Mountain Ind. Blvd. Tucker, GA 30084

Telephone: (404) 723–3615

Dallas

P.O. Box 10227 Dallas, TX 75207

Telephone: (214) 939–4919 Telephone: (403) 569–3208

Minneapolis

P.O. Box 1342

Minneapolis, MN 55440 Telephone: (612) 887–4232

If you need further assistance contact:

Consumer Services Department Mail Station 500 Ford New Holland, Inc. New Holland, PA 17557

New Holland

500 Diller Avenue New Holland, PA 17557 Telephone: (717) 285 8302

Calgary

Box 1616, Main P.O. Calgary, AB CANADA T2P 2M7

Before contacting Ford New Holland's branch office or Service Department, be aware that your problem will likely be resolved in the dealership using the dealer's facilities, equipment and personnel. So it is important that your initial contact be with the dealer.

A Service Publications Catalog & Order Form is available which lists the operator's and service manuals for many prior model and most current model Ford – New Holland – Versatile tractors, equipment and consumer products. To obtain a copy of this catalog, please call 1–800–635–4913.



FORD NEW HOLLAND INC. AND FORD NEW HOLLAND CANADA LTD.

WARRANTY AND LIMITATION OF LIABILITY - 3230, 3430, 3930, 4630 and 5030 TRACTORS

COVERAGE PROVIDED

Ford New Holland Inc. or Ford New Holland Canada Ltd., hereinafter called the "Company" warrants to the retail purchaser of each new Product (as listed below) that the Selling Dealer will repair or replace any part thereof found to be defective in materials or workmanship within the following periods. This warranty is for the benefit of the original or subsequent purchaser when purchased from an authorized Ford New Holland dealer.

BASIC WARRANTY Warranty Period Agricultural Tractor, Models 3430, 3930, 4630 and 5030	
	30 days of to end of basic warranty (whichever is longer)
Extended Power Train Warranty Selected power train components are covered for a period of 24 m 2,000 hours. The power train components covered by extended w	onths provided that the tractor has not been used more than a total of varianty consist of the following:
Engine – The rocker arm cover, cylinder head, engine block, cran closed within these units.	kcase pan and timing gear cover of the engine, and the parts fully en-
	case, dual power housing, differential housing, final drive housings, rithin these housings, including the drive axles, but excluding the hy-
LIMITATIONS, INCLUDING DISCLAIMER OF IMPLIED This warranty gives you specific legal rights and you may also have	WARRANTIES AND CONSEQUENTIAL DAMAGES ave other rights which vary, depending on state or provincial laws.
connection with these products. TO THE EXTENT ALLOWED I OR FITNESS APPLICABLE TO THIS PRODUCT IS LIMITED	authorize any person to create for it any other obligation or liability in BY LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY TO THE STATED DURATION OF THIS WRITTEN WARRANTY. IALL BE LIABLE FOR LOSS OF THE USE OF THE PRODUCT, OR CONSEQUENTIAL DAMAGES.
Some states and provinces do not allow limitations on how long an iconsequential damages, so the above limitations or exclusions may	mplied warranty will last or the exclusion or limitation of incidental or ay not apply to you.
The remedy of repair or replacement of a defective part during th remedy.	e warranty period herein specified shall be the purchaser's exclusive
EXTENDED SERVICE PLAN (ESP)	
When offered by the Company, the option to purchase an Extend	ed Service Plan has been explained and:
I accept and have signed the completed registration form	•
I decline the Extended Service Plan	
☐ I will consider later (within 180 days)	
PROTECTIVE EQUIPMENT A Roll Over Protective Structure (ROPS) and seat belt are provider and we strongly recommend their use. Customers who elect to re	d as standard equipment on all Ford New Holland agricultural tractors emove or not use this protection do so at their own risk.
I acknowledge the existence of OSHA regulations pertaining	g to ROPS.
A PTO master shield has been furnished with delivery of the	
The correct Operator's Manual has been furnished.	
•	1
Safety precautions were explained to me by the Selling Dea	er.
ACKNOWLEDGEMENT The blank spaces under "Protective Equipment" have been filled Warranty and Limitation of Liability.	in and are correct, and I acknowledge that I have read and accept this
Purchaser	Dealer Code
Address	Address
City State Zip	City State Zip
Model Serial No	Basic Warranty Expires on///
Retail Date//	Extended Service Plan Expires on////
Purchaser Date	Dealer Date

Additional details on back

Ford New Holland Warranty Detail

The warranty period will begin on date of original retail sale or date of original use, whichever is earlier.

- The obligation of the Company to the purchaser under this warranty is limited to the repair or replacement of defective parts by an authorized Ford New Holland dealer and will be done free of charge for both parts and labor using genuine Ford New Holland replacement parts. Repair or replacement in accordance with this warranty shall constitute fulfillment of all liabilities of the Company and the Selling Dealer in respect of such Products.
- Repairs or replacements will be performed by the Selling Dealer, following delivery of the Commercial Product by the
 purchaser to the Dealer's place of business. When the purchaser has moved a long distance from the Selling Dealer or the
 Selling Dealer is no longer in business, any Ford New Holland dealer authorized to sell and service the described Products may
 perform the repair at its dealership.
- The Selling Dealer shall review these warranty provisions with the purchaser prior to retail sale, secure his acknowlegement of
 delivery of this warranty and record the date of original retail sale or date of original use.
- To obtain warranty service, the purchaser must (1) report the product defect to an authorized Ford New Holland dealer and
 request repair within the applicable warranty term and (2) present evidence of the warranty start date.

WHAT IS NOT COVERED BY THE WARRANTY

- 1. This warranty shall **NOT** apply under the following conditions:
 - (i) With respect to vendor warranty items such as Deutz, Cummins and Caterpillar engines, or tires, tubes and attachments which shall be warranted by their manufacturer, or local representative thereof..
 - (ii) If the unit has been subject to misapplication, abuse, misuse, negligence of proper maintenance or other negligence, fire or other accident.
 - (iii) If parts or attachments other than those made or marketed by Ford New Holland Inc. or Ford New Holland Canada Ltd., have been used in connection with the unit and in the sole judgment of the Company such use affects its performance, stability or reliability.
 - (iv) If the unit has been altered or repaired outside of a Ford New Holland dealership in a manner which, in the sole judgment of the Company, affects its performance, stability or reliability.
 - (v) Batteries are covered by a separate pro rata adjustment warranty. The pro-rata plan covers the battery fully for the basic product warranty period, as indicated, wih any remaining warranty pro-rated according to the months of service.
 - (vi) The customer shall be responsible for payment of dealer travel time to the machine or to deliver the machine to the dealer's service shop for repair. The Ford New Holland warranty does not cover delivery charges or travel time.
 - (vii) With the exception of special Owner Protection Programs, the Company shall have no liability for used equipment sold beyond the specified coverage period.
 - (viii) No warranty shall apply to damage resulting from accident or damage caused by environment (such as exposure to corrosive material). The Company shall not be responsible for rental equipment used to replacement the equipment being repaired.
 - (ix) This warranty shall **NOT** apply to normal maintenance services (such as tune-ups, fuel injection system cleaning or wheel, brake and clutch adjustments), to normal replacement of service items (such as filters and brake or clutch linings), or to normal deterioration due to use or exposure (such as belts and exterior finish). Ford New Holland shall not be responsible for normal replacement parts such as cutting knives, chains, belts, filters, oil, or other parts which are worn out, unless they are determined to be defective in material or workmanship.
 - (x) This warranty shall **NOT** apply to any Ford New Holland Product which is retailed or distributed by anyone other than Ford New Holland Inc. or Ford New Holland Canada Ltd., through its authorized dealer. This warranty shall **NOT** apply to any Product which is normally operated outside of the United States and/or Canada.
 - (xi) This warranty shall **NOT** apply if the purchaser, insurance company, or any other entity or individual acting on behalf of the purchaser seeks re-imbursement for the dollar value of the repair(s) or replacement(s) covered under this warranty.

RIGHT TO MAKE DESIGN CHANGES

The Company reserves the right to make changes in the design and other changes in its products at any time and from time to time without notice and without incurring any obligation with respect to any product previously ordered from it, sold or shipped by it.



FORD NEW HOLLAND INC. AND FORD NEW HOLLAND CANADA LTD.

WARRANTY AND LIMITATION OF LIABILITY - 3230, 3430, 3930, 4630 and 5030 TRACTORS

COVERAGE PROVIDED

Ford New Holland Inc. or Ford New Holland Canada Ltd. hereinafter called the "Comp

Product (as listed below) that the Selling Dealer will repair or re	natter called the "Company" warrants to the retail purchaser of each new place any part thereof found to be defective in materials or workmanship the original or subsequent purchaser when purchased from an authorized	
Extended Power Train Warranty Selected power train components are covered for a period of 24 2,000 hours. The power train components covered by extended	4 months provided that the tractor has not been used more than a total of discouranty consist of the following:	
Engine – The rocker arm cover, cylinder head, engine block, cr closed within these units.	rankcase pan and timing gear cover of the engine, and the parts fully en-	
	ion case, dual power housing, differential housing, final drive housings, d within these housings, including the drive axles, but excluding the hy-	
LIMITATIONS, INCLUDING DISCLAIMER OF IMPLIE This warranty gives you specific legal rights and you may also	ED WARRANTIES AND CONSEQUENTIAL DAMAGES have other rights which vary, depending on state or provincial laws.	
connection with these products. TO THE EXTENT ALLOWED OR FITNESS APPLICABLE TO THIS PRODUCT IS LIMITE	not authorize any person to create for it any other obligation or liability in D BY LAW, ANY IMPLIED WARRANTY OF MERCHANTABILITY ED TO THE STATED DURATION OF THIS WRITTEN WARRANTY. SHALL BE LIABLE FOR LOSS OF THE USE OF THE PRODUCT, SOR CONSEQUENTIAL DAMAGES.	
Some states and provinces do not allow limitations on how long an implied warranty will last or the exclusion or limitation of incidental or consequential damages, so the above limitations or exclusions may not apply to you.		
The remedy of repair or replacement of a defective part during remedy.	the warranty period herein specified shall be the purchaser's exclusive	
EXTENDED SERVICE PLAN (ESP) When offered by the Company, the option to purchase an Exte I accept and have signed the completed registration form I decline the Extended Service Plan I will consider later (within 180 days)	nded Service Plan has been explained and:	
PROTECTIVE EQUIPMENT A Roll Over Protective Structure (ROPS) and seat belt are provi and we strongly recommend their use. Customers who elect to	ded as standard equipment on all Ford New Holland agricultural tractors or remove or not use this protection do so at their own risk.	
• I acknowledge the existence of OSHA regulations pertaining to ROPS.		
 A PTO master shield has been furnished with delivery of the machine. 		
• The correct Operator's Manual has been furnished.		
• Safety precautions were explained to me by the Selling D	ealer.	
ACKNOWLEDGEMENT The blank spaces under "Protective Equipment" have been fill Warranty and Limitation of Liability.	ed in and are correct, and I acknowledge that I have read and accept this	
Purchaser	Dealer Code	
Address	Address	
City State Zip	City State Zip	
Model Serial No	Basic Warranty Expires on///	
Retail Date//	Extended Service Plan Expires on///	
Purchaser Date	Dealer Date	

Additional details on back

Ford New Holland Warranty Detail

The warranty period will begin on date of original retail sale or date of original use, whichever is earlier.

- The obligation of the Company to the purchaser under this warranty is limited to the repair or replacement of defective parts by an authorized Ford New Holland dealer and will be done free of charge for both parts and labor using genuine Ford New Holland replacement parts. Repair or replacement in accordance with this warranty shall constitute fulfillment of all liabilities of the Company and the Selling Dealer in respect of such Products.
- Repairs or replacements will be performed by the Selling Dealer, following delivery of the Commercial Product by the
 purchaser to the Dealer's place of business. When the purchaser has moved a long distance from the Selling Dealer or the
 Selling Dealer is no longer in business, any Ford New Holland dealer authorized to sell and service the described Products may
 perform the repair at its dealership.
- The Selling Dealer shall review these warranty provisions with the purchaser prior to retail sale, secure his acknowlegement of delivery of this warranty and record the date of original retail sale or date of original use.
- To obtain warranty service, the purchaser must (1) report the product defect to an authorized Ford New Holland dealer and request repair within the applicable warranty term and (2) present evidence of the warranty start date.

WHAT IS NOT COVERED BY THE WARRANTY

- 1. This warranty shall **NOT** apply under the following conditions:
 - (i) With respect to vendor warranty items such as Deutz, Cummins and Caterpillar engines, or tires, tubes and attachments which shall be warranted by their manufacturer, or local representative thereof..
 - (ii) If the unit has been subject to misapplication, abuse, misuse, negligence of proper maintenance or other negligence, fire or other accident.
 - (iii) If parts or attachments other than those made or marketed by Ford New Holland Inc. or Ford New Holland Canada Ltd., have been used in connection with the unit and in the sole judgment of the Company such use affects its performance, stability or reliability.
 - (iv) If the unit has been altered or repaired outside of a Ford New Holland dealership in a manner which, in the sole judgment of the Company, affects its performance, stability or reliability.
 - (v) Batteries are covered by a separate pro rata adjustment warranty. The pro-rata plan covers the battery fully for the basic product warranty period, as indicated, wih any remaining warranty pro-rated according to the months of service.
 - (vi) The customer shall be responsible for payment of dealer travel time to the machine or to deliver the machine to the dealer's service shop for repair. The Ford New Holland warranty does not cover delivery charges or travel time.
 - (vii) With the exception of special Owner Protection Programs, the Company shall have no liability for used equipment sold beyond the specified coverage period.
 - (viii) No warranty shall apply to damage resulting from accident or damage caused by environment (such as exposure to corrosive material). The Company shall not be responsible for rental equipment used to replacement the equipment being repaired.
 - (ix) This warranty shall NOT apply to normal maintenance services (such as tune-ups, fuel injection system cleaning or wheel, brake and clutch adjustments), to normal replacement of service items (such as filters and brake or clutch linings), or to normal deterioration due to use or exposure (such as belts and exterior finish). Ford New Holland shall not be responsible for normal replacement parts such as cutting knives, chains, belts, filters, oil, or other parts which are worn out, unless they are determined to be defective in material or workmanship.
 - (x) This warranty shall **NOT** apply to any Ford New Holland Product which is retailed or distributed by anyone other than Ford New Holland Inc. or Ford New Holland Canada Ltd., through its authorized dealer. This warranty shall **NOT** apply to any Product which is normally operated outside of the United States and/or Canada.
 - (xi) This warranty shall NOT apply if the purchaser, insurance company, or any other entity or individual acting on behalf of the purchaser seeks re-imbursement for the dollar value of the repair(s) or replacement(s) covered under this warranty.

RIGHT TO MAKE DESIGN CHANGES

The Company reserves the right to make changes in the design and other changes in its products at any time and from time to time without notice and without incurring any obligation with respect to any product previously ordered from it, sold or shipped by it.

ROPS

ROLL OVER PROTECTIVE STRUCTURES

A Roll Over Protective Structure (ROPS) and seat belt were standard equipment for the tractor at time of factory assembly. The seat belt, when used by the operator, maximizes the protection offered by the ROPS. Always use your seat belt when the ROPS is installed – seat belts save lives when they are used. Do **not** use your seat belt if the ROPS is not installed on the tractor.


If the ROPS was deleted by the original purchaser or has been removed, it is recommended that you equip your tractor with a Roll Over Protective Structure and seat belt. ROPS, when used with a seat belt, are effective in reducing injuries during tractor overturn accidents. Overturning a tractor without a ROPS can result in serious injury or death.

A Roll Over Protective Structure and seat belt are available from your Ford New Holland dealer.

ROPS MAINTENANCE AND INSPECTION

After the first 20 hours of operation and every 300 hours of operation (or six months, whichever comes first):

- 1. Check the torque of the ROPS mounting bolts. Tighten, if necessary, to $180-220\,lbf.ft.$ (244 298 Nm).
- 2. Check the operator's seat mounting bolts and the seat belt mounting points. Tighten bolts to torque and replace any worn or damaged parts.



Ford Roll Over Protective Structure (ROPS)

DAMAGE TO THE ROPS

If the tractor has rolled over or the ROPS has been damaged (such as striking an overhead object during transport), it must be replaced to provide the original protection.

After an accident, check for damage to the (1) ROPS, (2) operator's seat, (3) seat belt and seat belt mountings. Before you operate the tractor, replace all damaged parts.

DO NOT TRY TO WELD OR STRAIGHTEN THE ROPS.

WARNING: Never attach chains, ropes or cables to the ROPS for pulling purposes; this will cause the tractor to tip backwards. Always pull from the tractor drawbar. Be careful when driving through door openings or under low overhead objects. Make sure there is sufficient overhead clearance for the ROPS.

WARNING: If the ROPS is removed or replaced, make certain that the proper hardware is used to replace the ROPS and the recommended torque values are applied to the attaching bolts.

WARNING: Always wear your seat belt if the tractor is equipped with a ROPS. Do not use the seat belt if the ROPS is lowered or removed from the tractor.

FALLING OBJECT PROTECTIVE STRUCTURE (FOPS)

When a tractor is equipped with a front end loader and is not equipped with a safety cab, it is recommended that the tractor be fitted with a FOPS canopy to protect the operator from falling objects.

SAFETY DECALS

Replace all missing, damaged or illegible decals.



WARNING

TO JUMP START

(Negative Grounded Battery)

- Shield eyes 2. Connect end of one cable to positive (+) terminals of each battery.
 Connect one end of other cable to negative (-) terminal of "Good" battery.
 Connect other end to engine block of vehicle being started. TO PREVENT DAMAGE to other electrical components on vehicle being started, make certain that engine is
- to other electrical components on vehicle being started, make certain that engine is at idle speed before disconnecting jumper cables.

E9NN-10661-BA

Part No. E9NN-10661-BA Location: Top of battery

WARNING

- Before starting and operating
 - Know the operating and safety instruction in the operator's manual and on the tractor
 - Clear the area of bystanders
 - Locate and know operation of controls
 - Fasten your seat belt
- Start engine only from operators seat with transmission in neutral, PTO disengaged and hydraulic controls in lowered position
- Avoid accidental contact with gear shift lever while the engine is running Unexpected tractor movement can result
- Slow down on turns, rough ground and slopes to avoid upset
- Do not permit anyone but the operator to ride on the tractor There is no safe place for riders
- Lock brakes together, use warning lights and SMV emblem while driving on roads
- Lower equipment, place gear shift levers in neutral, stop engine and apply parking brake before leaving tractor seat.

FAILURE TO FOLLOW ANY OF THE INSTRUCTIONS ABOVE CAN CAUSE SERIOUS INJURY TO THE OPERATOR OR OTHER PERSONS

(Replacement manuals are available from your Ford New Holland dealer or from Ford New Holland service publications - 500 Diller Avenue - New Holland, Pennsylvania 17557)

FONN-16A901-AA

Part No. F0NN-16A901-AA Location: Right-hand fender

EMERGENCY STOPPING AND PARKING BRAKE

Part No. D2NN-2K106-A

Location: Handbrake lever (where fitted)

A WARNING

- SET PARKING BRAKE AND PLACE SHIFT LEVERS IN NEUTRAL BEFORE DISMOUNTING.
- FAILURE TO OBSERVE THE ABOVE WARNING MAY ALLOW TRACTOR MOVEMENT CAUSING PERSONAL INJURY.

Part No. E4NN-7Z273-DA Location: Right-hand fender

WARNING

- Start engine only from operators seat. If safety start switch is bypassed engine can start with transmission in gear.
- Do not connect or short across terminals on starter solenoid.
- Attach booster cables as shown on battery decal and operators manual.

Starting in gear causing runaway can result in serious injury.

EINN-16A901-EA

Part No. E1NN-16A901-EA Location: Starting motor

SAFETY DECALS

Replace all missing, damaged or illegible decals.

WARNING

- Pull only from drawbar. Pulling from any other point can cause rear overturn.
- Do not operate with unshielded PTO.
- Disengage PTO and stop engine before servicing tractor or implements or attaching and detaching implements.
- Position drawbar at 14" from end of PTO shaft to drawbar hole for 540 and 16" for 1000 PTO RPM.
- When towing equipment use a safety chain.

FAILURE TO FOLLOW ANY OF THE INSTRUCTIONS ABOVE CAN CAUSE SERIOUS INJURY TO THE OPERATOR OR OTHER PERSONS.

NH-16A301-E

Part No. E1NN-16A901-BA

Location: Rear axle housing - right-hand side



Part No. FONN–94518R55–AA

Location: All models – Instrument panel, plus:
Folding ROPS – Center rear
Telescopic ROPS – left–hand side



Part No. 163154

Location: Telescopic ROPS - left-hand side

DANGER - EXPLOSIVE CAN CAUSE BLINDNESS OR SEVERE INJURY. PROTECT EYES. SPARKS, FLAMES, CIGARETTES CAN CAUSE EXPLOSION: TOOLS AND CABLE CLAMPS CAN CAUSE SPARKS. DO NOT USE WITHOUT INSTRUCTION. KEEP VENT CAPS TIGHT AND LEVEL.

ACID - POISON CAUSES SEVERE BURNS.
CONTAINS SULFURIC ACID. IN EVENT OF CONTACT,
FLUSH WITH WATER AND SEE A DOCTOR.
KEEP OUT OF REACH OF CHILDREN

Part No. E9NN-10K694-DA Location: Top of battery



Part No. D8NN-8653-AB Location: Both sides of

radiator fan shroud

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com