

ORIGINAL INSTRUCTIONS
- according to Directive 2006/42/EC, Annex I, 1.7.4.1

Maxxum 100
Maxxum 110
Maxxum 115
Maxxum 125
Maxxum 140
Tractors

OPERATOR'S MANUAL

Part Number 47380088

2nd edition English
July 2012



SECTION SUMMARY

1 - GENERAL INFORMATION AND SAFETY

2 - CONTROLS, INSTRUMENTS AND OPERATION

3 - FIELD OPERATION

4 - LUBRICATION AND MAINTENANCE

5 - FAULT FINDING

6 - VEHICLE STORAGE

7 - ACCESSORIES

8 - SPECIFICATIONS

9 - FIRST 50 HOUR SERVICE FORMS

10 - INDEX

CONTENTS

Title	Page
CE Declaration of Conformity Document	4
Metric and Imperial Units Abbreviations	6
Section 1 - General Information and Safety	
To the Owner	1-1
Product Identification	1-3
Ecology and the Environment	1-6
Safety Precautions	1-7
Safety Decals	1-15
International Symbols	1-23
Airborne Noise Emission	1-24
Tractor Vibration Level Information Sheet	1-26
Machine Stability	1-27
Protection offered by the tractor	1-31
Intended use of your tractor	1-34
Passenger's seat	1-36
Safety Aspects	1-38
Section 2 - Controls, Instruments and Operation	
Cab	2-7
Seats	2-25
Handbrake, Throttle and Foot Controls	2-32
Instrument Console	2-34
Analogue/Digital Instruments	2-37
Synchro Shift Transmission (12 x 12)	2-67
Two-speed Powershift Transmission (24 x 24)	2-73
Semi-Powershift Transmission (16 x 16 and 17 x 16))	2-84
Differential Lock and Four Wheel Drive	2-102
Section 3 - Field Operation	
Important Information	3-2
Using Jump Leads (Booster Cables)	3-6
Starting the Engine	3-7
Stopping the Engine	3-12
Turn Assist	3-14
Rear Power Take-Off	3-16
Front Power Take-Off and Hydraulic Lift	3-35
Mechanical Lower Link Sensing Hydraulics	3-43
Electronic Hitch Control	3-49
Remote Control Valves	3-61
Electro-Hydraulic Remote Control Valves	3-71
Three-point Hitch	3-85
Quick Hitch	3-92
Linkage Stabilisers	3-97

Drawbars and Towing Attachments	3-99
Hydraulic Trailer Brakes	3-115
Air-Operated Trailer Brakes	3-117
Front Wheel Track Adjustment	3-123
Rear Wheel Track Adjustment	3-130
Ballasting and Tyres	3-137

Section 4 - Lubrication and Maintenance

General Information	4-1
Tractor jacking points	4-5
Guard Removal	4-6
Lubrication and Maintenance Chart	4-11
Servicing: When Warning Lights Illuminate	4-12
10-hour/daily service	4-15
50-hour service	4-18
100-hour service	4-29
300-hour service	4-29
600-hour service	4-33
1200-hour/12 month service	4-40
1200-hour/24 month service	4-45
1800-hour service	4-52
Every 3 years	4-53
General Maintenance - as required	4-54

Section 5 - Fault Finding

Introduction	5-1
Engine	5-2
Transmission - 12 x 12 Synchro Shift	5-5
Transmission - 24 x 24 Two-speed Powershift	5-6
Transmission - 16 x 16 (17 x 16) Semi-Powershift	5-7
Hydraulics	5-8
Rear Three-Point Hitch	5-9
Brakes	5-10
Cab	5-10
Electrical	5-11

Section 6 - Vehicle Storage 6-1

Section 7 - Accessories

Engine Coolant Immersion Heater	7-2
Transmission Oil Heater	7-2
40 Amp Socket and Cable	7-3
Auxiliary Headlights	7-3
Battery Isolator Switch	7-4
Loader Subframe and Control Valve (Joystick)	7-5
Front-end loader fixation points	7-9


Section 8 - Specification

General Dimensions 8-2
Vehicle Weights 8-6
Lubricant and Fluid Capacities 8-8
Engine 8-9
Fuel System 8-9
Cooling System 8-10
Transmission Options 8-10
Brakes 8-11
Rear Power Take-Off 8-11
Front Power Take-Off 8-12
Steering 8-12
Maximum Operating Angle 8-12
Hydraulic System 8-13
Three-Point Hitch 8-14
Remote control valves 8-20
Front Three-Point Hitch 8-20
Front Remote Valves 8-21
Electrical Equipment 8-21
Hardware Torque Tables 8-22

Section 9 - First 50-hour Service Forms 9-1

Section 10 - Index 10-1

CE DECLARATION OF CONFORMITY DOCUMENT

Class of 2006/42/EC Annex II	BG Декларация ЕС за съответствие според Директива 2006/42/ЕО	CZE Prohlášení o shodě ES Podle směrnice 2006/42/ES	DA EU-overensstemmelseserklæring i henhold til direktivet 2006/42/EF	DE EG-Konformitätserklärung laut Richtlinie 2006/42/EG	EL Δήλωση Συμμόρφωσης ΕΚ Σύμφωνα με την Οδηγία 2006/42/ΕΚ	 CNH Europe Holding S.A. Boulevard Royal, 24 L-2449 LUXEMBOURG (Luxembourg)
1.A.1	№1, [1]	№1, [1]	№1, [1]	№1, [1]	№1, [1]	
1.A.2	Представявам от Giuseppe Gavioli, CNH Europe Holding S.A., 24, Boulevard Royal L-2449 Luxembourg	Zastupujem Giuseppe Gavioli, CNH Europe Holding S.A., 24, Boulevard Royal L-2449 Luxembourg	repræsenteret af Giuseppe Gavioli, CNH Europe Holding S.A., 24, Boulevard Royal L-2449 Luxembourg	wetrenen durch Giuseppe Gavioli, CNH Europe Holding S.A., 24, Boulevard Royal L-2449 Luxembourg	απορροπώμαι από τον Giuseppe Gavioli, CNH Europe Holding S.A., 24, Boulevard Royal L-2449 Luxembourg	(2) CASE II
1.A.3	Декларацията, посочена на мястото отговорност, не прогласява: Семейственически трактор Типове: име: [2] Модел: [3] Тип: [4] Серийен номер: [5] за който се отнася настоящата декларация, е съобразен с изискванията на Директива 2006/42/ЕО, променена с [6].	Prohlášení je platné pouze pro výrobek: Zemědělský traktor Obchodní název: [2] Model: [3] Typ: [4] Výrobni číslo: [5] na který se toto prohlášení vztahuje, odpovídá ustanovením Směrnice 2006/42/ES a následujícím změnám: [6].	erklærer på eget ansvar, at produktet: Landbrugstraktor Handelsnavn: [2] Model: [3] Type: [4] Serienummer: [5] hvortil denne erklæring henviser, opfylder alle de relevante krav i direktivet 2006/42/EF, ændret ved: [6].	entwässen auf unsere alleinige Verantwortung, dass das Produkt: Landwirtschaftliche Zugmaschine Handelsbezeichnung: [2] Modell: [3] Typ: [4] Serienummer: [5] auf das sich diese Erklärung bezieht, allen einschlägigen Bestimmungen der Richtlinie 2006/42/EG entspricht, abgeändert durch: [6].	επιβεβαιώνω, ότι αποκλειστικά μου εγγυώμαι, ότι το προϊόν: Γεωργικό Εξοπλισμό Εμπορικό ονομασία: [2] Μοντέλο: [3] Τύπος: [4] Σειριακός αριθμός: [5] στο οποίο αναφέρεται η δήλωση αυτή, είναι σύμφωνα με τις ορισμένες διατάξεις της Οδηγίας 2006/42/ΕΚ, όπως έχει τροποποιηθεί με: [6].	(3)
1.A.4	За реализацията на изискванията от Директива 2006/42/ЕО, са приложени следните (хармонизираните) стандарти: ISO 26322-1 част 1 и част 2 Други стандарти: вж. Ръководство за употреба.	Pro relevantní implementaci ustanovení této Směrnice byly aplikovány následující normy: ISO 26322-1 část 1 a část 2 Ostatní normy: viz Návod pro použití a údržbu.	Følgende (harmoniserede) standarder er anvendt for opfyldelse af kravene i direktivet: ISO 26322-1, del 1 eller 2 Andre Normer: se i henhold til Brugervejledningen og Vedligeholdelsesmanualen.	Zur sachgemäßen Umsetzung der Festlegungen in der Richtlinie wurden folgende (harmonisierte) Normen herangezogen: ISO 26322-1 Teil 1 oder 2 Andere Normen: siehe in der Gebrauchs- und Wartungsanleitung.	Επιβεβαιώνω, ότι ακολουθώ τα προδιαγραφόμενα (αρμονισμένα) πρότυπα: ISO 26322-1 μέρος 1 ή 2 Άλλες προδιαγραφές: αναφέρεται στο Εγχειρίδιο Χρήστη και Συντήρησης.	(4)
1.A.7	Име и подпис на упълномощеният лице: [8]	Iměno a podpis pověřeného osoby: [8]	Bemyndigedes navn og underskrift: [8]	Name und Unterschrift des Befugten: [8]	Όνομα και υπογραφή του εξουσιοδοτημένου προσώπου: [8]	(5)
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.3						
1.A.2						
1.A.1						
1.A.10						
1.A.9						
1.A.8						
1.A.7						
1.A.6						
1.A.5						
1.A.4						
1.A.						

For your better and easier understanding of the document you'll find original text reproduced hereafter together with some notes

Clause of 2006/42/EC Annex II	EN EC Declaration of conformity According to Directive 2006/42/EC.
1.A.1	We, [1]
1.A.2	represented by Giuseppe Gavioli, CNH Europe Holding S.A. 24, Boulevard Royal L-2449 Luxembourg
1.A.3	declare under our sole responsibility, that the product: Agricultural tractor Trade Name: [2] Model: [3] Type: [4] Serial Number: [5]
1.A.4	to which this declaration relates, fulfils all the relevant provisions of the Directive 2006/42/EC, amended by [6].
1.A.7	For the relevant implementation of the provisions of the Directive, the following (harmonised) standards have been applied: • ISO 26322-1 part 1 or 2 Other standards: see Operators Manual
1.A.9	Place and date of the declaration: [7]
1.A.10	Name and signature of the authorised person: [8]

HEALTH AND SAFETY RELATED STANDARDS APPLIED TO YOUR TRACTOR

- FOPS level on your tractor cab is certified according to **OECD Code 10**.
- HVAC (Heating, ventilation Air Conditioning) CAB is certified **Category 1** according to **EN 15695-1**.

NOTE: See safety section 1 in this manual for further explanation and details on above mentioned standards and specific terminology.

METRIC AND IMPERIAL UNITS ABBREVIATIONS

TYPICAL APPLICATIONS	RECOMMENDED SI (METRIC) UNITS		IMPERIAL UNIT	
	NAME	SYMBOL	NAME	SYMBOL
AREA				
Land area	hectare	ha	acre	
	square meter	m ²	square foot square inch	ft ² in ²
	square millimetre	mm ²	square inch	in ²
ELECTRICITY				
	ampere	A	ampere	A
	volt	V	volt	V
	microfarad	μF	microfarad	μF
	ohm	Ω	ohm	Ω
FORCE				
	kilonewton	kN	pound	lb
	newton	N	pound	lb
FORCE PER LENGTH				
	newton per metre	N/m	pound per inch	lb/in
FREQUENCY				
	megahertz	MHz	Megahertz	MHz
	kilohertz	kHz	kilohertz	kHz
	hertz	Hz	hertz	Hz
FREQUENCY - ROTATIONAL				
	revolution per minute	r/min rpm	revolution per minute	r/min ^(a) rpm
LENGTH				
	kilometre	km	mile	mi
	meter	m	foot	ft
	centimetre	cm	inch	in
	millimetre	mm	inch	in
	micrometer	μm		
MASS				
	kilogram	kg	pound	lb
	gram	g	ounce	oz
	milligram	mg		

TYPICAL APPLICATIONS	RECOMMENDED SI (METRIC) UNITS		IMPERIAL UNIT	
	NAME	SYMBOL	NAME	SYMBOL
POWER				
	kilowatt	kW	horsepower	Hp
	watt	W	Btu per hour Btu per minute	Btu/hr Btu/min
PRESSURE or STRESS (FORCE PER AREA)				
	kilopascal	kPa	pound per square inch inch of mercury	psi inHg
	pascal	Pa	inch of water	inH ₂ O
	megapascal	Mpa	pound per square inch	psi
TEMPERATURE (other than THERMODYNAMIC)				
	degrees Celsius	°C	degrees Fahrenheit	°F
TIME				
	hour	h	hour	h
	minute	min	minute	min
	second	s	second	s
TORQUE (includes BENDING MOMENT, MOMENT OF FORCE, and MOMENT OF A COUPLE)				
	newton meter	N m N m	pound foot pound inch	lb ft lb in
VELOCITY				
	kilometre per hour	km/h	mile per hour	mph
	meter per second	m/s	foot per second	ft/s
	millimetre per second	mm/s	inch per second	in/s
	meter per minute	m/min	foot per minute	ft/min
VOLUME (includes CAPACITY)				
	cubic meter	m ³	cubic yard	yd ³ cu yd
	litre	l	cubic inch	in ³
	litre	l	US gallon UK gallon US quart UK quart	US gal UK gal US qt UK qt
	millilitre	ml	fluid ounce	fl oz

TYPICAL APPLICATIONS	RECOMMENDED SI (METRIC) UNITS		IMPERIAL UNIT	
	NAME	SYMBOL	NAME	SYMBOL
VOLUME PER TIME (includes DISCHARGE and FLOW RATE)				
	cubic meter per minute	m ³ /min	cubic foot per minute	ft ³ /min
	litre per minute	l/min	US gallon per minute	US gal/min
	millilitre per minute	ml/min	UK gallon per minute	UK gal/min
SOUND POWER LEVEL and SOUND PRESSURE LEVEL				
	decibel	dB	decibel	dB

SECTION 1

GENERAL INFORMATION AND SAFETY

TO THE OWNER

GENERAL

This Manual has been prepared to assist you in the correct procedure for running-in, driving and operating and for the maintenance of your new tractor. Read this Manual carefully. Your tractor is intended for use in normal and customary agricultural applications.

If at any time you require advice concerning your tractor, do not hesitate to contact your authorised dealer. He has factory trained personnel, genuine manufacturers' parts and the necessary equipment to carry out all your service requirements.

Your tractor has been designed and built to give maximum performance, economy and ease of operation under a wide variety of operating conditions. Prior to delivery, the tractor was carefully inspected, both at the factory and by your dealer to ensure that it reaches you in optimum condition. To maintain this condition and ensure trouble-free operation, it is important that the routine services, as specified in Section 4 of this Manual, are carried out at the recommended intervals.

OPERATORS MANUAL STORAGE

A storage pocket for the Operators Manual can be found on the rear of the seat. The manual should be kept in this pocket at all times when not in use.

CLEANING THE TRACTOR

Your tractor is a state-of-the-art machine with sophisticated, electronic controls. This should be borne in mind when cleaning the tractor, particularly if using a high pressure washer. Even though every precaution has been taken to safeguard electronic components and connections, the pressure generated by some of these machines is such that complete protection against water ingress cannot be guaranteed.

When using a high pressure washer, do not stand too close to the tractor and avoid directing the jet at electronic components, electrical connections, breathers, seals, filler caps, etc. Never direct a cold water jet at a hot engine or exhaust.

SAFETY

Pages 1-7 to 1-37 inclusive list the precautions to be observed to ensure your safety and the safety of others. Read the safety precautions and follow the advice offered **before** operating the tractor.

FIRST 50 HOUR SERVICE

In Section 9, at the back of this Manual, you will find the 50-hour service reports.

After you have operated the tractor for 50 hours, take your tractor, together with this Manual, to your dealer. He will then perform the factory recommended 50 hour service and complete the service report sheets (pages 9-1 and 9-3). The first sheet (page 9-1) is the dealer's copy and should be removed by the dealer after the service has been carried out. The second sheet (page 9-3) is your copy of the service performed. **Ensure that you and the dealer sign both copies.**

SERVICE PARTS

It should be pointed out that genuine parts have been examined and approved by the Company. The installation and/or use of 'non-genuine' products could have negative effects upon the design characteristics of your tractor and thereby affect its safety. The Company is not liable for any damage caused by the use of 'non-genuine' parts and accessories. Only genuine Case IH replacement parts should be used. The use of non-genuine parts may invalidate legal approvals associated with this product.

It is prohibited to carry out any modifications to the tractor unless specifically authorised, in writing, by the After Sales Service department of the Company.

WARRANTY

Your tractor is warranted according to legal rights in your country and the contractual agreement with the selling dealer. No warranty shall, however, apply if the tractor has not been used, adjusted and maintained according to the instructions given in the Operator's Manual.

EMISSION CONTROLS

ATTENTION: *The engine and fuel system on your machine is designed and built to government emissions standards. Tampering by dealers, customers, operators and users is **strictly prohibited by law**. Failure to comply could result in government fines, rework charges, invalid warranty, legal action and possible confiscation of the machine until rework to original condition is completed. Engine service and/or repairs must be done by a certified technician only!*

Buy Now



Our support email:

ebooklibonline@outlook.com