

# **7110E/20E Tractor**

## **Operators Manual**

9-15022








*THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.*

M171B

If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



# WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

TO THE OWNER

---

## TO THE OWNER

Read this manual before you start the engine or operate your tractor. If you need more information, see your dealer.

Your dealer can give you assistance with Case Corporation approved service parts. Your dealer has technicians with special training that know the best methods of repair and maintenance for your tractor.

Call your dealer if you need any assistance or information.

### MODEL 7110E TRACTOR With Mechanical Front Drive



A14153.55

**NOTE:** *When you are in the tractor seat looking forward, the right hand and left hand of the tractor are the same as your right hand and left hand.*

Rac 9-15022  
July, 1989 (Revised October, 1991)

TO THE OWNER










---

**MODEL 7120E TRACTOR**  
**With Mechanical Front Drive**



A14152.55

## GENERAL TABLE OF CONTENTS

Safety/Decals .....	6-14	
Instruments/Controls .....	15-49	
Operating Instructions.....	50-84	
Field Operation.....	85-137	
Tires/Wheels/Spacing/Ballast.....	138-166	
Lubrication/Filters/Fluids .....	167-205	
Maintenance/Adjustments.....	206-218	
Electrical System.....	219-233	
Specifications .....	234-241	
Detail Index.....	242-245	

IDENTIFICATION NUMBERS \_\_\_\_\_


## PRODUCT IDENTIFICATION AND SERIAL NUMBERS

Write your machine Model Number, Product Identification Number (P.I.N.), and Serial Numbers of major components on the lines provided. If needed, give these numbers to your dealer when you need parts or information for your machine.


1. TRACTOR MODEL NUMBER \_\_\_\_\_
2. PRODUCT IDENTIFICATION NUMBER \*JJA \_\_\_\_\_ \*
3. ENGINE SERIAL NUMBER \_\_\_\_\_
4. TRANSMISSION SERIAL NUMBER \_\_\_\_\_
5. CAB SERIAL NUMBER \_\_\_\_\_
6. AXLE SERIAL NUMBER \_\_\_\_\_

IDENTIFICATION NUMBERS


Identification Number Locations




Tractor Model and Product Identification Number




Tractor Model and Product Identification Number - Europe




Cab Serial Number



Engine Serial Number



MFD Axle Serial Number



Transmission Serial Number

## SAFETY

Understand that your safety and the safety of other persons is measured by how you service, and operate this machine. Know the positions and operations of all controls before you try to operate. **MAKE SURE YOU CHECK ALL CONTROLS IN A SAFE AREA BEFORE STARTING YOUR WORK.**

**READ THIS MANUAL COMPLETELY** and make sure you understand the controls. All equipment has a limit. Make sure you understand the speed, brakes, steering, stability, and load characteristics of this machine before you start to operate.

The safety information given in this manual does not replace safety codes, insurance needs, federal, state and local laws. Make sure your machine has the correct equipment needed by the local laws and regulations.

Case Corporation is continuing to work for your safety: by making tractors with better protection and by giving these rules for safe operation.



***THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.***

M171B

## Intended Use

This tractor is designed solely for use in customary agricultural or similar operation (intended use).

Use in any other way is considered as contrary to the intended use. The manufacturer accepts no liability for any damage or injury resulting from this misuse and these risks must be born solely by the user.

Compliance with and strict adherence to the conditions of operation, service and repair as specified by the manufacturer also constitute essential elements for the intended use.

This tractor should be operated, serviced and repaired only by persons familiar with all its particular characteristics and acquainted with the relevant safety rules (accident prevention).

The accident prevention regulations, all other generally recognised regulations on safety and occupational medicine and the road traffic regulations must be observed at all times.

Any arbitrary modifications carried out on the tractor will relieve the manufacturer of all liability for any resulting damage or injury.





## General Safety and Accident Prevention Regulations



1. In addition to the instructions contained in this operator's manual, also observe the general safety and accident prevention regulations.
2. Always comply with local traffic regulations when driving on public roads.
3. Before starting work, familiarize yourself with all the controls and instruments and their functions. During work is too late.
4. Start the engine only from the operator's seat.  
Never attempt to start engine by shorting across the starting motor terminals as the machine may immediately start to move.
5. Before moving away, always check the immediate vicinity of the machine ( e.g. for children). Ensure adequate visibility.
6. Never run the engine in a closed building.
7. Clothing worn by the operator must be close-fitting. Avoid wearing loose jackets, shirts or ties.
8. Handle fuel with care as it is highly flammable. Never refuel the machine in the vicinity of naked flames or sparks. Do not smoke during refuelling.
9. Always stop the engine and remove the main switch key before refuelling. Fill fuel tank outdoors. Clean up any spilled fuel immediately.
10. Prevent fires by keeping the machine clean.
11. Take care when handling brake fluid and battery acid (toxic and corrosive).



## Transporting Passengers



12. Passengers may only be carried if a proper passenger seat is fitted.
13. The carrying of passengers is otherwise not permitted.

**Buy Now**



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)