


# **150 and 190 Garden Tractors**

## **Operator's Manual**

**9-1851**

Reprinted








If Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates an potentially hazardous situation which if not avoided, will result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates an potentially hazardous situation which if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.

If Safety Decals on this machine are ISO two panel Pictorial, decals are defined as follows:

- The first panel indicates the nature of the hazard.
- The second panel indicates the appropriate avoidance of the hazard.
- Background color is YELLOW.
- Prohibition symbols such as   and  if used, are RED.



# WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site.

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

# **Operator's Instruction Manual**

## **150 and 190 Garden Tractors**



**J. I. CASE® CO.**

**RACINE, WISCONSIN U.S.A.**

## **NOTICE**

At the time your Case Dealer delivers your new tractor, he will acquaint you with its operation and maintenance as outlined in the "Delivery Procedure and Warranty Registration". When your Dealer has completed these instructions, he will ask you to sign the report and will then hand you a copy for your records.

### ***NOTE***

The "Delivery Procedure and Warranty Registration" also contains a record of the Pre-Delivery Checkup which your Dealer made on your tractor.

## **AFTER DELIVERY CHECKUP**

The Authorized Case Dealer from whom you purchased your new tractor will perform the "After Delivery Checkup" outlined on the following page, if you will arrange to bring your tractor to his Service Shop within - - -

60 days after date of delivery or 200 hours of operation (whichever occurs first).

### ***NOTE***

The only charge your dealer will make for this inspection will be for oil, filters, or other accessories.

## AFTER DELIVERY CHECKUP

..... (Owner's Name)		..... (Date Checkup Performed)	
..... (Owner's Address)			
..... (Dealership)		..... (Town)	
Tractor has been operated.....hours		..... (Tractor Model and Serial Number)	

### TRACTOR

- |   |   |
|---|---|
| <input type="checkbox"/> Operate hydraulic system.                                    | <input type="checkbox"/> Crankcase oil (Change oil if necessary).       |
| <input type="checkbox"/> Check tire pressure.   | <input type="checkbox"/> Oil level in transmission.                     |
| <input type="checkbox"/> Tighten cylinder head .                                      | <input type="checkbox"/> Lubricate all pressure fittings.               |
| <input type="checkbox"/> Check ignition timing.                                       | <input type="checkbox"/> Check air cleaner.                             |
| <input type="checkbox"/> Check spark plug and breaker point gap.                      | <input type="checkbox"/> Check tension of all belts.                    |
| <input type="checkbox"/> Check full governed no load engine speed and low idle speed. | <input type="checkbox"/> Check steering.                                |
| <input type="checkbox"/> Tighten all bolts (including rims).                          | <input type="checkbox"/> Check front wheel toe-in (190 only).           |
| <input type="checkbox"/> Cooling system.  | <input type="checkbox"/> Battery, starter - generator and lights.       |
|   | <input type="checkbox"/> Check operation of all instruments and levers. |

DEALER: Question purchaser carefully concerning his experience with tractor and answer any questions concerning maintenance or operation that are not clear to him.

Checkup.....  
Performed by.....

Signed.....  
Dealer.....

Original—Dealer  
Duplicate—Leave in Operators Manual  
for Purchaser

Signed.....  
Customer.....

## AFTER DELIVERY CHECKUP

..... (Owner's Name)		..... (Date Checkup Performed)
..... (Owner's Address)		
..... (Dealership)	..... (Town)	
Tractor has been operated..... hours		..... (Tractor Model and Serial Number)

### TRACTOR

- |   |   |
|---|---|
| <input type="checkbox"/> Operate hydraulic system.                                    | <input type="checkbox"/> Crankcase oil (Change oil if necessary).       |
| <input type="checkbox"/> Check tire pressure.   | <input type="checkbox"/> Oil level in transmission.                     |
| <input type="checkbox"/> Tighten cylinder head .                                      | <input type="checkbox"/> Lubricate all pressure fittings.               |
| <input type="checkbox"/> Check ignition timing.                                       | <input type="checkbox"/> Check air cleaner.                             |
| <input type="checkbox"/> Check spark plug and breaker point gap.                      | <input type="checkbox"/> Check tension of all belts.                    |
| <input type="checkbox"/> Check full governed no load engine speed and low idle speed. | <input type="checkbox"/> Check steering.                                |
| <input type="checkbox"/> Tighten all bolts (including rims).                          | <input type="checkbox"/> Check front wheel toe-in (190 only).           |
| <input type="checkbox"/> Cooling system.  | <input type="checkbox"/> Battery, starter - generator and lights.       |
|   | <input type="checkbox"/> Check operation of all instruments and levers. |

DEALER: Question purchaser carefully concerning his experience with tractor and answer any questions concerning maintenance or operation that are not clear to him.

Checkup.....  
Performed by

Signed.....  
Dealer

Original—Dealer  
Duplicate—Leave in Operators Manual  
for Purchaser

Signed.....  
Customer


## TO THE PURCHASER OF A CASE TRACTOR

The care you give your new Case Tractor will greatly determine the satisfaction and service life you will obtain from it. Use this manual as your guide. By observing the instructions and suggestions in this manual, your Case Tractor will serve you well for many years.

As an Authorized Case Dealer, we stock Genuine Case Parts, which are manufactured with the same precision and skill as the original equipment. Our factory trained staff is kept well informed on the best methods of servicing Case equipment and is ready and able to help you.

Should you require additional aid or information, contact us.

*Your Authorized Case Dealer*



HI FOLKS!-I'm Sammy Safety.  
Look for me to point out  
important Safety Precautions

To insure efficient and prompt service, please furnish us with the Model, Serial, Engine Model Number and Engine Specification Number of your Tractor in all correspondence or contacts.



Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)