

9350 Tractor

Operators Manual

Rac 9-26040



Reprinted



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

M171B

IMPORTANT

If This Machine Is Used By An Employee Or Is Loaned Or Rented, Make Certain That The Operator(s), Prior To Operating:

1. Is Instructed In Safe And Proper Use.
2. Reviews And Understands The Manual(s) Pertaining To The Machine.

TO THE OWNER

TO THE OWNER

This manual contains important information about the safe operation, adjustment and maintenance of your Case IH tractor. Refer to the Detail Index at the end of this manual for locating specific items about the tractor.

DO NOT operate or permit anyone to operate or service this tractor until you or other persons have read this manual. Use only trained operators who have demonstrated the ability to operate and service this tractor correctly and safely.

This tractor, with standard equipment and authorized attachments, is intended to be used for normal agricultural PTO, planting and tillage operations.

DO NOT use this tractor for any application or purpose other than those described in this manual. Consult an authorized dealer or the Case Corporation on changes, additions or modifications that can be required for this machine to comply with various country regulations and safety requirements. Unauthorized modifications can cause serious injury or death. Anyone making such unauthorized modifications is responsible for the consequences.

This Operators Manual is to be stored in the manual storage compartment provided on this tractor. Make sure this manual is complete and in good condition. Contact your dealer to obtain additional manuals or for any additional information or assistance about your tractor. Your dealer has Case Corporation approved service parts and has technicians with special training that know the best methods of repair and maintenance for your tractor.

Model 9350 Tractor (Bar Axle)



NOTE: When you are in the tractor seat looking forward, the right hand and left hand of the tractor are the same as your right and left hand.


TO THE OWNER _____

Model 9350 Tractor (Planetary Axle)



F00122











Manual Storage Compartment



Keep the operators manual in the storage compartment provided in your tractor cab. The operators manual must be available for use by all operators.

IMPORTANT: Also, refer to the *Cummins Engine Operation and Maintenance Manual* supplied with your tractor for supplemental engine maintenance information and procedures not covered in this manual. Adhere to the *Lubrication and Maintenance Schedule* as outlined in this manual on Page 161 and 162.

GENERAL TABLE OF CONTENTS

SAFETY/DECALS	6	
INSTRUMENTS/CONTROLS	15	
OPERATING INSTRUCTIONS	44	
FIELD OPERATION	81	
TIRES/WHEELS/SPACING/BALLAST	119	
LUBRICATION/FILTERS/FLUIDS	161	
MAINTENANCE/ADJUSTMENTS	215	
ELECTRICAL SYSTEM	225	
SPECIFICATIONS	240	
DETAIL INDEX	247	


IDENTIFICATION NUMBERS _____

PRODUCT IDENTIFICATION AND SERIAL NUMBERS


Write your machine Model Number, Product Identification Number (P.I.N.), and Serial Numbers of major components on the lines provided. If needed, give these numbers to your dealer when you need parts or information for your machine.

1. TRACTOR MODEL NUMBER _____
2. PRODUCT IDENTIFICATION NUMBER * JEE _____ *
3. ENGINE SERIAL NUMBER _____
4. TRANSMISSION SERIAL NUMBER _____
5. CAB OR ROPS SERIAL NUMBER _____
6. AXLE SERIAL NUMBER - FRONT _____
7. AXLE SERIAL NUMBER - REAR _____

Identification Number Locations



TRACTOR MODEL AND PRODUCT IDENTIFICATION NUMBERS



ROPS SERIAL NUMBER

Buy Now



Our support email:

ebooklibonline@outlook.com