

**Gasoline,
Low Cost Fuel, LP Gas
Dual Range Drive
700 Series
Tractor**

Operators Manual

9-411


Reprinted



TABLE OF CONTENTS

| | Page |
|--|--------------|
| Serial Number | 8 |
| General Specifications | 9 thru 26 |
| Lubrication | 27 thru 49 |
| Pressure Fittings..... | 30 thru 34 |
| Engine Lubrication..... | 37 thru 41 |
| Transmission Lubrication..... | 42 thru 44 |
| Hydraulic Control System..... | 45 |
| Hydraulic Power Steering Attachment..... | 47 and 48 |
| Independent Power Take-off..... | 49 |
| Operating Instructions | 51 thru 117 |
| Run-In Procedure..... | 52 |
| Operating Controls and Instrument Guide..... | 54 thru 58 |
| Engine Starting Procedure..... | 60, 61 |
| Stopping Engine..... | 61 |
| Cold Weather Operation..... | 62, 63 |
| Case Dual-range Transmission..... | 64 |
| Rear Tire Sizes..... | 67 |
| Rear Wheel and Front End Weights..... | 68 |
| Drawbar..... | 69 thru 71 |
| Belt Pulley..... | 72 thru 74 |
| Independent Power Take-Off..... | 75 thru 78 |
| Constant Hydraulic Control Operation..... | 79 thru 90 |
| Rear Wheel Tread Spacings..... | 91 thru 103 |
| Front Wheel Tread Spacings..... | 104 thru 109 |
| Fuels and Fuel Storage..... | 110 and 111 |
| Low Cost Fuel Equipped Tractors..... | 112 and 113 |
| Implement Warning Lamp..... | 114 |
| Important Checks During Operation..... | 116 and 117 |
| Service Suggestions | 119 thru 128 |
| Preventive Maintenance | 129 thru 177 |
| Cooling System..... | 131 thru 137 |
| Air Cleaner..... | 139 thru 141 |
| Crankcase Breather..... | 142 |
| Transmission Breather..... | 142 |
| Fuel System..... | 143 thru 145 |
| Starting and Lighting Equipment..... | 146 thru 164 |
| Governor and Engine Speed..... | 165 |
| Steering Gear..... | 165 |
| Transmission..... | 165 |
| Valve Tappet Clearance..... | 166 and 167 |
| Traction Clutch Adjustment..... | 168 thru 170 |
| Differential Brake..... | 171 |
| Adjusting Power Take-off Clutch..... | 172 |
| Repacking and Adjusting Front Wheel Bearing..... | 173 thru 175 |
| Tractor Storage..... | 176 and 177 |
| LP Gas Equipment | 179 thru 193 |

INTRODUCTION



The Case 700 Series Tractor is powered by a rugged four cylinder spark ignition engine which features heavy duty precision type construction, usually found only in diesel engines. This engine is noted for its quiet operating characteristics and economy of operation.

Advanced engineering also includes the following outstanding features on the 700 Series Tractors.

***Dual-Range* Transmission**

The Case Dual-Range transmission, 8 speeds forward and 2 reverse, provides a working speed for every job on the farm in any type or condition of soil. The high speed (8th) road gear brings your fields closer to the farm yard in terms of non-productive time spent on the road.

“Comforized” Platform

The “Deluxe Seat,” easily accessible operating controls, well lighted “Tell-Easy” instrument panel; all features designed with the operator’s comfort in mind are standard equipment on Case 700 Series Tractors.

Wide Range of Easily Adjustable Wheel Spacings

Both front and rear wheel treads can be adjusted on 700 Series Tractors for the various row spacings in a matter of minutes. One man can easily move the tire and rim to any of the tread positions.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com