

**MX100, MX110, MX120
and MX135 Tractors**

Operators Manual

Don 9-78374





THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

M171B

Safety Decals on this machine use the words **Danger, Warning or Caution**, which are defined as follows:

- **DANGER:** Indicates an immediate hazardous situation which, if not avoided, will result in death or serious injury. The color associated with Danger is RED.
- **WARNING:** Indicates a potentially hazardous situation which, if not avoided could result in serious injury. The color associated with Warning is ORANGE.
- **CAUTION:** Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices. The color associated with Caution is YELLOW.



WARNING

IMPROPER OPERATION OF THIS MACHINE CAN CAUSE INJURY OR DEATH. BEFORE USING THIS MACHINE, MAKE CERTAIN THAT EVERY OPERATOR:

- Is instructed in safe and proper use of the machine.
- Reads and understands the Manual(s) pertaining to the machine.
- Reads and understands ALL Safety Decals on the machine.
- Clears the area of other persons.
- Learns and practices safe use of machine controls in a safe, clear area before operating this machine on a job site

It is your responsibility to observe pertinent laws and regulations and follow Case Corporation instructions on machine operation and maintenance.

CASE TECHNICAL MANUALS

Manuals are available from your Dealer for the operation, service and repair of your machine. For prompt convenient service, contact your Dealer for assistance in obtaining the manuals for your machine.

Your Dealer can expedite your order for operators manuals, parts catalogs, service manuals and maintenance records.

Always give the Machine Name, Model and P.I.N. (product identification number) or S.N. (serial number) of your machine so your Dealer can provide the correct manuals for your machine.

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds. **Wash hands after handling.**

NOTE: CNH America LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

GENERAL TABLE OF CONTENTS

TO THE OWNER	1
IDENTIFICATION NUMBERS/MACHINE COMPONENTS	5
SAFETY/DECALS	9
SAFETY RULES	9
SAFETY DECALS	12
INSTRUMENTS/CONTROLS	18
SEAT BELT	26
STEERING COLUMN ADJUSTMENT	27
OPERATING INSTRUCTIONS	56
RUN IN PROCEDURE	57
SERVICE INDICATOR LAMPS AND GAUGES	58
COLD TEMPERATURE OPERATION	62
CAB ENVIRONMENT	78
IMPLEMENT DRAWBAR DIMENSIONS	88
AUXILIARY ELECTRICAL POWER SOCKETS	89
WARNING LAMPS AND SLOW MOVING VEHICLE (SMV) SYMBOL	92
FIELD OPERATION	98
TIRES/WHEELS/SPACING/BALLAST	171
LUBRICATION/MAINTENANCE	218
ENVIRONMENT	218
PLASTIC AND RESIN PARTS	218
TOOL BOX (If Equipped)	218
10 HOURS OR DAILY	225
50 HOUR MAINTENANCE	228
100 HOUR MAINTENANCE	234
300 HOUR MAINTENANCE	238
600 HOUR MAINTENANCE	247
1200 HOUR MAINTENANCE	252
2400 HOUR MAINTENANCE	267
GENERAL MAINTENANCE	271
ELECTRICAL SYSTEM	275

TRIM THIS EDGE

I

TRIM THIS EDGE

RIGHT PAGE

MACHINE STORAGE	294
SPECIFICATIONS	296
ELECTRICAL SYSTEM	298
APPROXIMATE TRACTOR WEIGHTS	326
MAXIMUM PERMITTED OPERATING WEIGHTS	327
DETAIL INDEX	328

TRIM THIS EDGE

II

TRIM THIS EDGE

LEFT PAGE

TO THE OWNER

Use this manual as your guide. Read this manual before you start the engine or operate this machine. Refer to the Detail Index at the end of this manual for locating specific items about your machine. If you follow the instructions given in this manual, your Tractor will work well for many years.

NOTE: *Some information, illustrations and photographs in this manual may differ to the standard equipment and accessories on your tractor. See your dealer for further information.*

Your Dealer can give you assistance with Case made parts and persons with special training that know the best methods of repair and maintenance for your tractor.

Call your Dealer if you need any assistance or information.

Tractor with Mechanical Front Drive (MFD)



RD97B156

NOTE: *The right and left of the tractor in this manual are the same as your right and left when sitting in the tractor seat looking forward.*

TRIM THIS EDGE

ROPS Tractor with Mechanical Front Drive (MFD)



RD97B157

Tractor with Foldable ROPS



RD98A130

MX Special with Fixed ROPS

TRIM THIS EDGE

High Clearance (Vegetable Special) Tractor



RD97B158

TRIM THIS EDGE

LEFT PAGE

Tractor with Two Wheel Drive



RD97B159

TRIM THIS EDGE

How To Use This Manual

Read this manual before you start the engine or operate your Tractor. If you need any more information, see your dealer.

This manual contains important information about the safe operation, adjustment and maintenance of your Case Tractor. To help you find information easily this manual has been separated into chapters, as shown in the General Table of Contents. The operation of the Tractor has been separated into four main chapters:

1. INSTRUMENTS/CONTROLS - Showing the location and a description of all controls.
2. OPERATING INSTRUCTIONS - General information for every day Tractor operation, e.g. Starting and stopping the Tractor, operating the transmission etc.
3. FIELD OPERATION - Information for various operations specifically for use in the field, e.g. Operation of the 3 point hitch, rear PTO etc.
4. TIRES/WHEELS/SPACING/BALLAST - Adjustments for various Tractor operating applications, e.g. Tire pressures, tread widths etc.

The maintenance of the tractor has been separated into two main chapters:

1. LUBRICATION/MAINTENANCE - Service interval hours, and adjustments.
2. ELECTRICAL SYSTEM - General electrical service information.

TRIM THIS EDGE

RIGHT PAGE

TO THE OWNER

IMPORTANT: Refer to the Detail Index at the end of this manual for locating specific items about your machine.

DO NOT operate or permit anyone to operate or service this machine until you or the other persons have read this manual. Use only trained operators who have demonstrated the ability to operate and service this machine correctly and safely.

This Tractor, with standard equipment and authorized attachments, is intended to be used for farming and related operations.

DO NOT use this machine for any application or purpose other than those described in this manual. Consult an authorized dealer or the Case Corporation on changes, additions or modifications that can be required for this machine to comply with various country regulations and safety requirements. Unauthorized modifications could cause serious injury or death. Anyone making such unauthorized modifications is responsible for the consequences.

Manual Storage

Keep the Operators Manual stored in the manual compartment equipped on this machine. Make sure this manual is complete and in good condition. Contact your dealer to obtain additional manuals, for any further information or assistance about your machine. Your dealer has technicians with special training that know the best methods of repair and maintenance for your tractor.



DP96E064

IMPORTANT: This Operators Manual is part of your Tractor. If the Tractor is sold, loaned or rented, the Operators Manual **MUST** go with it.

TRIM THIS EDGE

TRIM THIS EDGE

LEFT PAGE

Buy Now



Our support email:

ebooklibonline@outlook.com