CATERPILLAR®

Service Repair Manual

Models

336F L XE 336F LN XE Excavator Model: 336F L XE EXCAVATOR DFY

Configuration: 336F L XE & 336F LN XE Excavators DFY00001-UP (MACHINE) POWERED BY C9.3 Engine

Disassembly and Assembly

C9.3 Engines for Caterpillar Built Machines

Media Number -UENR0130-06

Publication Date -01/08/2015

Date Updated -22/05/2017

i05296500

Rocker Arm - Assemble

SMCS - 1123-016

Assembly Procedure

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

1. Lubricate all components of the rocker arm shaft with clean engine oil.




Illustration 1 g01947678

2. Install exhaust rocker arm (3) and inlet rocker arm (4) on rocker shaft (1).

3. Install plug (2) into rocker shaft (1). Install plug (2) to a depth of 1.25 ± 0.25 mm $(0.049 \pm 0.010$ inch).

End By:

a. Install the rocker arm and shaft.

<u>Copyright 1993 - 2020 Caterpillar Inc.</u> <u>All Rights Reserved.</u>

Private Network For SIS Licensees.

Thu Jun 18 22:15:41 UTC+0800 2020

Model: 336F L XE EXCAVATOR DFY

Configuration: 336F L XE & 336F LN XE Excavators DFY00001-UP (MACHINE) POWERED BY C9.3 Engine

Disassembly and Assembly

C9.3 Engines for Caterpillar Built Machines

Media Number -UENR0130-06

Publication Date -01/08/2015

Date Updated -22/05/2017

i06019448

Cylinder Head - Remove

SMCS - 1100-011

Removal Procedure

Start By:

- A. Remove the exhaust manifold.
- B. Remove the fan drive mounting group.
- C. Remove the fuel rail and the fuel manifold.
- D. Remove the fuel filter base.
- E. Remove the inlet manifold.
- F. Remove the rocker arm and shaft.
- G. Remove the unit injectors.

NOTICE

Keep all parts clean from contaminants.

Contaminants may cause rapid wear and shortened component life.

NOTICE

Care must be taken to ensure that fluids are contained during performance of inspection, maintenance, testing, adjusting, and repair of the product. Be prepared to collect the fluid with suitable containers before opening any compartment or disassembling any component containing fluids. Refer to Special Publication, NENG2500, "Dealer Service Tool Catalog" for tools and supplies suitable to collect and contain fluids on Cat products.

g01361659

Dispose of all fluids according to local regulations and mandates.





Illustration 1

1. Remove tube assembly (1).



Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com