

Parts Manual



See "General Information"
for New Parts Manual
Features.

420E Backhoe Loader Single Tilt, Center Pivot

HLS1-Up (Machine)
THP1-Up (Machine)
CRS1-Up (Engine)
CRX1-Up (Engine)

Powered By 3054C Engine

This Parts Manual is also available in .PDF Format on Compact Disc
*(CD-ROM) - Caterpillar Form No. SERP3703-00.

TABLE OF CONTENTS

Name	Page	Name	Page
GENERAL INFORMATION	A23	RADIATOR & OIL COOLER GP	52
REPAIR ALTERNATIVES	A42	TANK GP-EXPANSION	54
SUPPLEMENTAL COOLANT ADDITIVES	A47	AIR INLET AND EXHAUST SYSTEM	55
MAINTENANCE PARTS	A52	AIR CLEANER GP	55
INDEX	A65	INDICATOR GP-AIR FILTER CHANGE	57
MACHINE ARRANGEMENT	1	MUFFLER GP	58
BACKHOE AR-EXTENDABLE STICK	1	TURBOCHARGER GP	59
BACKHOE AR-STANDARD STICK	3	FUEL SYSTEM	61
CHASSIS AR	4	CONTROL GP-GOVERNOR	61
COMMON AR	4	LINES GP-FUEL	62
ENGINE ARRANGEMENT	5	LINES GP-FUEL FILTER	64
ENGINE AR	5	PUMP GP-FUEL INJECTION	65
BASIC ENGINE	7	PUMP GP-FUEL PRM & PRIM FILTER	68
CAMSHAFT GP	7	TANK & MTG GP-FUEL	70
COVER GP-CYLINDER HEAD	8	TANK GP-FUEL	71
COVER GP-VALVE MECHANISM	9	ELECTRICAL AND STARTING SYSTEM	73
CRANKSHAFT GP	11	ALTERNATOR GP-CHARGING	73
CYLINDER BLOCK GP	13	BATTERY & WIRING GP	74
CYLINDER HEAD GP	16	CONTROL GP-COMMUNICATION	78
DRIVE GP-FAN	18	ELECTRONICS GP-MACHINE	79
FLYWHEEL GP	19	ELECTRONICS GP-MONITOR	80
HOUSING GP-FLYWHEEL	20	GLOW PLUG GP	81
HOUSING GP-FRONT	21	HEATER GP-JACKET WATER	82
LIFTING GP-ENGINE	23	INSTALLATION GP-	
MOUNTING GP-ENGINE	24	COMMUNICATION	83
MOUNTING GP-ENGINE & TMSN	25	INSTALLATION GP-GRADE	
PAN GP-OIL	26	CONTROL	87
PISTON & ROD GP	28	LAMP GP-FLOOD	91
PLUG GP-ENGINE	30	LAMP GP-WARNING BEACON	93
PULLEY GP-CRANKSHAFT	33	LIGHTING GP-FLOOD & SIGNAL	94
VALVE MECHANISM GP	34	LIGHTING GP-WARNING BEACON	96
LUBRICATION SYSTEM	35	MOUNTING GP-MAST	97
BREATHER GP	35	MOUNTING GP-SENSOR	98
GAUGE GP-OIL LEVEL & FILLER	37	RELAY GP	99
PUMP GP-ENGINE OIL	38	SENSOR GP-SPEED	102
COOLING SYSTEM	39	STARTING MOTOR GP-ELECTRIC	103
CONNECTION GP-WATER	39	SWITCH GP-ALL WHEEL DRIVE	106
COOLER GP-ENGINE OIL	40	SWITCH GP-DIFFERENTIAL LOCK	107
COOLER GP-FLTR BASE & ENG OIL	41	SWITCH GP-PRESSURE	108
COOLING AR	43	WIRING GP-AIR CONDITIONER	109
FAN GP-SUCTION	44	WIRING GP-CONSOLE	112
LINES GP-TRANSMISSION COOLER	46	WIRING GP-CONTROL	116
MOUNTING GP-RAD & OIL COOLER	48	WIRING GP-ENGINE	119
PUMP GP-WATER	50	WIRING GP-EXTENDABLE STICK	122
		WIRING GP-HEATER	123
		WIRING GP-KICKOUT & POSITIONER	125
		WIRING GP-PLATFORM	127
		WIRING GP-REAR	132
		WIRING GP-RIDE CONTROL	134
		WIRING GP-TRANSMISSION	
		CONTROL	136

TABLE OF CONTENTS

Name	Page	Name	Page
POWER TRAIN	138	FRAME GP-LOADER	238
AXLE GP-DRIVE & STEERING	138	FRAME GP-SWING	239
AXLE GP-REAR	140	GUARD GP-DRIVE SHAFT	241
CASE AS-TRANSMISSION	143	GUARD GP-RADIATOR	242
CONTROL GP-TRANSMISSION	146	HOOD & GUARD GP	243
DIFFERENTIAL & BEVEL GEAR GP	148	HOOD GP-ENGINE	245
DIFFERENTIAL GP	150		
DRIVE AR-BACKHOE LOADER	152	HYDRAULIC SYSTEM	247
DRIVE GP-FLEXIBLE COUPLING	153	ACCUMULATOR GP-PILOT OIL	247
FILLER GP-POWER TRAIN OIL	154	ACCUMULATOR GP-RIDE CONTROL	248
FLANGE GP-WHEEL	158	CONTROL AR-RIDE	249
HOUSING & FLANGE GP-AXLE	159	CONTROL GP-HYDRAULIC HAND	250
HOUSING GP-AXLE	161	CONTROL GP-JOYSTICK	255
LINES GP-POWER TRAIN OIL	165	CYLINDER & LINES GP-THUMB	259
MOUNTING GP-AXLE	166	CYLINDER GP-BACKHOE BUCKET	260
MOUNTING GP-TRANSMISSION	167	CYLINDER GP-BOOM	264
PLANETARY GP-FINAL DRIVE	169	CYLINDER GP-EXTENDABLE STICK	267
POWER TRAIN AR	171	CYLINDER GP-LIFT	269
SHAFT GP-COUNTER	172	CYLINDER GP-MULTIPURPOSE	
SHAFT GP-DRIVE	174	BUKT	270
SHAFT GP-IDLER	175	CYLINDER GP-STABILIZER	271
SHAFT GP-INPUT	177	CYLINDER GP-STICK	275
SHAFT GP-OUTPUT	181	CYLINDER GP-SWING	279
TRANSMISSION & MOUNTING GP	187	CYLINDER GP-THUMB	281
TRANSMISSION AR-DIRECT DRIVE	188	CYLINDER GP-TILT	282
TRANSMISSION AR-POWER SHIFT	188	DRIVE & MTG GP-PUMP	284
TRANSMISSION GP-DIRECT DRIVE	189	FASTENER GP-VALVE	285
TRANSMISSION GP-POWER SHIFT	194	FILTER GP-OIL	286
VALVE & LINES GP-SOLENOID	200	FITTING GP-HYDRAULIC	287
VALVE & MTG GP-SOLENOID	202	HYDRAULIC AR	288
VALVE GP-RELIEF	203	KICKOUT & POSITIONER GP	289
VALVE GP-TIRE	204	KIT-RIDE CONTROL	291
WHEEL & TIRE AR	205	LINES GP-BACKHOE AUXILIARY	294
WHEEL & TIRE GP	206	LINES GP-BOOM	301
		LINES GP-BUCKET	303
BRAKING SYSTEM	213	LINES GP-DRAIN	308
CONTROL GP-PARKING BRAKE	213	LINES GP-EXTENDABLE STICK	309
CONTROL GP-SERVICE BRAKE	215	LINES GP-HYDRAULIC OIL COOLER	311
CYLINDER GP-BRAKE	218	LINES GP-LIFT CYLINDER	313
LEVER GP-HAND CONTROL	220	LINES GP-LOADER AUXILIARY	315
		LINES GP-MULTIPURPOSE BUCKET	317
STEERING SYSTEM	221	LINES GP-PILOT	321
CONTROL GP-STEERING	221	LINES GP-PUMP	327
KNOB GP-STEERING	223	LINES GP-RIDE CONTROL	329
LINES GP-STEERING	224	LINES GP-STABILIZER	331
PUMP GP-METERING	226	LINES GP-STICK	337
		LINES GP-SWING	338
FRAME AND BODY	227	LINES GP-TILT CYLINDER	340
BOX GP-BATTERY	227	MANIFOLD GP-CONTROL	342
COUNTERWEIGHT GP	228	MANIFOLD GP-CONTROL &	
DOOR GP-BATTERY	231	SOLENOID	346
EXTENSION GP-FENDER	232	MOUNTING GP-BACKHOE CONTROL	348
FENDER GP-FRONT	233	MOUNTING GP-BANK VALVE	350
FENDER GP-REAR	234	MOUNTING GP-CYLINDER	351
FLOORPLATE GP	236	MOUNTING GP-LINES	354

TABLE OF CONTENTS

Name	Page	Name	Page
PUMP GP-PISTON	356	THUMB GP	552
ROTATING GP-PUMP	358	TOOTH GP-UNI	554
SHAFT GP-PUMP DRIVE	359		
TANK & MTG GP-HYDRAULIC	360	OPERATOR STATION	555
VALVE & LINES GP-PILOT	362	AIR CONDITIONER & MOUNTING GP	555
VALVE AR-BANK 2	364	AIR CONDITIONER GP	557
VALVE AR-BANK 3	364	BRACKET GP-MOUNTING	559
VALVE AR-BANK 6	364	CAB AR	560
VALVE AR-BANK 7	365	CAB GP	563
VALVE AR-BANK 8	365	CANOPY AR	566
VALVE GP-BANK 2	366	CANOPY GP-OPEN ROPS	568
VALVE GP-BANK 3	367	COMPARTMENT GP-LITERATURE	571
VALVE GP-BANK 6	368	COMPRESSOR & MTG GP-REFRIG	572
VALVE GP-BANK 7	369	COMPRESSOR GP-REFRIGERANT	573
VALVE GP-BANK 8	370	CONDENSER & MTG GP-	
VALVE GP-CONTROL	372	REFRIGERANT	574
VALVE GP-PILOT	386	CONSOLE GP-OPERATOR	575
VALVE GP-PUMP CONTROL	388	COVER GP-WIPER MOTOR	581
VALVE GP-SOLENOID	389	DOOR GP-CAB	582
		FLOOR MAT GP	586
IMPLEMENTS	391	HEATER GP-CAB	587
ARM GP-LIFT	391	INSTALLATION GP-MONITOR	591
BOOM GP	393	LATCH GP-CONSOLE	593
BRACE GP-LIFT CYLINDER	394	LEVER GP-GOVERNOR	594
GUARD GP-BOOM	395	LINER GP-CAB	595
LINK GP-THUMB	396	LINES GP-HEATER	597
LINKAGE GP-BACKHOE BUCKET	397	LINES GP-HEATER & AIR COND	598
LINKAGE GP-LOADER BUCKET	399	MIRROR GP-REAR VIEW	600
LOADER AR	401	MOTOR GP-WINDOW WIPER	602
LOCK GP-TRANSPORT	402	MOUNTING GP-CAB	603
MOUNTING GP-STICK	406	MOUNTING GP-MONITOR	604
PAD & GUARD GP-STABILIZER	407	PEDAL GP-GOVERNOR	605
PAD & MTG GP-STABILIZER	413	ROOF GP-CAB	606
PAD GP-STABILIZER	416	SEAT BELT GP	607
STABILIZER GP-BACKHOE	418	SEAT GP	609
STICK GP-EXTENDABLE	419	SEAT GP-SUSPENSION	614
STICK GP-HOE	423	SUSPENSION GP-SEAT	619
		TACHOMETER GP-ELECTRIC	624
WORK TOOLS	425	TRIM GP-CAB	625
BOWL AS-BUCKET	425	VISOR GP-CAB	627
BUCKET AR-MULTIPURPOSE	427	WASHER GP-WINDOW	628
BUCKET AS-GENERAL PURPOSE	430	WINDOW GP-CAB	630
BUCKET AS-HOE	440	WINDOW GP-DOOR	636
BUCKET GP-GENERAL PURPOSE	444	WIPER & WASHER GP-WINDOW	640
BUCKET GP-HOE	451	WIPER GP-WINDOW	642
BUCKET GP-MULTIPURPOSE	495		
BULLDOZER AS	502	SERVICE EQUIPMENT AND SUPPLIES	643
COUPLER AR-QUICK	506	BRACKET GP-TRANSPORT	643
COUPLER GP-QUICK	507	FILM GP	644
EDGE GP-CUTTING	512	LINK GP-SHIPPING	645
FORK GP	514	LOCK GP-VANDALISM	645
GUARD GP-WORK TOOL	515	PLATE & FILM GP	645
MOUNTING GP-BUCKET	516	PROTECTION GP-VANDALISM	649
PIN GP-COUPLER	517	SHIPPING AR-BUCKET	650
THUMB AR	519		

TABLE OF CONTENTS

Name	Page	Name	Page
PART NUMBER INDEX	B1		

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com