

**JOHN DEERE**  
**AG & TURF DIVISION**

**Utility Cart  
10P**

**OMM166620 L2**

**OPERATOR'S MANUAL**



**JOHN DEERE**

**Original Instruction**

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

**COPYRIGHT© 2013**

**Deere & Co.**

**John Deere Worldwide Commercial and  
Consumer Equipment Division**

**All rights reserved**

**Previous Editions**

**COPYRIGHT©**

# PRODUCT IDENTIFICATION

---

## Table of Contents

Product Identification.....	1
Safety Labels.....	2
Safety .....	3
Assembly.....	4
Installing .....	8
Removing .....	8
Operating.....	8
Service .....	9
Specifications .....	9
Getting Quality Service .....	9

---

## Product Identification

### Product Compatibility

This utility cart is designed for use with lawn tractors and lawn and garden tractors.

### Record Purchase Information

Record your purchase information in the spaces provided below.

DATE OF PURCHASE:

---

DEALER NAME:

---


DEALER PHONE:

---

# SAFETY LABELS

## Safety Labels

### Safety Label Location



MX47772, MX17871a, B7084B, DMU211840

**Picture Note:** Cart without front pocket shown. Use label number listed in table below to locate complete text of safety label message following this illustration. No-text labels are required for certain regions of the world. Your cart may not be equipped with all these labels.

- 1 - WARNING (B7084B)
- 2 - CAUTION (MX17871a)
- 3 - WARNING (DMU211480)



### Understanding The Machine Safety Labels

The machine safety labels shown in this section are placed in important areas on your machine to draw attention to potential safety hazards.

On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards.

The operator's manual also explains any potential safety hazards whenever necessary in special safety messages that are identified with the word, CAUTION, and the safety-alert symbol.

### CAUTION




MX17871a

TO HELP PREVENT BODILY INJURY DUE TO LOSS OF STABILITY OR CONTROL

- Do not exceed maximum towing capacity of towing vehicle listed in the vehicle operator's manual.
- Do not exceed maximum cart load capacity listed in cart operator's manual.
- Reduce loaded cart weight on slopes and/or slippery surfaces.
- Do not exceed 8 mph (13 kph) when towing cart.

### Warning - DMU211480



DMU211480

This operator's manual contains important information necessary for safe machine operation. Observe all safety rules to avoid accidents.

### WARNING

# SAFETY



B7084B

## AVOID INJURY FROM EXPLOSION

- Do not place gas container in cart when filling

## RIDERS CAN FALL OFF AND BE KILLED

- No riders in cart

## Safety

### Read Safety in Machine Operator's Manual

Read the general safety operating precautions in your machine operator's manual for additional safety information.

### Operate Safely

- This attachment is intended for use in lawn care and home applications. Do not tow behind a vehicle on a highway or in any high speed application. Do not tow at speeds higher than maximum recommended towing speed.
- Towing speed should always be slow enough to maintain control. Travel slowly over rough ground.
- Do not let children or an untrained person operate machine.
- Do not let anyone, especially children, ride on machine or attachment. Riders are subject to injury such as being struck by foreign objects and being thrown off. Riders may also obstruct the operator's view, resulting in the machine being operated in an unsafe manner.
- Check machine brake action before you operate. Adjust or service brakes as necessary.
- Keep all nuts and bolts tight to be sure the equipment is in safe working condition.
- Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Replace all worn or damaged safety and instruction decals.
- Do not modify machine or safety devices. Unauthorized modifications to the machine or attachment may impair its function and safety.
- Securely anchor all loads to prevent loads from falling.
- Distribute load evenly for safe travel and unloading of cart.
- Do not obstruct the operator's view during use.

### Towing Loads Safely

- Stopping distance increases with speed and weight of towed load. Travel slowly and allow extra time and distance to stop.
- Total towed weight must not exceed limits specified in towing vehicle operator's manual.
- Excessive towed load can cause loss of traction and loss of control on slopes. Reduce towed weight when operating on slopes.
- Never allow children or others in or on towed equipment.
- Use only approved hitches. Tow only with a machine that has a hitch designed for towing. Do not attach towed equipment except at the approved hitch point.
- Follow the manufacturer's recommendations for weight limits for towed equipment and towing on slopes. Use counterweights or wheel weights as described in the machine operator's manual.
- Do not turn sharply. Use additional caution when turning or operating under adverse surface conditions. Use care when reversing.
- Do not shift to neutral and coast downhill.

### Protect Bystanders

- Keep bystanders away when you operate a towed attachment.
- Before you back machine and attachment, look carefully behind attachment for bystanders.

### Keep Riders Off Towed Attachment

# ASSEMBLY

- Keep riders off of a towed attachment.
- Riders on a towed attachment are subject to injury, such as being struck by objects and being thrown off the attachment during sudden starts, stops and turns.
- Riders obstruct the operator's view, resulting in the attachment being used in an unsafe manner.
- Keep riders off of hitch bracket.

## Avoid Injury From Drawbar

Before you disconnect an attachment from machine hitch plate:


- Unload attachment.
- Stop attachment on level ground.

- Stop machine engine.
- Lock machine park brake.
- Block attachment wheels.
- Make sure hands, feet or other body parts are not under drawbar.

## Assembly

### Parts in Kit

### Parts in Kit (Main)



MX52114

Qty.	Description
1	Cart (A)
1	Lock Bracket (B)
1	Axle Support (C)
1	Axle (D)
2	Wheel (E)
1	Drawbar (F)
1	Clevis (G)
1	Foot Pedal (If Equipped) (H)
1	Lock Bar (If Equipped) (I)

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)