

T300


TURBO



Bobcat®

Parts Manual

S/N 5219 11001 & Above
S/N 5220 11001 & Above
S/N 5254 11001 & Above
S/N 5255 11001 & Above



An  **Ingersoll-Rand** business

Printed in U.S.A.

6902226 (8-03) Revised (2-04)

© Bobcat Company 2004

T300 CONTENTS

MAIN FRAME	11-46
MAINTENANCE ITEMS	11-12
SERVICE SCHEDULE ITEMS	13-18
MAIN FRAME	19-20
OPERATOR CAB	21-26
SEAT & SEAT BAR	27-28
SEAT	29-32
REAR DOOR	33-34
LIFT ARMS & BOBTACH	35-36
BOB-TACH	37-38
PANELS	39-42
FUEL SYSTEM	43-46
DRIVE TRAIN	47-56
DRIVE TRAIN	47-48
TRACK TENSIONER	49-50
FRONT IDLER	51-52
REAR IDLER	53-54
TRACK ROLLER	55-56
HYDRAULIC SYSTEM	57-92
HYDRAULIC CIRCUITRY	57-58
LIFT & TILT CONTROL CIRCUITRY	59-60
AUXILIARY HYDRAULICS	61-62
TILT CYLINDER	63-64
LIFT CYLINDER	65-68
MANUAL LIFT RELEASE VALVE	69-70
CONTROL PEDALS	71-72
HYDRAULIC CONTROL VALVE (SPOOL LOCK)(W/BICS CONTROL VALVE)	73-80
BICS CONTROL VALVE	81-82
HYDRAULIC CONTROL VALVE (ADVANCED HAND CONTROL SYSTEM)	83-86
* HYDRAULIC CONTROL VALVE (JOYSTICK CONTROL SYSTEM)	87-90
BUCKET POSITIONING VALVE	91-92
HIGH HORSEPOWER HYDRAULICS	93-100
HIGH HORSEPOWER HYDRAULICS	93-100
HYDROSTATIC SYSTEM	101-142
HYDROSTATIC CIRCUITRY	101-106
HAND CONTROLS	107-108
HYDROSTATIC MOTOR & BRAKE	109-116
HYDROSTATIC PUMP	117-132
GEAR PUMP	133-136
HYDROSTATIC OIL FILTER	137-140
BRAKE VALVE	141-142
ELECTRICAL SYSTEM	143-164
CAB ELECTRICAL CIRCUITRY	143-144
* ENGINE ELECTRICAL	145-148
* CONTROLS ELECTRICAL	149-160
ALTERNATOR	161-162
STARTER	163-164
POWER UNIT	165-258
COOLING SYSTEM	165-170
ENGINE & ATTACHING PARTS	171-180
THROTTLE	181-186
COOLING FAN DRIVE ASSY.	187-188
ENGINE (V3300 DI T KUBOTA)	189-190
MANIFOLDS (V3300 DI T KUBOTA)	119-192

T300 CONTENTS (Cont'd)

POWER UNIT (CONT'D)	165-258
TURBOCHARGER (V3300 DI T KUBOTA)	193-194
CYLINDER HEAD & COVER (V3300 DI T KUBOTA)	195-196
CYLINDER HEAD (V3300 DI T KUBOTA)	197-198
OIL PAN (V3300 DI T KUBOTA)	199-200
PISTON & CRANKSHAFT (V3300 DI T KUBOTA)	201-202
CAMSHAFT (V3300 DI T KUBOTA)	203-204
FRONT COVER (V3300 DI T KUBOTA)	205-206
WATER PUMP & THERMOSTAT (V3300 DI T KUBOTA)	207-208
WATER PUMP (V3300 DI T KUBOTA)	209-210
FUEL INJECTION SYSTEM (V3300 DI T KUBOTA)	211-214
FUEL INJECTION PUMP (V3300 DI T KUBOTA)	215-216
GOVERNOR (V3300 DI T KUBOTA)	217-220
AIR CLEANER (V3300 DI T KUBOTA)	221-222
* ENGINE (V3300 DI T KUBOTA) (TIER II)	223-224
* MANIFOLDS (V3300 DI T KUBOTA) (TIER II)	225-226
* TURBOCHARGER (V3300 DI T KUBOTA) (TIER II)	227-228
* CYLINDER HEAD & COVER (V3300 DI T KUBOTA) (TIER II)	229-230
* CYLINDER HEAD (V3300 DI T KUBOTA) (TIER II)	231-232
* OIL PAN (V3300 DI T KUBOTA) (TIER II)	233-234
* PISTON & CRANKSHAFT (V3300 DI T KUBOTA) (TIER II)	235-236
* CAMSHAFT (V3300 DI T KUBOTA) (TIER II)	237-238
* FRONT COVER (V3300 DI T KUBOTA) (TIER II)	239-240
* WATER PUMP & THERMOSTAT (V3300 DI T KUBOTA) (TIER II)	241-242
* WATER PUMP (V3300 DI T KUBOTA) (TIER II)	243-244
* FUEL INJECTION SYSTEM (V3300 DI T KUBOTA) (TIER II)	245-248
* FUEL INJECTION PUMP (V3300 DI T KUBOTA) (TIER II)	249-250
* GOVERNOR (V3300 DI T KUBOTA) (TIER II)	251-256
* AIR CLEANER (V3300 DI T KUBOTA) (TIER II)	257-258
ACCESSORIES & OPTIONS	262-291
ACS CONVERSION KIT	262-263
BACK-UP ALARM KIT	264-267
BEACON	268-269
BLOCK HEATER	270-271
BUCKET POSITIONING KIT	272-273
CAB DOOR	274-283
CAB ENCLOSURE	284-287
CAB WINDOWS	288-291
* DEBRIS SHIELD KIT	292-293
DECALS	294-297
ELECTRICAL CONNECTOR KIT	298-299
ELECTRICAL CONTROLS KIT	300-303
* EUROPEAN ACCESSORIES	304-307
FIRE EXTINGUISHER	308-309
FLASHER LIGHTS	310-311
F.O.P.S. KIT	312-313
FRONT AUXILIARY	314-317
* GAS SPRING KIT	318-319
HEATER & A/C	320-337
HORN KIT	338-341
LIFT KIT	342-345
LIGHT KIT	346-347
* NOISE REDUCTION KIT	348-349
POWER BOB-TACH KIT	350-355
POWER BOB-TACH CYLINDER	356-357

T300 CONTENTS (Cont'd)

ACCESSORIES & OPTIONS (CONT'D)	262-291
POWER BOB-TACH	358-361
* PURIFIER	362-363
* RADIATOR SCREEN KIT	364-365
REAR AUXILIARY HYDRAULICS	366-369
REAR AUXILIARY VALVE	370-373
REAR DOOR LOCK	374-375
REAR WIPER	376-377
SEAT BELT	378-383
* STEERING DAMPENING KIT	384-385
STROBE LIGHT	386-387
BULK ITEMS	388-391
NUMERICAL INDEX	392-445
NUMERICAL INDEX	392-445

T300 CONTENTS

MAIN FRAME	11-46
MAINTENANCE ITEMS	11-12
SERVICE SCHEDULE ITEMS	13-18
MAIN FRAME	19-20
OPERATOR CAB	21-26
SEAT & SEAT BAR	27-28
SEAT	29-32
REAR DOOR	33-34
LIFT ARMS & BOBTACH	35-36
BOB-TACH	37-38
PANELS	39-42
FUEL SYSTEM	43-46
DRIVE TRAIN	47-56
DRIVE TRAIN	47-48
TRACK TENSIONER	49-50
FRONT IDLER	51-52
REAR IDLER	53-54
TRACK ROLLER	55-56
HYDRAULIC SYSTEM	57-92
HYDRAULIC CIRCUITRY	57-58
LIFT & TILT CONTROL CIRCUITRY	59-60
AUXILIARY HYDRAULICS	61-62
TILT CYLINDER	63-64
LIFT CYLINDER	65-68
MANUAL LIFT RELEASE VALVE	69-70
CONTROL PEDALS	71-72
HYDRAULIC CONTROL VALVE (SPOOL LOCK)(W/BICS CONTROL VALVE)	73-80
BICS CONTROL VALVE	81-82
HYDRAULIC CONTROL VALVE (ADVANCED HAND CONTROL SYSTEM)	83-86
* HYDRAULIC CONTROL VALVE (JOYSTICK CONTROL SYSTEM)	87-90
BUCKET POSITIONING VALVE	91-92
HIGH HORSEPOWER HYDRAULICS	93-100
HIGH HORSEPOWER HYDRAULICS	93-100
HYDROSTATIC SYSTEM	101-142
HYDROSTATIC CIRCUITRY	101-106
HAND CONTROLS	107-108
HYDROSTATIC MOTOR & BRAKE	109-114
HYDROSTATIC PUMP	117-132
GEAR PUMP	133-136
HYDROSTATIC OIL FILTER	137-140
BRAKE VALVE	141-142
ELECTRICAL SYSTEM	143-164
CAB ELECTRICAL CIRCUITRY	143-144
* ENGINE ELECTRICAL	145-148
* CONTROLS ELECTRICAL	149-160
ALTERNATOR	161-162
STARTER	163-164
POWER UNIT	165-258
COOLING SYSTEM	165-170
ENGINE & ATTACHING PARTS	171-180
THROTTLE	181-186
COOLING FAN DRIVE ASSY.	187-188
ENGINE (V3300 DI T KUBOTA)	189-190
MANIFOLDS (V3300 DI T KUBOTA)	119-192

T300 CONTENTS (Cont'd)

POWER UNIT (CONT'D)	165-258
TURBOCHARGER (V3300 DI T KUBOTA)	193-194
CYLINDER HEAD & COVER (V3300 DI T KUBOTA)	195-196
CYLINDER HEAD (V3300 DI T KUBOTA)	197-198
OIL PAN (V3300 DI T KUBOTA)	199-200
PISTON & CRANKSHAFT (V3300 DI T KUBOTA)	201-202
CAMSHAFT (V3300 DI T KUBOTA)	203-204
FRONT COVER (V3300 DI T KUBOTA)	205-206
WATER PUMP & THERMOSTAT (V3300 DI T KUBOTA)	207-208
WATER PUMP (V3300 DI T KUBOTA)	209-210
FUEL INJECTION SYSTEM (V3300 DI T KUBOTA)	211-214
FUEL INJECTION PUMP (V3300 DI T KUBOTA)	215-216
GOVERNOR (V3300 DI T KUBOTA)	217-220
AIR CLEANER (V3300 DI T KUBOTA)	221-222
* ENGINE (V3300 DI T KUBOTA) (TIER II)	223-224
* MANIFOLDS (V3300 DI T KUBOTA) (TIER II)	225-226
* TURBOCHARGER (V3300 DI T KUBOTA) (TIER II)	227-228
* CYLINDER HEAD & COVER (V3300 DI T KUBOTA) (TIER II)	229-230
* CYLINDER HEAD (V3300 DI T KUBOTA) (TIER II)	231-232
* OIL PAN (V3300 DI T KUBOTA) (TIER II)	233-234
* PISTON & CRANKSHAFT (V3300 DI T KUBOTA) (TIER II)	235-236
* CAMSHAFT (V3300 DI T KUBOTA) (TIER II)	237-238
* FRONT COVER (V3300 DI T KUBOTA) (TIER II)	239-240
* WATER PUMP & THERMOSTAT (V3300 DI T KUBOTA) (TIER II)	241-242
* WATER PUMP (V3300 DI T KUBOTA) (TIER II)	243-244
* FUEL INJECTION SYSTEM (V3300 DI T KUBOTA) (TIER II)	245-248
* FUEL INJECTION PUMP (V3300 DI T KUBOTA) (TIER II)	249-250
* GOVERNOR (V3300 DI T KUBOTA) (TIER II)	251-256
* AIR CLEANER (V3300 DI T KUBOTA) (TIER II)	257-258
ACCESSORIES & OPTIONS	262-291
ACS CONVERSION KIT	262-263
BACK-UP ALARM KIT	264-267
BEACON	268-269
BLOCK HEATER	270-271
BUCKET POSITIONING KIT	272-273
CAB DOOR	274-283
CAB ENCLOSURE	284-287
CAB WINDOWS	288-291
* DEBRIS SHIELD KIT	292-293
DECALS	294-297
ELECTRICAL CONNECTOR KIT	298-299
ELECTRICAL CONTROLS KIT	300-303
* EUROPEAN ACCESSORIES	304-307
FIRE EXTINGUISHER	308-309
FLASHER LIGHTS	310-311
F.O.P.S. KIT	312-313
FRONT AUXILIARY	314-317
* GAS SPRING KIT	318-319
HEATER & A/C	320-337
HORN KIT	338-341
LIFT KIT	342-345
LIGHT KIT	346-347
* NOISE REDUCTION KIT	348-349
POWER BOB-TACH KIT	350-355
POWER BOB-TACH CYLINDER	356-357

T300 CONTENTS (Cont'd)

ACCESSORIES & OPTIONS (CONT'D)	262-291
POWER BOB-TACH	358-361
* PURIFIER	362-363
* RADIATOR SCREEN KIT	364-365
REAR AUXILIARY HYDRAULICS	366-369
REAR AUXILIARY VALVE	370-373
REAR DOOR LOCK	374-375
REAR WIPER	376-377
SEAT BELT	378-383
* STEERING DAMPENING KIT	384-385
STROBE LIGHT	386-387
BULK ITEMS	388-391
NUMERICAL INDEX	392-445
NUMERICAL INDEX	392-445

Buy Now



Our support email:

ebooklibonline@outlook.com