




9812/7210 B1-4-1 HYDRAULIC TANK



446280


Item	Part #	Change No	Description	Usage Code	QTY
1	335/13940		Tank WA Hydraulic		1
2	296/10023		Filler Neck WA		1
3	331/32566		Cap filler hydraulic		1

4	123/00295		Breather		1
5	123/08053		Gauge Sight 50mm		1
7	242/00178		Gasket		1
8	1745/0003		Plug Blanking		1
9	32/912500		Strainer suction		1
10	32/904100		Strainer Suction 1" BSP Thread, 46AF Hexagon		1
13	816/90467		Cap Blanking 1/2"BSP Female		2
16	1315/0207Z		Screw M6x25		8
17	1420/0007Z		Washer (M8)		8
19	816/90044		Cap blanking 3/8"BSP Female		1

4	826/10081		Latch Bonnet		1
5	123/04067		Handle Barrel Lock Only		1
6	335/14094		Hinge		1
7	1391/3312D		Capscrew M8 x 50mm		2
8	1370/0203D		Nut Lock M8		2
9	236/05133		Stop rubber,M6		1
10	1420/0006D		Washer (M6)		5
11	1315/0209D		Setscrew M6 x 35mm		2
12	1370/0103D		Nut (M6)		2
13	1370/0101D		Nut Plain M6		1
14	1315/0303D		Setscrew M8 x 16mm		8
15	1420/0007D		Washer (M8)		8
16	831/00141		Bearing liner		4
17	1315/0108D		Screw M5x30		2
18	1420/0005D		Washer (M5)		2
19	1315/0210D		Setscrew M6 x 40mm		1
20	926/17013		Seal Self Adhesive 1800mm long		1
30	332/R3593		Buffer Bonnet Stop		1



9812/7210 B1-5-5 BONNET SOUND PROOF




912520

Item	Part #	Change No	Description	Usage Code	QTY
1	****		'See Remark' <i>SEE B1-5-3</i>		1
2	331/67568		Panel Bonnet, Soundproofing Large		1

3	331/67569		Panel Bonnet Soundproofing Small		1
4	332/R0098		Panel Bonnet Soundproofing		1
5	332/R0100		Panel Bonnet Soundproofing		1
6	332/R0101		Panel Soundproofing		1
7	332/R0220		Stud Fixing		22



9812/7210 B1-5-8 BONNET SURROUND FACIA PANELS




406360

Item	Part #	Change No	Description	Usage Code	QTY
1	331/69017		Panel Front Wrapper Military		1
1	346/90027		Panel Bulkhead Wrapper		1
2	346/90028		Panel Quarter		1
3	331/43138		Bracket Mounting		1
4	331/43137		Bracket Mounting		1
5	331/43135		Plate Hinge Cover <i>NLA REQ FROM JAN 01/01/06</i>		1
6	331/68933		Plate Exhaust Cover Military Green		1
7	1370/0203D		Nut Lock M8		6
8	1412/0002D		Washer (5/16" Large)		81
9	1420/0007D		Washer (M8)		7
10	1315/0308D		Setscrew M8 x 30 mm		6
11	826/11155		Screw Button Head		3



9812/7210 B1-5-10 BONNET BUMP STOP INSTALLATION



917140


Item	Part #	Change No	Description	Usage Code	QTY
1	332/R3156		Plate Stop		1
2	826/11311		Retainer Door - Rubber		1
3	331/36544		Buffer Rubber		1

4	1420/0006D		Washer (M6)		4
5	1412/0003D		Washer (3/8" Large)		4
6	1370/0203D		Nut Lock M8		1
7	1370/0103D		Nut (M6)		4
8	826/01559		Flange Button Head Socket		3
9	826/01560		Screw M6x25		1
10	826/01405		Fastener Button,Fir Tree 7mm Hole		4

4	295/00072		Gasket access plate		1
5	1315/0207Z		Screw M6x25		9
6	1420/0006Z		Washer (M6)		12
7	1315/3220Z		Bolt (M6 x 100)		3
8	716/25500		Ring Sealing		1
9	716/25600		Ring Locking		1
10	704/50130		Sender Fuel		1
10A	:32/925704		Filter gauze fuel strainer		1
11	335/05010		Cover Sender Protection		1
12	826/11324		Nut M6 Bollofff Blind 5.5 to 8mm Plate		12
15	1745/0003		Plug Blanking <i>DIESEL TANK DRAIN PLUG</i>		1



9812/7210 B1-7-1 SOUNDPROOFING COOLING PACK



728020

Item	Part #	Change No	Description	Usage Code	QTY
1	331/48341		Panel Soundproofing Radiator Bottom		1
2	331/48339		Panel Soundproofing Radiator LH Side		1
3	331/48430		Shim t=1.2mm		1

4	331/45491		Panel soundproofing radiator top quilt		1
5	331/45492		Panel soundproofing radiator top Bituman		1
6	826/01405		Fastener Button,Fir Tree 7mm Hole		10
7	1412/0001D		Washer (1/4" Large)		14

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com