

2050M
Tier 2
Crawler Dozer

*PIN NCDC25000 and above; PIN NDDC25000 and above;
PIN NEDC20000 and above; PIN NFDC20000 and above*

SERVICE MANUAL

Part number 47907873

2nd edition English

October 2015

Replaces part number 47645620





SERVICE MANUAL

2050M Bulldozer (BD) Blade, Extra Long Track (XLT) - Non-regulated [NCDC25000 -] , 2050M Bulldozer (BD) Blade, Extra Long Track (XLT) - Non-regulated [NDDC25000 -] , 2050M Bulldozer (BD) Blade, Extra Long Track (XLT) - Non-regulated [NEDC20000 -] , 2050M Bulldozer (BD) Blade, Extra Long Track (XLT) - Non-regulated [NFDC20000 -] , 2050M Bulldozer (BD) Blade, Long Track (LT) - Non-regulated [NCDC25000 -] , 2050M Bulldozer (BD) Blade, Long Track (LT) - Non-regulated [NDDC25000 -] , 2050M Bulldozer (BD) Blade, Long Track (LT) - Non-regulated [NEDC20000 -] , 2050M Bulldozer (BD) Blade, Long Track (LT) - Non-regulated [NFDC20000 -] , 2050M Bulldozer (BD) Blade, Low Ground Pressure (LGP) - Non-regulated [NCDC25000 -] , 2050M Bulldozer (BD) Blade, Low Ground Pressure (LGP) - Non-regulated [NDDC25000 -] , 2050M Bulldozer (BD) Blade, Low Ground Pressure (LGP) - Non-regulated [NEDC20000 -] , 2050M Bulldozer (BD) Blade, Low Ground Pressure (LGP) - Non-regulated [NFDC20000 -] , 2050M Power Angle Tilt (PAT) Blade, Extra Long Track (XLT) - Non-regulated [NCDC25000 -] , 2050M Power Angle Tilt (PAT) Blade, Extra Long Track (XLT) - Non-regulated [NDDC25000 -] , 2050M Power Angle Tilt (PAT) Blade, Extra Long Track (XLT) - Non-regulated [NEDC20000 -] , 2050M Power Angle Tilt (PAT) Blade, Extra Long Track (XLT) - Non-regulated [NFDC20000 -] , 2050M Power Angle Tilt (PAT) Blade, Long Track (LT) - Non-regulated [NCDC25000 -] , 2050M Power Angle Tilt (PAT) Blade, Long Track (LT) - Non-regulated [NDDC25000 -] , 2050M Power Angle Tilt (PAT) Blade, Long Track (LT) - Non-regulated [NEDC20000 -] , 2050M Power Angle Tilt (PAT) Blade, Long Track (LT) - Non-regulated [NFDC20000 -] , 2050M Power Angle Tilt (PAT) Blade, Low Ground Pressure (LGP) - Non-regulated [NCDC25000 -] , 2050M Power Angle Tilt (PAT) Blade, Low Ground Pressure (LGP) - Non-regulated [NDDC25000 -] , 2050M Power Angle Tilt (PAT) Blade, Low Ground Pressure (LGP) - Non-regulated [NEDC20000 -] , 2050M Power Angle Tilt (PAT) Blade, Low Ground Pressure (LGP) - Non-regulated [NFDC20000 -]

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.206] Fuel filters	10.3
[10.202] Air cleaners and lines	10.4
[10.250] Turbocharger and lines.....	10.5
[10.254] Intake and exhaust manifolds and muffler	10.6
[10.400] Engine cooling system	10.7
[10.414] Fan and drive	10.8
[10.310] Aftercooler.....	10.9
[10.304] Engine lubrication system.....	10.10
Hydrostatic drive.....	29
[29.218] Pump and motor components.....	29.1
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems.....	35
[35.300] Reservoir, cooler, and filters.....	35.1
[35.104] Fixed displacement pump	35.2
[35.106] Variable displacement pump	35.3
[35.105] Charge pump.....	35.4
[35.359] Main control valve.....	35.5
[35.741] Dozer blade cylinders	35.6
[35.525] Auxiliary hydraulic valves and lines	35.7
[35.752] Hydraulic fan drive cooling system.....	35.8

[35.000] Hydraulic systems	35.9
Frames and ballasting	39
[39.100] Frame	39.1
Tracks and track suspension	48
[48.130] Track frame and driving wheels	48.1
[48.100] Tracks	48.2
[48.134] Track tension units	48.3
[48.138] Track rollers	48.4
[48.140] Dropbox and final drive	48.5
Cab climate control	50
[50.100] Heating	50.1
[50.104] Ventilation	50.2
[50.200] Air conditioning	50.3
Electrical systems	55
[55.000] Electrical system	55.1
[55.011] Fuel tank system	55.2
[55.015] Engine control system	55.3
[55.030] Service brake electrical system	55.4
[55.050] Heating, Ventilation, and Air-Conditioning (HVAC) control system	55.5
[55.100] Harnesses and connectors	55.6
[55.201] Engine starting system	55.7
[55.202] Cold start aid	55.8
[55.301] Alternator	55.9
[55.302] Battery	55.10
[55.408] Warning indicators, alarms, and instruments	55.11
[55.512] Cab controls	55.12
[55.518] Wiper and washer system	55.13
[55.DTC] FAULT CODES	55.14

Dozer blade and arm.....	86
[86.110] Dozer blade	86.1
[86.124] Dozer pushbeams and struts	86.2
Tools	89
[89.128] Ripper assembly	89.1
Platform, cab, bodywork, and decals	90
[90.150] Cab	90.1
[90.114] Operator protections	90.2
[90.124] Pneumatically-adjusted operator seat.....	90.3
[90.100] Engine hood and panels	90.4

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com