

888P/888P4A EXCAVATOR

TABLE OF CONTENTS

DIVISION/SECTION	SECTION N°	FORM N°
1 GENERAL		
Sectional Index		7-33020
Safety, General Information and Torque Specifications.....	1001 *	8-86530
Specifications	1002	7-31291
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Specifications	1002	7-40200
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
2 ENGINE		
Sectional Index		7-33030
Engine Removal and Installation.....	2000	7-31300
Radiator, Oil Cooler and Coolant Recovery System	2001	7-31310
Engine Specifications.....	2401	8-26063
Cylinder Head and Drive Train.....	2415	8-26073
Cylinder Block	2425	8-26084
Lubrication System.....	2445	8-26093
Cooling System	2455	8-26103
Turbocharger.....	2465	8-26110
Turbocharger Failure Analysis.....	2565	9-78235
3 FUEL SYSTEM		
Sectional Index		7-33040
Fuel System and Filters	3410	8-26131
Fuel Injection Pump and Drive Gear	3412	8-26143
Fuel Injectors.....	3413	8-26152
4 ELECTRICAL		
Sectional Index		7-33050
Electrical Schematics and Troubleshooting.....	4001 *	7-31331
Battery Testing, Maintenance and Booster Battery Connections	4002	7-31340
Starter Motor	4003	7-31350
Alternator.....	4004	7-31360
5 STEERING		
Sectional Index		7-33060
Steering Hand Pump.....	5002	7-31370
Steering Cylinder.....	5003	7-31380
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Steering Cylinder.....	5003	7-40590
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		

THIS TABLE OF CONTENTS REPLACES DON 7-32911

DIVISION/SECTION**SECTION N°****FORM N°****6 POWER TRAIN**

Sectional Index		7-33071
Swing Motor and Reduction Gears	6003	7-31390
Front Axle	6004	7-31400
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Front Axle	6004	7-40120
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Rear Axle	6005	7-31410
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Rear Axle	6005	7-40130
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Drive Shaft	6006	7-31420
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Drive Shaft	6006	7-40140
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Travel Motor	6007	7-31430
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Travel Motor	6007	7-40150
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Drop Box	6008	7-31440
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Drop Box	6008	7-40160
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		

7 BRAKES

Sectional Index		7-33080
Service Brakes	7002	7-31450
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Service Brakes	7002	7-40630
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Parking Brake	7003	7-31460
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Parking Brake	7003	7-40520
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		

DIVISION/SECTION	SECTION N°	FORM N°
8 HYDRAULICS		
Sectional Index		7-33091
Hydraulic Components	8000	7-31470
Hydraulic Troubleshooting	8001 *	7-31480
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Hydraulic Troubleshooting	8001 *	7-40340
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Low Pressure Pump	8002	7-31490
High Pressure Pump	8003	7-31500
Attachment Valve	8004	7-31510
Drive Control Valve	8005	7-31520
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Drive Control Valve	8005	7-40530
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Option Control Valve	8006	7-31530
Stabilizer Valve	8007	7-31540
Swing Brake Release Valve	8008	7-31550
Swing Control Valve	8009	7-31560
Anti-Surge Valve	8010	7-31570
Hydraulic Swivel	8011	7-31580
(888P Serial Number : Prior to 6199)		
(888P4A Serial Number : Prior to 7699)		
Hydraulic Swivel	8011	7-40540
(888P Serial Number : 6201 and After)		
(888P4A Serial Number : 7701 and After)		
Drive Speed Limiter	8012	7-31590
Foot Brake and Travel Control Valve	8013	7-31600
Option Foot Control Valve	8014	7-31610
Hand Control Valves	8015	7-31620
Hydraulic Oil Tank	8016	7-31630
Forward and Reverse Travel Control Valve	8017	7-32640
Attachment Cylinders	8018	7-31640
Accumulators	8020	7-32400
Clamshell Swing Motor	8024	7-40100
Clamshell Swing Safety Valve	8025	7-40110
9 CHASSIS		
Sectional Index		7-33100
Upperstructure and Turntable Bearing	9001	7-31660
Boom Dipper and Bucket	9002	7-31670
Stabilizer and Dozer Blade	9003	7-31680
Cab Servicing	9004	7-31690

* Schematic Set Sections

Sectional Index

	SECTION NO.
1 GENERAL	
C Capacities	1002
E Electrical System Specifications	1002
Engine Specifications	1002
Engine Special Torques	1002
F Fuel Specifications	1002
G General Information	1001
H Hydraulic Fittings Special Torques	1001
Hydraulic Specifications	1002
R Run-In Instructions	1002
S Safety Warnings	1001
Standard Nut and Bolt Torques	1001
Steering Specifications	1002
T Transmission Specifications	1002

Sectional Index

2	ENGINE	SECTION NO.
B	Bearings	2425
	Belt Tensioner	2455
C	Camshaft	2425
	Cooling System (Engine)	
	Cleaning and Maintenance	2425
	Crankshaft Pressure Check (Blow By)	2425
	Crankshaft	2425
	Cylinder Block	2425
	Cylinder Head	2415
E	Engine Installation	2000
	Engine Removal	2000
	Exhaust Valves	2415
	Expansion Plug Replacement	
	Expansion Cylinder Block	2425
	Expansion Cylinder Head	2415
F	Fan Pulley	2455
	Flywheel	2425
I	Intake Valves	2415
L	Lubrication System	2445
O	Oil Filter Housing	2445
	Oil Pan	2445
	Oil Pressure Relief Valve	2445
	Oil Pump	2445
	Oil Seals	2425
P	Pistons	2425
R	Radiator and Oil Cooler Installation	2001
	Radiator and Oil Cooler Removal	2001
	Rocker Arms	2415
	Rods	2425
S	Sleeves	2425
T	Thermostat	2455
	Top Dead Centre (How to Locate)	2415
	Turbocharger	2465
	Turbocharger Failure Analysis	2565
V	Valve Guide Replacement	2415
	Valve Dye Pattern Analysis	2415
	Valve Seats	2415
	Valve Train	2415
W	Water Pump	2455

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com