

FARMALL® I 10A
FARMALL® I 20A
FARMALL® I 30A
FARMALL® I 40A
Tier 4B (final)
Tractor

PIN CT00001M and above

SERVICE MANUAL

Part number 47924636

1st edition English
December 2015





SERVICE MANUAL

Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and cab. , Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and cab. , Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and cab. , Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and ROPS. , Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and cab. , Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and ROPS. , Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and cab.

Link Product / Engine

Product	Market Product	Engine
Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413U*B001
Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413U*B001
Farmall® 110A 110 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413U*B001
Farmall® 110A 110 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413U*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413T*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413T*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413T*B001
Farmall® 120A 119 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413T*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413S*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413S*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413S*B001
Farmall® 130A 130 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413S*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and ROPS.	North America	F4DFE413R*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and ROPS.	North America	F4DFE413R*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 2WD, and cab.	North America	F4DFE413R*B001
Farmall® 140A 139 HP TIER 4B (final) engine, 4WD, and cab.	North America	F4DFE413R*B001

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.202] Air cleaners and lines	10.2
[10.206] Fuel filters	10.3
[10.216] Fuel tanks	10.4
[10.254] Intake and exhaust manifolds and muffler	10.5
[10.310] Aftercooler.....	10.6
[10.400] Engine cooling system	10.7
[10.414] Fan and drive	10.8
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.9
Clutch	18
[18.100] Clutch mechanical release control	18.1
[18.110] Clutch and components	18.2
[18.112] Slip clutch or flywheel damper	18.3
Transmission.....	21
[21.109] Transmission cooler and lines.....	21.1
[21.112] Power shuttle transmission.....	21.2
[21.114] Mechanical transmission	21.3
[21.134] Power shuttle transmission external controls	21.4
[21.154] Power shuttle transmission internal components	21.5
[21.160] Creeper	21.6
Four-Wheel Drive (4WD) system	23
[23.202] Electro-hydraulic control	23.1
[23.304] Four-Wheel Drive (4WD) gearbox	23.2
[23.314] Drive shaft.....	23.3

Front axle system	25
[25.100] Powered front axle	25.1
[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
[25.400] Non-powered front axle	25.4
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential.....	27.2
[27.120] Planetary and final drives	27.3
Power Take-Off (PTO).....	31
[31.114] Two-speed rear Power Take-Off (PTO)	31.1
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.202] Hydraulic service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.116] Three-point hitch cylinder	35.4
[35.204] Remote control valves	35.5
[35.304] Combination pump units	35.6
Hitches, drawbars, and implement couplings.....	37
[37.110] Rear three-point hitch	37.1
Steering.....	41
[41.101] Steering control	41.1
[41.106] Tie rods.....	41.2
[41.206] Pump.....	41.3
[41.216] Cylinders	41.4

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com