

FARMALL® 45C FARMALL® 55C Tier 4B (final) Compact Tractor

*FARMALL® 45C Cab: PIN LSMF45CCxx0010001 to LSMF45CCPH0010018
FARMALL® 45C ROPS: PIN LSMF45CRxx0010001 to LSMF45CRVH0010031
FARMALL® 55C Cab: PIN LSMF55CCxx0010001 to LSMF55CCAH0010024
FARMALL® 55C ROPS: PIN LSMF55CRxx0010001 to LSMF55CRLH0010014*

SERVICE MANUAL

Part number 48144021

1st edition English
June 2017





SERVICE MANUAL

- Farmall® 45C Tier 4B (final), Cab [LSMF45CCxx0010001 -
LSMF45CCPH0010018]**
- Farmall® 45C Tier 4B (final), ROPS [LSMF45CRxx0010001 -
LSMF45CRVH0010031]**
- Farmall® 55C Tier 4B (final), Cab [LSMF55CCxx0010001 -
LSMF55CAH0010024]**
- Farmall® 55C Tier 4B (final), ROPS [LSMF55CRxx0010001 -
LSMF55CRLH0010014]**

Link Product / Engine

Product	Market Product	Engine
Farmall® 45C Tier 4B (final), ROPS [LSMF45CRxx0010001 - LSMF45CRVH0010031]	North America	L3C19-T3
Farmall® 45C Tier 4B (final), Cab [LSMF45CCxx0010001 - LSMF45CCPH0010018]	North America	L3C19-T3
Farmall® 55C Tier 4B (final), ROPS [LSMF55CRxx0010001 - LSMF55CRLH0010014]	North America	L3C19-T1
Farmall® 55C Tier 4B (final), Cab [LSMF55CCxx0010001 - LSMF55CCAH0010024]	North America	L3C19-T1

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.206] Fuel filters	10.3
[10.218] Fuel injection system.....	10.4
[10.202] Air cleaners and lines	10.5
[10.254] Intake and exhaust manifolds and muffler	10.6
[10.501] Exhaust Gas Recirculation (EGR) exhaust treatment.....	10.7
[10.400] Engine cooling system	10.8
[10.414] Fan and drive	10.9
Clutch	18
[18.100] Clutch mechanical release control	18.1
[18.110] Clutch and components	18.2
Power coupling.....	19
[19.110] Flywheel damper	19.1
Transmission.....	21
[21.114] Mechanical transmission	21.1
[21.130] Mechanical transmission external controls.....	21.2
[21.140] Mechanical transmission internal components.....	21.3
[21.110] Master clutch housing	21.4
Four-Wheel Drive (4WD) system	23
[23.314] Drive shaft.....	23.1
[23.101] Mechanical control	23.2
Front axle system	25
[25.100] Powered front axle	25.1

[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
Rear axle system.....	27
[27.106] Rear bevel gear set and differential	27.1
[27.120] Planetary and final drives	27.2
Hydrostatic drive.....	29
[29.200] Mechanical control	29.1
[29.100] Transmission and steering hydrostatic control	29.2
[29.204] Reservoir, cooler, and lines	29.3
[29.218] Pump and motor components.....	29.4
[29.202] Hydrostatic transmission	29.5
Power Take-Off (PTO)	31
[31.101] Rear mechanical control	31.1
[31.104] Rear electro-hydraulic control.....	31.2
[31.110] One-speed rear Power Take-Off (PTO)	31.3
[31.120] Central Power Take-Off (PTO)	31.4
Brakes and controls	33
[33.110] Parking brake or parking lock	33.1
[33.120] Mechanical service brakes	33.2
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.300] Reservoir, cooler, and filters.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.350] Safety and main relief valves	35.4
[35.204] Remote control valves	35.5
[35.114] Three-point hitch control valve	35.6
[35.116] Three-point hitch cylinder	35.7
[35.724] Front loader hydraulic system control.....	35.8

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com