MAGNUM 235
MAGNUM 260
MAGNUM 290
MAGNUM 315
MAGNUM 340

Tractor

from PIN ZBRD07000 and above

SERVICE MANUAL

Part number 47442317
2nd edition English
September 2012
Replaces part number 47386173

CASE IH AGRICULTURE

Contents

INTRODUCTION

Engine 10

Engine and crankcase 10.001

Cylinder heads 10.101

Pump drives 10.114

Air cleaners and lines 10.202

Fuel tanks 10.216

Aftercooler 10.310

Engine cooling system 10.400

Fan and drive 10.414

Selective Catalytic Reduction (SCR) exhaust treatment 10.500

Transmission 21

Powershift transmission lubrication system 21.105

Powershift transmission 21.113

Powershift transmission external controls 21.135

Gearbox internal components 21.145

Powershift transmission internal components 21.155

Drop box 21.200

Four-Wheel Drive (4WD) system 23

Electrohydraulic control 23.202

Drive shaft 23.314

Front axle system 25

Powered front axle 25.100

Front bevel gear set and differential 25.102

Final drive hub, steering knuckles, and shafts 25.108

Axle suspension control 25.122

Rear axle system 27

Powered rear axle 27.100
Rear bevel gear set and differential 27.106
Planetary and final drives 27.120
Power Take-Off (PTO) 31
Rear electrohydraulic control 31.104
One-speed rear Power Take-Off (PTO) 31.110
Two-speed rear Power Take-Off (PTO) 31.114
Front Power Take-Off (PTO) 31.146
Brakes and controls 33
Parking brake / Parking lock 33.110
Hydraulic service brakes 33.202
Trailer brake hydraulic control 33.220
Trailer brake pneumatic control 33.224
Hydraulic systems 35
Hydraulic systems 35.000
Pump control valves 35.102
Variable displacement pump 35.106
Three-point hitch control valve 35.114
Remote control valves 35.204
Reservoir, cooler, and filters 35.300
Combination pump units 35.304
Pneumatic system 36
Pneumatic system 36.100
Hitches, drawbars, and implement couplings 37
Rear three-point hitch 37.110
Front hitch 37.162
Steering 41
Steering control 41.101

Hydraulic control components 41.200
Pump 41.206
Cab climate control 50
Heating 50.100
Air conditioning 50.200
Cab pressurizing system 50.300
Electrical systems 55
Engine cooling system 55.012
Front axle control system 55.045
Rear axle control system 55.046
Heating, Ventilation, and Air-Conditioning (HVAC) control system 55.050
Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls 55.051
Harnesses and connectors 55.100
Three-point rear hitch electronic control system 55.130
Engine starting system 55.201
Alternator 55.301
Battery 55.302
External lighting 55.404
External lighting switches and relays 55.405
Warning indicators, alarms, and instruments 55.408
Cab controls 55.512
Cab lighting 55.514
Wiper/Washer system 55.518
Electronic modules 55.640
Selective Catalytic Reduction (SCR) electrical system 55.988
FAULT CODES 55.DTC
Platform, cab, bodywork, and decals 90
Engine hood and panels 90.100
Engine shields, hood latches, and trims 90.102

Protections and footboards 90.118
Pneumatically-adjusted operator seat 90.124
Cab 90.150
Cab interior 90.151

Thank you so much for reading.

Please click the “Buy Now!” button below to download the complete manual.

After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com