

Magnum™ 180
Magnum™ 200
Magnum™ 220
Powershift Transmission (PST)
Tractor

PIN ZERH08100 and above

SERVICE MANUAL

Part number 47748093

1st edition English
September 2014





SERVICE MANUAL

Magnum™ 180 696110052 PST TIER 4B [ZERH08100 -]
Magnum™ 200 696110062 PST TIER 4B [ZERH08100 -]
Magnum™ 220 696110072 PST TIER 4B [ZERH08100 -]

Link Product / Engine

Product	Market Product	Engine
Magnum™ 180 696110052 PST TIER 4B [ZERH08100 -]	North America	F4HFE613K*B002
Magnum™ 180 696110052 PST TIER 4B [ZERH08100 -]	Australia New Zealand	F4HFE613K*B002
Magnum™ 200 696110062 PST TIER 4B [ZERH08100 -]	Australia New Zealand	F4HFE613J*B005
Magnum™ 200 696110062 PST TIER 4B [ZERH08100 -]	North America	F4HFE613J*B005
Magnum™ 220 696110072 PST TIER 4B [ZERH08100 -]	North America	F4HFE613H*B003
Magnum™ 220 696110072 PST TIER 4B [ZERH08100 -]	Australia New Zealand	F4HFE613H*B003

Contents

INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase	10.1
[10.216] Fuel tanks	10.2
[10.218] Fuel injection system.....	10.3
[10.202] Air cleaners and lines	10.4
[10.500] Selective Catalytic Reduction (SCR) exhaust treatment.....	10.5
[10.400] Engine cooling system	10.6
[10.414] Fan and drive	10.7
[10.310] Aftercooler.....	10.8
[10.304] Engine lubrication system.....	10.9
Power coupling.....	19
[19.100] Drive shaft.....	19.1
[19.110] Flywheel damper	19.2
Transmission.....	21
[21.113] Powershift transmission	21.1
[21.135] Powershift transmission external controls.....	21.2
[21.155] Powershift transmission internal components.....	21.3
[21.160] Creeper	21.4
[21.166] Overdrive.....	21.5
[21.200] Dropbox	21.6
Four-Wheel Drive (4WD) system	23
[23.202] Electro-hydraulic control	23.1
[23.314] Drive shaft.....	23.2
Front axle system	25
[25.100] Powered front axle	25.1

[25.102] Front bevel gear set and differential	25.2
[25.108] Final drive hub, steering knuckles, and shafts	25.3
[25.122] Axle suspension control.....	25.4
Rear axle system.....	27
[27.100] Powered rear axle.....	27.1
[27.106] Rear bevel gear set and differential	27.2
Power Take-Off (PTO)	31
[31.104] Rear electro-hydraulic control.....	31.1
[31.114] Two-speed rear Power Take-Off (PTO)	31.2
Brakes and controls	33
[33.202] Hydraulic service brakes	33.1
[33.110] Parking brake or parking lock	33.2
[33.220] Trailer brake hydraulic control.....	33.3
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.104] Fixed displacement pump.....	35.3
[35.105] Charge pump.....	35.4
[35.106] Variable displacement pump	35.5
[35.114] Three-point hitch control valve	35.6
[35.116] Three-point hitch cylinder	35.7
[35.204] Remote control valves	35.8
[35.300] Reservoir, cooler, and filters.....	35.9
Hitches, drawbars, and implement couplings.....	37
[37.110] Rear three-point hitch	37.1
Frames and ballasting	39
[39.140] Ballasts and supports	39.1
Steering.....	41

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.
You can download the most
perfect and complete manual in
the world immediately.

Our support email:
ebooklibonline@outlook.com