



Service Repair Manual

Models

730C Ejector Articulated Truck

Product: EJECTOR TRUCK

Model: 730C EJECTOR TRUCK TFH

Configuration: 730C Ejector Articulated Truck TFH00001-UP (MACHINE) POWERED BY C13 Engine

Disassembly and Assembly 730C and 730C EJECTOR Articulated Trucks

Media Number -UENR2343-01

Publication Date -01/10/2014

Date Updated -29/03/2016

i05827145

Diesel Exhaust Fluid Tank - Remove and Install

SMCS - 108T-010

Removal Procedure



Illustration 1

g03683264

1. Disconnect tubes (1).



2. Remove clip (2).



Illustration 3

g03687356

3. Clamp and disconnect tubes (3). Disconnect harness assembly (4).




Illustration 4

g03687365

4. Remove strap assemblies (5) and diesel exhaust fluid tank (6).

Installation Procedure

1. Install diesel exhaust fluid tank (6) in the reverse order of removal.
 - a. Tighten locknuts on straps assemblies (5) to a torque of $12 \pm 2 \text{ N}\cdot\text{m}$ ($106 \pm 18 \text{ lb in}$).

Product: EJECTOR TRUCK

Model: 730C EJECTOR TRUCK TFH

Configuration: 730C Ejector Articulated Truck TFH00001-UP (MACHINE) POWERED BY C13 Engine

Disassembly and Assembly 730C and 730C EJECTOR Articulated Trucks

Media Number -UENR2343-01

Publication Date -01/10/2014

Date Updated -29/03/2016

i06599787

Diesel Exhaust Fluid Pump - Remove and Install

SMCS - 108J-010

Removal Procedure





Illustration 1

g03676794


1. Disconnect hose assemblies (1).




2. Remove bolt (2) and hose clamp (3).



3. Remove bolt (4) and hose clamp (5).



4. Disconnect harness assembly (6). Remove cable strap (7).



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com