

8875
Skid-Steer
Loader

(Serial No. 010001 –)

OPERATOR'S
MANUAL

John Deere
Lawn & Grounds Care Division
OMM123273 C5

Export Version
Litho in U.S.A
English

INTRODUCTION

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages (see your John Deere dealer to order).

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing the direction of forward travel.

BEFORE DELIVERING THIS MACHINE, your dealer performed a predelivery inspection to ensure best performance.

THIS SKID STEER LOADER IS DESIGNED SOLELY for use in customary agricultural and forestry operations, for park and amenity area maintenance, and for winter work or similar operation (“INTENDED USE”). Use in any other way is considered as contrary to the intended use.

The manufacturer accepts no liability for damage or injury resulting from this misuse, and these risks must be borne solely by the user. Compliance with and strict adherence to the conditions of operation, service and repair as specified by the manufacturer also constitute essential elements for the intended use.

INTRODUCTION

THIS SKID STEER LOADER SHOULD BE OPERATED, serviced and repaired only by persons familiar with all its particular characteristics and acquainted with the relevant safety rules (accident prevention). The accident prevention regulations, all other generally recognized regulations on safety and occupational medicine and the road traffic regulations must be observed at all times.

Any arbitrary modifications carried out on this skid steer loader will relieve the manufacturer of all liability for any resulting damage or injury.

Date of Purchase: _____

Dealer Name: _____	Phone: _____
------------------------------	------------------------



INTRODUCTION

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the space provided below. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.





TABLE OF CONTENTS

	Page
Safety Signs	
Safety-Alert Symbol	1
Machine Safety Labels	1
Certification Labels	5
Controls	
Hand Controls.....	6
Foot and Overhead Panel Controls	7
Operating	
SAFETY:	
Operator Training Required	9
Use Seat Belt Properly	9
Use Handholds and Steps	9
Operate Safely.....	10
Protect Children and Prevent Accidents	11
Keep Riders Off	11
Avoid Tipping	12
Park Safely	12
Wear Appropriate Clothing	13
Check Wheel Bolts	13
Transport Safely	13
ADJUSTMENTS:	
Seat	14
DRIVING:	
Entering and Exiting Loader	15
Using the Park Brake.....	16
Using Service/Run Switch	16
Using Electronic Instrument Monitor (EIM)	17
Using Select Switches	23
Using Cold Start Button	26
Starting the Engine	26
Avoid injury from an explosion:.....	28
Stopping the Engine	30
Using Drive Controls.....	31

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com