

# 201 Implement Carrier



## OPERATORS MANUAL

### 201 Implement Carrier

OMA41296 Issue E0 English

**John Deere Plow & Planter Works**  
**OMA41296 Issue E0**


LITHO IN U.S.A.  
ENGLISH





## To the Purchaser

---

 This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

"Right-hand" and "left-hand" sides are determined by facing in the direction of forward travel.

Record your carrier serial number in the space provided on page 18.

The general carrier warranty appears on your copy of the purchase order which you should have received from your dealer when you purchased the implement carrier.

This operator's manual contains SI Metric equivalents which follow immediately after the U.S. customary units of measure.

# JOHN DEERE 201 IMPLEMENT CARRIER

## PREDELIVERY CHECK LIST

After the carrier has been completely assembled and lubricated, inspect it thoroughly to be certain it is in good operating condition before delivering it to the customer. The following check list is a reminder of points to inspect. Check off each item as it is found satisfactory.

### Carrier Inspection

- ☐ Check all wheel hub bolts to be sure they are tight.
- ☐ Check lock plate bolts on the axle to be sure they are tight.
- ☐ Inflate tires to proper pressure (see page 5).
- ☐ Check and, if necessary, lubricate all lubrication points.
- ☐ Raise and lower bed of carrier and check for proper operation.

\_\_\_\_\_  
(Date)

\_\_\_\_\_  
(Service Technician)

## DELIVERY CHECK LIST

- ☐ Show the customer the location and function of the controls.
- ☐ Explain the adjustment for operation.
- ☐ Explain the importance of proper lubrication.
- ☐ Give the customer the operator's manual and explain that all the things discussed so far are explained and illustrated in the manual in detail plus a lot of other valuable information.
- ☐ Explain to the customer that when the carrier is transported on a road or highway at night or during the day, devices should be used for adequate warning to operators of other vehicles. In this regard tell the customer to check local governmental regulations.

- ☐ Invite the customer to come in and discuss any problems which may be encountered while loading and unloading the carrier.

\_\_\_\_\_  
(Date)

\_\_\_\_\_  
(Delivery Person)

## AFTER-SALE CHECK LIST

- ☐ Check with the customer to see if the recommended periodic lubrication has been performed.
- ☐ Check with the customer as to the performance of the carrier.
- ☐ Acquaint the customer with any special attachment which will help do a better job.

\_\_\_\_\_  
(Date)

\_\_\_\_\_  
(Service Technician)

## OWNER REGISTER

Name \_\_\_\_\_

Post Office \_\_\_\_\_

County \_\_\_\_\_ State \_\_\_\_\_

Date Purchased \_\_\_\_\_



# Contents

---

**Page**

**2-3**

**Safety**

**4**

**Identification Views**

**5-9**

**Operation**

**10**

**Lubrication**

**11**

**Attachments**

**12-17**

**Assembly**

**18**

**Specifications**

**19**


**Index**



# Safety

## PROTECT AGAINST NOISE

2-3



A—Earmuffs

B—Earplugs

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs (A) or earplugs (B) to protect against objectionable or uncomfortable loud noises.

## LUBRICATE THE CARRIER SAFELY

Do not grease, oil or adjust the carrier while it is in motion.

## DISPOSE OF SPRAY CANS SAFELY

If spray can paint is used for protecting carrier frame before storage, be careful when discarding empty can. Do not incinerate or puncture can.

## OPERATE CARRIER SAFELY

Never ride, or permit others to ride, on the drawbar of the tractor hitch, carrier hitch, or bed of the carrier.

Keep all persons clear when moving carrier bed to and from loading position.

Always keep feet clear of carrier frame when lowering or raising the carrier with the jack stand.

Never leave the implements on the carrier in a raised position.

Tow only with an agricultural tractor equipped with stationary drawbar.

Always stop the tractor engine before dismounting.

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)