

## 494 and 495 Corn Planters



## **OPERATORS MANUAL**

494 and 495 Corn Planters

OMB25002B (01OCT60) English

OMB25002B (01OCT60)

LITHO IN U.S.A. ENGLISH



## TO THE PURCHASER

Your new Planter is sturdy and dependable. It will give long and efficient service if given proper care and operation.

This Operator's Manual is provided to furnish information on the proper operation, adjustment, maintenance, and lubrication of the 494 and 495 Planters. Generally instructions apply to either machine. However, where instructions apply specifically to only one machine, the information is included in the heading.

When in need of parts, see your John Deere dealer. He will furnish genuine John Deere Parts and prompt and efficient service in the field or in the shop.

Right-hand and left-hand reference is determined by standing at the rear of the planter and facing the direction of travel.




Study this manual carefully. Keep it handy, in a safe place, for future reference.


494 OR 495 CORN PLANTER		
Check off model of your planter, special equipment obtained, and record date purchased.  Model:  494—Hill-Drop with runner openers.  494—Drill with runner openers.  494—Drill with disk openers.  495—with runner openers.  Check-Row Attachment.  Fertilizer Attachment:  Dry.  Liquid.	Press Wheel Scrapers	
Gauge Shoes	Granular Herbicide	
Trash Nickers	Date Fulchased	

## TABLE OF CONTENTS

	Page
IDENTIFICATION VIEWS	2-3
SPECIFICATIONS	4–5
OPERATION	6-56
Preparing the Tractor	6
Preparing the Planter	6-9
	10-11
Transporting	12
Basic Field Operation.	12-13
Check-Row Planting—494 Only.	14-21
Hill-Drop Planting—494 Only	22-24
Drill Planting—494 Only.	26-27
Hill-Drop or Drill Planting—495 Only.	28-31
Soybean Charts—494 or 495 Planter	
Maize Chart—494 or 495 Planter	34
Plant Population	34–35
Safety Suggestions	37
Fertilizer Attachments	38–47
Trash Kickers	48
14-Inch Double-Disk Openers	48
11-Inch Double-Disk Openers	48
Double-Disk Furrowers.	49
Dual Wheel Frame	49
Seed Packer Wheels—494 Only	50
Press Wheel Scrapers	50
Press Wheel Bands	50
Rubber Press Wheel Tires	51
Gauge Shoes	51
Insecticide Attachment	52-53
Pea Attachment	53
Disk Coverers	53
Dual Marker Control	54-55
Beet Seed Hopper	55
Minimum Tillage Attachment	56
Dry Fertilizer Hopper Divider	56
LUBRICATION	58–59
	60-71
At the Beginning of the Season	60
At the End of the Season.	60
Storing Planter	61
Runner Alignment.	
Rockshaft Bearings.	63
Timing the Planter	
Ratchet Drive.	66 66
Valve Adjustment—494 Only	67
Valve Adjustment—494 Only	
Causes for Common Difficulties Encountered when Planting	70 71



494 Hill-Drop Corn Planter



494 Hill-Drop Corn Planter with Dry Fertilizer Attachment

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com