

PRE-EMERGENCE SPRAYER FOR 493A COTTON AND CORN PLANTER OR 494,494A, 495 OR CORN PLANTERS



OPERATORS MANUAL

**PRE-EMERGENCE SPRAYER FOR 493A COTTON
AND CORN PLANTER OR 494,494A, 495 OR
CORN PLANTERS**

OMB25221 D5 English

OMB25221 D5

LITHO IN THE U.S.A.
ENGLISH






TO THE PURCHASER

Your new John Deere Pre-Emergence Sprayer is sturdy and dependable. It will give long and efficient service if given proper care and operation.

This Operator's Manual is provided to furnish information on the proper operation, adjustment, and lubrication of your Pre-Emergence Sprayer. A parts list, with illustrations, is provided.

When in need of parts, see your John Deere dealer. He will furnish genuine John Deere parts and prompt and efficient service in the field or shop.

Study this manual carefully. Keep it handy, in a safe place, for future reference.



Right-hand and left-hand reference is determined by standing at the rear of the machine and facing the direction of travel.


John Deere Pre-Emergence Sprayer

Date Purchased



TABLE OF CONTENTS

SPECIFICATIONS	3
OPERATION.	4
Attaching to tractor	4
Shut-off rod adjustment	4
Pressure control	5
Determining and adjusting rate of application	6
Nozzle check valve	6
PTO pumps	10
Gear pump lubrication.	10
Pump capacity	10
Cleaning sprayer	11
SAFETY SUGGESTIONS	12
SERVICE	13
Nozzles	13
Pressure regulator.	13
Gear pump	14
Strainer	14
Roller pump	15
TROUBLE SHOOTING	19
ASSEMBLY	20





SPECIFICATIONS

The Pre-Emergence Sprayer is used to apply any liquid chemical form of herbicide in the row at the time of planting. It can be used with or without the liquid or dry fertilizer attachment and also with or without the granular insecticide attachment.

TANK CAPACITY - Approximately 50 U.S. gallons.

PUMP - A gear or roller pump, operated by the tractor power take-off, furnishes the pressure needed to operate the sprayer.

CONTROLS - The pressure regulator is easily accessible and the pressure gauge is visible from the tractor seat.

NOZZLES - Located at the rear of the press wheels.

NOZZLE TIPS - Nozzle tip number B11655B is furnished as regular equipment. Other nozzle tips of various sizes are available from your John Deere dealer.

WIDTH OF SPRAY BAND - Adjustable, by moving the nozzle frame up or down.

(Specifications and design subject to change without notice.)



THE COMPLETE OBSERVANCE of one simple rule would prevent many thousand serious injuries each year. THAT RULE IS: "NEVER ATTEMPT TO CLEAN, OIL, OR ADJUST A MACHINE WHILE IT IS IN MOTION."

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com