

# 130 DRAPER PLATFORM 35 AND 65 HAY CONDITIONERS



## OPERATORS MANUAL 130 DRAPER PLATFORM 35 AND 65 HAY CONDITIONERS


OME65969 J1 English


OTTUMWA WORKS  
OME65969 J1

LITHO IN THE U.S.A.  
ENGLISH



# INTRODUCTION

 **This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.**


 Worldwide symbols are used to assist identification and operation. In this manual, an identifying symbol is placed by the instructions like the example at left for the symbol on the engine oil pressure gauge. The cylinder block in the symbol represents the engine, the drop signifies oil, and the arrows indicate pressure. Regardless of the language used in a nation, this symbol means engine oil pressure without translation.

This operator's manual contains SI Metric equivalents which follow immediately after the U.S. customary units of measure.

"Right-hand" and "left-hand" sides are determined by facing in the direction the platform will travel when in use.

Record your platform model and serial numbers on page 121.

Your warranty appears on your copy of the purchase order copy which you should have received from your dealer.



E17264

A—Hydraulic Reel Drive Motor  
B—Reel Drive Reservoir

C—Pickup Reel  
D—Hydraulic Reel Lift Cylinder

E—Divider Point  
F—Canvases

E17264

*John Deere 130 Draper Platform - 15 Foot (4 572 mm)*

# JOHN DEERE 130 DRAPER PLATFORM

## PREDELIVERY CHECK LIST

After the draper platform has been completely assembled, inspect it to be sure it is in good running order before delivering it to the customer. The following check list is a reminder of points to inspect. Check off each item as it is found satisfactory or after proper adjustment is made.

- All grease fittings have been lubricated and gear cases filled. (See "Lubrication", page 28.)
- All moving parts are working freely.
- Check gauge wheel inflation pressure.
- Remove shipping plug from cutterbar drive case and install breather plug. Check knife drive case mounting bolts and knife drive arm nut torque (see page 85).
- Remove shipping plug from platform distribution case and install breather.

\_\_\_\_\_  
(Date Set-Up)

- Check tension of all belts and adjust if necessary.
- Check all chains for proper installation and adjustment.
- Check reel speed and position, pages 14 and 15.
- Platform has been run for one-half hour and bearings are not heating.

\_\_\_\_\_  
(Signature of Set-Up Technician)

## DELIVERY CHECK LIST

At the time the draper platform is delivered, the following check list is a reminder of very important information which should be conveyed directly to the customer. Check off each item as it is fully explained to the customer.

- Advise the customer that the life expectancy of this or any other machine is dependent on regular lubrication as described in the operator's manual.
- Advise the customer of the safety precautions that must be exercised while using this platform, page 2.
- Give the operator's manual to the customer and explain all operating adjustments and lubrication fully.

\_\_\_\_\_  
(Date Delivered)

## OWNER REGISTER

Name \_\_\_\_\_  
Rural Route # \_\_\_\_\_  
County \_\_\_\_\_ State \_\_\_\_\_ Zip \_\_\_\_\_  
Serial Number \_\_\_\_\_  
Operator's Manual No. \_\_\_\_\_  
Date Sold \_\_\_\_\_

- Advise the customer of the optional attachments that are available for special crop and operating conditions.

\_\_\_\_\_  
(Signature)

## AFTER-SALE CHECK LIST

It is suggested the following items be checked sometime during the first operating season.

- Go over the entire machine and check for loose or missing bolts.
- Check chains and belts for proper tension.
- Make sure all safety shields are in place.
- Check canvases for proper tension.
- Check platform flotation.
- Check for broken or damaged parts.
- If possible, run the platform to see if it is functioning properly.
- Review the entire operator's manual with the customer and stress the importance of proper and regular lubrication and safety precautions.

---

(Date Checked)

---

(Signature)



# Contents

---

	Page
Safety .....	2
Attaching the Platform .....	5
Operating the Platform .....	9
Attachments .....	24
Lubrication and Maintenance .....	28
Trouble Shooting .....	34
Service .....	40
Storage .....	66
Assembly .....	68
Specifications .....	124
Index .....	126

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)