

330B / 430B LOG LOADER

OPERATOR'S MANUAL 330B / 430B LOG LOADER OMF307962

CALIFORNIA Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects and other reproductive harm.



WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Worldwide Construction and Forestry Division

English

Serial Numbers :

330B

90CA4201 –

TJ330BX004111 –

WM330BX004300 –

WC0330B011002 –

TJ330BX004216

WM330BX004312

WC0330B011004

430B

90CB4118 –

90CB4120 –

TJ430BX004118 –

WM430BX004300 –

WC0430B012009 –

90CB4119

TJ430BX004217

WM430BX004317

WC0430B012092

Sections

Section	Description
1	Introduction
2	Warranty
3	Safety
4	Description
5	Operation
6	Lubrication & Maintenance
7	Troubleshooting
8	Specifications
9	S240/S260/S261 Slashers Operator's Manual Section
10	D250 Delimber Operator's Manual Section

Appendices

A	Metric & Imperial Unit Expressions
B	Measurement Conversions
C	Wood Measurement
D	Weights of Commercial Woods
E	General Bolt Torque Values
F	Abbreviations
	Checklists

Contents

Section 1 – Introduction

.1	Foreword	1-1
.2	Model & Serial Number Record	1-2
.3	Installation	1-3

Section 2 – Warranty

2-1

Section 3 – Safety

3-1

.1	Safety Signs	3-20
----	--------------------	------

Contents

Section 4 – Description

.1	Introduction	4-1
.2	Equipment Nomenclature	4-2
.3	Controls & Instrumentation	4-4
.1	Switches, Gauges & Indicators	4-4
	Master Disconnect Switch	4-4
	Engine Gauges	4-4
	Ignition Key Switch	4-5
	Throttle Control	4-5
	Horn	4-6
	Switches	4-7
	Indicators	4-8
.2	Operating Controls	4-9
	Swing Control	4-9
	Joysticks	4-9
.3	Miscellaneous Items	4-10
	Interior Light	4-10
	Cab Fan	4-10
	Seat	4-11

Section 5 – Operation

.1	Engine	5-1
.1	Pre-Start Checks	5-1
.2	Throttle Speed Switch	5-2
.3	Starting/Stopping	5-2
	Normal Starting	5-2
	Cold Weather Starting	5-2
	Using Battery Charger	5-3
.4	Cold Weather Warm-Up	5-3
.5	Idling	5-3
.6	Stopping the Engine	5-4
.2	Loader	5-4
.1	Stabilizers	5-4
.2	Turntable Rotation	5-5
.3	Implements	5-5
.1	Joystick Controls	5-5
.4	Transporting	5-7
.5	330B & 430B Main Boom Lowering	5-8

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com