

7722 COMBINE



OPERATORS MANUAL 7722 COMBINE

OMH124035 D6 English



OMH124035 D6

LITHO IN THE U.S.A. ENGLISH

Introduction

Use this operator's manual as a supplement to the 7720 and 200 Series Platform manuals provided. This manual covers only those areas of your machine that are unique to the 7722 Combine and platform.



This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

Your operator's manual contains SI metric equivalents which follow immediately after the U.S. customary units of measure.

"Right-hand" and "left-hand" sides are determined by facing in the direction the machine will travel when in use.

The warranty on this machine appears on your copy of the purchase order which you should have received from your dealer when making your purchase. This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provided field improvements, often without charge to the customer, even if the product is out of warranty.

Warranty and field improvements are a part of John Deere's product support program for customers who operate and maintain their equipment as described in this manual. Should the equipment be abused or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied.

Contents

Î

Page

Safety	1
Operation	5
Lubricants	6
Lubrication and Maintenance 1	8
Service	4
Specifications	2

H11;1 050366

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

AB6;T81389 053;ALERT 071085

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



AWARNING


ACAUTION

AB6;T\$187 053;SIGNAL 071085

FOLLOW SAFETY INSTRUCTIONS


Carefully read all safety messages in this manual and on your machine safety signs. Follow recommended precautions and safe operating practices.

Keep safety signs in good condition. Replace missing or damaged safety signs.



UNAUTHORIZED MODIFICATIONS

Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.




H11;P001 020486

OPERATE SAFELY

Clothing worn by operator must be fairly tight and belted. Loose jackets, shirts, or sleeves must never be worn.


Any time work is being done under header, the hydraulic cylinder safety stop must be placed in the safety position.

Keep hands, feet and clothing away from moving parts.



LEAVING COMBINE UNATTENDED


Before leaving combine unattended, turn off engine and remove keys. Support header with hydraulic cylinder safety stop if it is necessary to go under the header or feeder house. See the combine Operator's Manual for complete safety information.



4KA;H37524 H01;;25HC B 080185

AVOID CONTACT WITH MOVING PARTS

Keep hands, feet and clothing away from powerdriven parts. Never clean, lubricate or adjust machine when it is running.



AVOID CONTACT WITH CUTTERBAR

Never attempt to clear obstructions off cutting platform unless separator is disengaged and engine is shut off and key removed. Everyone must be clear before starting engine or running combine.



H11;P002 020486

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com