# 48 and 54-Inch **Commercial** Walk-Behind Mowers (Serial No. 010,001— )

John Deere Horicon Works **OMM111766 Issue C2** (This manual replaces OMM111766, Issue L0.) LITHO IN U.S.A.
ENGLISH

### Introduction

THANK YOU for purchasing a John Deere product.

READ THIS MANUAL CAREFULLY to learn how to operate and service your mower correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your mower and should remain with the mower when you sell it.

**MEASUREMENTS IN THIS MANUAL** are U.S. customary units and their metric equivalents.

RIGHT AND LEFT SIDES are determined by facing in the direction of forward travel.

WRITE MACHINE NUMBERS in the Specifications section. You need these numbers to help you order parts, and to help trace the machine if it is stolen. Also record and keep these numbers in a safe place in case this manual is lost.

WARRANTY IS PROVIDED as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.



MX,IFC,M111766 -19-19MAR92

## **Contents**

Page	Page
Safety	
<b>Controls</b>	Service—Lubrication and TiresGrease28Lubricating Mower28Checking Tire Pressure29
Operation	Officially file fressure
Leveling Mower	Service—Fuel System
Side-to-Side	Fuel
Front-to-Rear	Fuel Shutoff 30
Adjusting Cutting Height	Cleaning Fuel Cap Vent
Starting Engine	Changing Fuel Filter
Checking Safety System	Complete Aim Inteller Countries
Stopping Engine	Service—Air Intake System Servicing Air Cleaner
Checking Blade Stop Time	Carburetor Adjustments
Travel Speeds	Carbarotor / tajacamonto : : : : : : : : : : : : : : : : : : :
Traction Drive	Service—Electrical System
PTO Switch	Electrolyte Level
Turn/Service Brakes	Gapping Spark Plug
Mowing Tips	Charging Battery
Bagging Tips 20	Booster Battery
Mulching Tips 20	Replacing Battery
Transporting 20	Replacing ruse
Troubleshooting	Service—Blades
Troubleshooting	Inspecting Blades
John Deere Parts	Sharpening Blade
John Deere Faits ZZ	Balancing Blade
Service Interval Chart	
Solvios interval share	Service—Belts
Service—Engine Oil and Filter	Belt Shields 42
Engine Oil	Replacing Transmission Belt 43
Checking Oil Level	Replacing Mower Belt 43
Changing Engine Oil	
Changing Engine Oil Filter	Service—Brakes
- , -	Linkage & Brake Adjustment
Service—Transmission Oil	Turn Brake Adjustment
Transmission Oil	Park Brake Adjustment
Checking Oil Level 27	•
Changing Oil	Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMM111766 C2-19-19MAR92

COPYRIGHT® 1992
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRUCTION™ Manual
Previous Editions
Copyright 1991 & 1990 Deere & Company

#### Contents

	Page
Traction Control Linkage Adjustment	
Storage	. 57
Assembly	. 59
Specifications	. 67
Index	

### **Safety**

#### **READ SAFETY SIGNS & INSTRUCTIONS**



This symbol means **BE ALERT FOR POSSIBLE INJURY**.

**DANGER** points out immediate hazards which will cause severe injury or death.

**WARNING** points out hazards or unsafe practices which could cause severe injury or death.


**CAUTION** points out hazards or unsafe practices which could cause minor injury or machine or property damage.

**KEEP SAFETY SIGNS** in good condition. You can buy safety signs from your John Deere dealer.

**READ, UNDERSTAND, & FOLLOW** all instructions in this manual and on the machine, before starting.

**ALLOW ONLY RESPONSIBLE ADULTS**, who are familiar with instructions, to operate the machine.

**IF YOU DON'T UNDERSTAND** any part of this manual, see your John Deere dealer.



Right End of Mower Deck

-19-18SEP90



Left End of Mower Deck

### **A** CAUTION

#### HELP AVOID INJURY

- OPERATOR TRAINING REQUIRED
- KNOW CONTROLS BEFORE OPERATING
- CLEAR AREA OF PEOPLE AND ANIMALS
- STOP ENGINE WHENEVER YOU
- LEAVE THE MOWER

   KEEP ALL SHIELDS AND SAFETY
  DEVICES IN PLACE
- READ OPERATORS MANUAL

Center of Instrument Panel

3297

19-010CT90

MX,SAFQ,M -19-19MAR92

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com