3375 Skid-Steer Loader

(Serial No. 140001 –)

OPERATOR'S MANUAL

John Deere Lawn & Grounds Care Division OMM121047 B5

> Export Version Litho in U.S.A English

INTRODUCTION

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages (see your John Deere dealer to order).

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing the direction of forward travel.

SETTING FUEL DELIVERY BEYOND PUBLISHED factory specifications or otherwise overpowering will result in loss of warranty protection for this machine.

BEFORE DELIVERING THIS MACHINE, your dealer performed a predelivery inspection to ensure best performance.

THIS SKID STEER LOADER IS DESIGNED SOLEY for use in customary agricultural and forestry operations, for park and amenity area maintenance and for winter work ("intended use"). Use in any other way is considered as contrary to the intended use.

The manufacturer accepts no liability for damage or injury resulting from this misuse, and these risks must be borne soley by the user. Compliance with and strict adherence to the conditions of operation, service and repair as specified by the manufacturer also constitute essential elements for the intended use.

INTRODUCTION

THIS SKID STEER LOADER SHOULD BE OPERATED,

serviced and repaired by persons familiar with all its particular characteristics and acquainted with the relevant safety rules (accident prevention). The accident prevention regulations, all other generally recognized regulations on safety and occupational medicine and the road traffic regulations must be observed at all times.

Any arbitrary modifications carried out on this machine will relieve the manufacturer of all liability for any resulting damage or injury.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the space provided below. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

Date of Purchase:	Dealer Name:	Phone:



INTRODUCTION




TABLE OF CONTENTS

	Page
Safety Signs	
Pictorial Safety Signs	1
Avoid Overturn	
Avoid Injury	1
Avoid Death	2
No Riders-Avoid Death	2
Avoid Injury	2
Warning	3
Stop engine	3
Avoid Tipping	3
Controls	
Hand Controls	5
Foot Controls	
Instrument Panel	
Control Panel	
Indicator Lights	7
Lift Arm Stop Control Lever	8
Operate Safely	
Operator Training Required	9
Use Seat Belt Properly	9
Protect Children	10
Keep Riders Off Machine	10
Park Safely	10
Avoid Tipping	11
Avoid Death	11
Remember The Other Guy	11
Avoid Injury	
Avoid Hazards	
Use Handholds And Steps	13

Thank you so much for reading.

Please click the "Buy Now!"

button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com