

STX38 and STX46 Lawn Tractor

(Serial No. 270001–)

OPERATOR'S MANUAL

**John Deere
Lawn & Grounds Care Division
OMM124078 J5**

**North American Version
Litho in U.S.A
English**

INTRODUCTION

THANK YOU for purchasing a John Deere product.


Read this manual and your attachment manuals thoroughly. Failure to do so could result in personal injury or equipment damage.



C WARNING: The Engine Exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

CALIFORNIA Proposition 65 Warning

This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.

Measurements in this manual are metric units and their U.S. customary equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow () it indicates the part it is pointing to is hidden.

Record identification numbers below. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also

| | | |
|--------------------------|---------------------|---------------|
| Date of Purchase: | Dealer Name: | Phone: |
| | | |

Vehicle Serial Number:

| | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|

Engine Serial Number:

| | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|
| | | | | | | | | | | | | |
|--|--|--|--|--|--|--|--|--|--|--|--|--|

TABLE OF CONTENTS

| | Page |
|---|------|
| Safety Signs | |
| Safety-Alert Symbol..... | 1 |
| Machine Safety Labels | 1 |
| Certification Label..... | 3 |
| | |
| Controls | |
| Throttle–Choke Lever | 4 |
| Key, PTO Knob, Shift Lever..... | 4 |
| Mower Lift Lever And Park Brake Lever | 5 |
| Brake Pedal | 5 |
| Free-Wheeling Lever (Hydrostatic Only) | 6 |
| | |
| Operating | |
| Operate Safely..... | 7 |
| Park Safely | 7 |
| Rotating Blades Are Dangerous - Protect Children And Prevent Accidents | 8 |
| Avoid Tipping..... | 9 |
| Operator Training Required..... | 9 |
| Keep Riders Off | 10 |
| Wear Appropriate Clothing | 10 |
| Transport Safely | 10 |
| Adjusting Seat..... | 11 |
| Locking And Unlocking The Park Brake | 11 |
| Starting Engine | 12 |
| Idling Engine..... | 14 |
| Stopping Engine | 14 |
| Traveling Forward And Traveling In Reverse (Hydrostatic)... | 15 |
| Traveling Forward And Traveling In Reverse (5-Speed) | 16 |
| Changing Forward Speeds (Shift On The Go) (5-Speed)..... | 18 |
| Stopping The Tractor | 19 |
| Emergency Stopping Or Parking Tractor..... | 19 |
| Using Front Weights | 20 |

TABLE OF CONTENTS

| | Page |
|--|------|
| Operating (Continued) | |
| Pushing The Tractor (5-Speed)..... | 21 |
| Pushing The Tractor (Hydrostatic)..... | 21 |
| Transporting..... | 22 |
| Avoid Damage To Plastic And Painted Surfaces..... | 22 |
| Daily Operating Checklist..... | 23 |
| Testing Safety Systems..... | 23 |
| | |
| Operating The Mower | |
| Check Ground Conditions..... | 28 |
| Avoid Injury From Contacting Blades..... | 28 |
| Operate Mower Safely (On Slopes)..... | 29 |
| Operate Mower Safely (When Children Are Present)..... | 30 |
| Operate Mower Safely (General Operation)..... | 30 |
| Using Mower Lift Lever..... | 31 |
| Adjusting Cutting Height..... | 32 |
| Adjusting Mower Level (Side-To-Side)..... | 32 |
| Adjusting Mower Level (Front-To-Rear)..... | 34 |
| Engaging Mower..... | 35 |
| Disengaging Mower..... | 37 |
| | |
| Lawn Care | |
| Mowing Tips..... | 38 |
| Trimming Tips..... | 39 |
| To Help Avoid Scalping..... | 39 |
| After Mowing..... | 40 |
| Bagging And Composting..... | 40 |
| | |
| Replacement Parts | |
| WE RECOMMEND JOHN DEERE quality parts and lubricants, available at your John Deere dealer..... | 42 |

TABLE OF CONTENTS

| | Page |
|--|------|
| Service Machine Safely | |
| Practice Safe Maintenance..... | 43 |
| Wear Appropriate Clothing | 43 |
| Handling Waste Product And Chemicals..... | 44 |
| Service Interval Chart | |
| Service Intervals | 45 |
| Service Record | 47 |
| Service - Engine | |
| Avoid Fumes..... | 48 |
| Engine Oil | 48 |
| Checking Engine Oil Level..... | 49 |
| Changing Engine Oil..... | 50 |
| Changing Engine Oil Filter..... | 52 |
| Cleaning Air Intake Screen..... | 53 |
| Cleaning Engine Fins..... | 54 |
| Checking And Cleaning Air Cleaner Element..... | 55 |
| Checking Spark Plug | 57 |
| Fuel Shut Off Valve..... | 58 |
| Replacing Fuel Filter..... | 59 |
| Adjusting Carburetor..... | 60 |
| Service - Transmission | |
| Hydrostatic Transmission Oil..... | 61 |
| Checking Hydrostatic Transmission Oil | 61 |
| Checking Gear Transmission | 62 |
| Service - Electrical | |
| Cleaning Or Replacing Battery | 63 |
| Checking Battery Electrolyte Level..... | 66 |
| Charging The Battery..... | 67 |
| Charging Rates..... | 69 |
| Using Booster Battery..... | 70 |

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com