


550 and 660 PTO Tillers for 50 and 55 Series Compact Utility Tractors

(Serial No. 150001 –)



OPERATOR'S MANUAL

**John Deere
Lawn & Grounds Care Division
OMM128097 F6**

North American Version
Litho in U.S.A
English

INTRODUCTION

THANK YOU for purchasing a John Deere product.

If you purchased the **550 Tiller** it can be mounted on the following John Deere (or similar) tractors:

- **650, 655, 670, 750, 755, 770, 850, 855, 870, 950, 955, and 970** series tractors.

If you purchased the **660 Tiller** it can be mounted on the following John Deere (or similar) tractors:

- **850, 870, 900HC, 950, 955, 970, 1050, and 1070** series tractors.

Read this manual and your vehicle manual thoroughly. Failure to do so could result in personal injury or equipment damage.



This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.

Measurements in this manual are metric units and their U.S. customary equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (- - - ➔) it indicates the part it is pointing to is hidden.

Product warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The product warranty is explained on the warranty certificate you received from your dealer.

INTRODUCTION

Record identification numbers below. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also need to give these numbers to your dealer when you order parts.

Date of Purchase: <div style="border-bottom: 1px solid black; height: 20px; margin-top: 5px;"></div>	Dealer Name: <div style="border-bottom: 1px solid black; height: 20px; margin-top: 5px;"></div>	Phone: <div style="border-bottom: 1px solid black; height: 20px; margin-top: 5px;"></div>
--	---	---




TABLE OF CONTENTS

	Page
Safety Signs.....	1
Preparing the Vehicle	3
Installing the Tiller	5
Removing the Tiller.....	7
Operating	8
Replacement Parts.....	16
Service Machine Safely.....	17
Service - Lubrication.....	19
Service	27
Troubleshooting.....	31
Storage.....	33
Assembly	35
Specifications	42
Index.....	44
John Deere Service Literature	47

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.


COPYRIGHT© 1996
John Deere Horicon Works
All rights reserved
Previous Editions
COPYRIGHT© 1991, 1987, 1984

SAFETY SIGNS

Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.



On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards. In this manual, the word CAUTION and this symbol call attention to safety messages.



Machine Safety Labels



One on each side of tiller frame



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com