


**Compact Utility Tractor with
Hydrostatic Transmission
Model 4100** Serial No. (110001 -)



OPERATOR'S MANUAL

**John Deere
Worldwide Commercial And
Consumer Equipment Division
OMM134969 K7**


**North American Version
Litho in U.S.A.**

English

INTRODUCTION

THANK YOU for purchasing a John Deere product.

Read this manual and your attachment manuals thoroughly. Failure to do so could result in personal injury or equipment damage.



WARNING: The Engine Exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

CALIFORNIA Proposition 65 Warning

This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.

Measurements in this manual are metric units and their U.S. customary equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (---->), it indicates the part it is pointing to is hidden.

Record identification numbers below. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also need to give these numbers to your dealer when you order parts.

DATE OF PURCHASE: _____

DEALER NAME: _____

DEALER PHONE: _____

Engine Serial Number:

----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------

Machine Product Identification Number:

----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------	----------------------




TABLE OF CONTENTS

Safety Signs	1
Controls	5
Operating Machine	7
Replacement Parts	48
Service Machine Safely	49
Service Interval Chart	50
Service Engine	53
Service Transmission	71
Service Electrical	77
Service Miscellaneous	84
Troubleshooting	92
Storing Machine	97
Assembly	99
Specifications	102
Warranty	112
Index	117
John Deere Service Literature	125

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT©1997

John Deere Horicon Works


All rights reserved

SAFETY SIGNS

Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.

On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards. In this manual, the word CAUTION and this symbol call attention to safety messages.



Machine Safety Labels

Avoid crushing injuries:

- DO NOT jump if machine tips.
- Use machine seat belt.



Avoid injury from tipover:

- Drive up and down slopes, not across.
- Avoid sudden stops.
- If machine stops going uphill, stop blades and back down slowly.



SAFETY SIGNS

Avoid injury to children:

- STOP mower when children are near.
- DO NOT mow in reverse.
- Look behind machine when backing.
- Never carry riders, especially children.



Avoid injury to operator and bystanders:

- Read operator's manual before operating this tractor.
- Keep all shields in place.
- Hitch towed loads only to drawbar to avoid rearward upset.
- Make certain everyone is clear of machine before starting engine or operation.
- Keep all riders off tractor and equipment.
- Keep hands, feet and clothing away from power-driven parts.
- Use seat belt. Extend belt completely from any wind-up device before adjusting to fit.
- Reduce speed when turning or applying individual brakes or operating around hazards, on rough ground or steep slopes.
- Use flashing warning lights on highway unless prohibited by law.
- Stop engine, lower implement to ground, shift to "N" neutral and set park brake securely before dismounting.
- Wait for all movement to stop before servicing machinery.
- Remove key if leaving tractor unattended.



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com