

Sabre Yard Tractors

1842GV and 1842HV

1848GV and 1848HV

Serial No. (020,001-)



OPERATOR'S MANUAL


John Deere
Worldwide Commercial And
Consumer Equipment Division
OMM138147 J8

North American Version
Litho in U.S.A.
English

INTRODUCTION

THANK YOU for purchasing a John Deere product.

Read this manual and your attachment manual thoroughly. Failure to do so could result in personal injury or equipment damage.



WARNING: The Engine Exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

CALIFORNIA Proposition 65 Warning

This manual should be considered a permanent part of your machine and should remain with the machine when you sell it.

Product warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The product warranty is explained on the warranty certificate you received from your dealer.

Measurements in this manual are metric units and their U.S. customary equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (----->), it indicates the part it is pointing to is hidden.


Record identification numbers below. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also need to give these numbers to your dealer when you order parts.

DATE OF PURCHASE: _____

DEALER NAME: _____

DEALER PHONE: _____

Sabre® is a registered trademark of Deere & Company



INTRODUCTION

Vehicle Serial Number:

□	□	□	□	□	□	□	□	□	□	□	□	□
---	---	---	---	---	---	---	---	---	---	---	---	---

Located on Rear of Tractor



Briggs & Stratton Engine Information

Model	Type	Code
□□□□□□	□□□□□□	□□□□□□□□

Located on Engine




TABLE OF CONTENTS

Assembly	1
Safety Signs.....	8
Controls	11
Operating the Machine	13
Operating the Mower	30
Replacement Parts	37
Service Machine Safely	39
Service Interval Chart.....	41
Service Engine	43
Service Transmission.....	48
Service Mower	49
Service Electrical	56
Service Miscellaneous.....	61
Removing Mower	69
Installing Mower	71
Troubleshooting	72
Storing Machine.....	77
Specifications.....	80
Warranty	83
Index.....	89
Service Literature	93

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1998
Deere & Co.

John Deere Worldwide Commercial and
Consumer Equipment Division
Horicon, WI

All rights reserved
Previous Editions
COPYRIGHT© 1997


OMM138147 J8

ASSEMBLY

1842GV and 1842HV Only - Box of Parts

NOTE: *If you are missing any parts see the Replacement Parts section for additional service part numbers.*

A	Sabre Operator's Manual Safety Video	M135884 M134321
B	Steering Wheel	AM121918
C	Bag of Hardware	H63686
	• 1 - Shoulder bolt-Steering Wheel	M87404
	• 1 - Nut- Steering Wheel	M63662
	• 1 - Washer- Steering Wheel	24H1721
	• 2 - M8x16 Bolts- Battery	19M7775
	• 2 - M8x16 Nut- Battery	14M7303
	• 2 - Keys	M127340



Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com