
Utility Vehicle ProGator®

2020 Serial No. (010001 -)

2030 Serial No. (010001 -)



OPERATOR'S MANUAL

John Deere Worldwide Commercial And Consumer Equipment Division OMM141589 J9

INTRODUCTION


THANK YOU for purchasing a John Deere product.

Read this manual thoroughly. Failure to do so could result in personal injury or equipment damage.



WARNING: The Engine Exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

CALIFORNIA Proposition 65 Warning




Measurements in this manual are metric units and their U.S. customary equivalents. RIGHT-HAND and LEFT-HAND sides are determined by facing in the direction the machine will travel when going forward. When you see a broken line arrow (----->), it indicates the part it is pointing to is hidden.

Product warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The product warranty is explained on the warranty certificate you received from your dealer.

Record identification numbers below. Be sure to record all the numbers to help in tracing the machine if it is stolen. You also need to give these numbers to your dealer when you order parts.

DATE OF PURCHASE:	
DEALER NAME:	
DEALER PHONE:	
PRODUCT IDENTIFICATION NUMBER	(A):
ENGINE SERIAL NUMBER (B):	






TABLE OF CONTENTS

Safety Signs
Controls
Operating
Replacement Parts
Service Machine Safely
Service Interval Chart
Service-Engine
Service-Transmission
Service-Hydraulics
Service-Steering & Brakes
Service-Electrical
Service-Miscellaneous
Troubleshooting
Storing Machine
Assembly
Specifications
Warranty
Index
Service Literature 97

All information, illustrations and specifications in this manual are based on the latest information at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT© 1999

Deere & Co.
John Deere Worldwide Commercial and
Consumer Equipment Division
Horicon, WI
All rights reserved


OMM141589 J9

SAFETY SIGNS

Safety-Alert Symbol

Read and recognize safety information. Be alert to the potential for personal injury when you see this safety-alert symbol.

On your machine safety labels, the words DANGER, WARNING, and CAUTION are used with this safety-alert symbol. DANGER identifies the most serious hazards. In this manual, the word CAUTION and this symbol call attention to safety messages.




Machine Safety Labels

WARNING


RIDERS CAN FALL OFF AND BE KILLED

- · Maximum of one person to a seat
- · No riders in box or anywhere else



CAUTION

Read operator's manual. Before leaving machine: Stop engine, set park brake and remove key.




SAFETY SIGNS

WARNING-HOT SURFACE

Picture Note: "HOT" muffler warning stamped into the top of the vehicle muffler.


DO NOT touch the vehicle muffler, it may be hot.



WARNING

USE SEAT BELT


To avoid injury from crushing always wear seat belt. Do not jump from machine.



WARNING

Picture Note: Labels are located on each vehicle frame side rail.

Avoid injury from crushing: Always use safety support when working on a raised bed or attachment.



Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com