

826 and 1032 Snowblowers

(Serial No. 525,001 -)



OPERATOR'S MANUAL

John Deere
Lawn & Grounds Care Division

OMM89489 C5

Introduction

Thank you for purchasing a John Deere Snowblower.

Read This Manual carefully to learn how to operate and service your snowblower correctly. Failure to do so could result in personal injury or equipment damage.

This manual should be considered a permanent part of your snowblower and should remain with the snowblower when you sell it.

Measurements in this manual are U.S. units and their metric equivalents.

Right-Hand and Left-Hand sides of the snowblower are determined by facing in the direction the snowblower will travel when going forward.

Write Serial Number of your snowblower in the Specifications section. Your dealer needs this number when you order parts.

If A Problem Should Arise or if you have any questions about your snowblower, see your John Deere dealer.

Warranty is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual.

The warranty does not cover:

A—Products which have been altered or modified in ways not approved by John Deere, including setting fuel delivery above specifications or otherwise overpowering of products.

B—Depreciation or damage caused by normal wear, accident, lack of reasonable and necessary maintenance as specified in this manual, improper maintenance, improper protection in storage, or improper use or abuse.

C—Normal maintenance and replacement of service items such as filters, spark plugs, belts, brake linings, cutting blades and hoses unless such items are defective.

D—Transportation, mailing and service call charges for warranty service.



1032 Snowblower

All information, illustrations, and specifications in this manual are based on the latest product information available at the time of publication. The right is reserved to make changes at any time without notice.

Dealer Checklists

Owner's Name _____ Date Sold _____
Address _____ Snow Blower Model _____
City _____ Snow Blower Serial Number _____
State _____ Zip _____ Engine Serial Number _____

6A8; M23;INCA A 200384

PREDELIVERY CHECKLIST

- | | |
|---|---|
| <input type="checkbox"/> 1. Guards and shields fastened in place. | <input type="checkbox"/> 7. Add fuel. Start engine. Test drive. |
| <input type="checkbox"/> 2. Decals fastened and legible. | <input type="checkbox"/> 8. Controls operate correctly. |
| <input type="checkbox"/> 3. Tire pressure. | <input type="checkbox"/> 9. Touch up scratches in snow blower finish. |
| <input type="checkbox"/> 4. Lubrication points. | <input type="checkbox"/> 10. Clean and polish snow blower. |
| <input type="checkbox"/> 5. Gearbox oil level. | |
| <input type="checkbox"/> 6. Engine oil level. | |

Date Set Up

Signature

6A8; M23;INCA B 250484

Dealer Checklists

DELIVERY CHECKLIST

Review the operator's manual with the customer. Explain the following:

- | | |
|---|--|
| <input type="checkbox"/> 1. John Deere warranty. | <input type="checkbox"/> 9. Servicing the snow blower regularly and correctly. |
| <input type="checkbox"/> 2. Safe operation and service. | <input type="checkbox"/> 10. John Deere parts and service. |
| <input type="checkbox"/> 3. How to use controls. | <input type="checkbox"/> 11. Have the customer write machine numbers in the Specifications section. |
| <input type="checkbox"/> 4. Operating the snow blower correctly. | <input type="checkbox"/> 12. Remove and file this page. |
| <input type="checkbox"/> 5. Correct fuel and lubricants. | <input type="checkbox"/> 13. Give the customer the operator's manual. Encourage the customer to read the manual. |
| <input type="checkbox"/> 6. Troubleshooting the snow blower. | |
| <input type="checkbox"/> 7. Daily and periodic inspections. | |
| <input type="checkbox"/> 8. Changing engine oil after first 2 hours of operation. | |

Date Delivered

Signature

6A8; M23;;INCA C 200184

Contents

| | Page | | Page |
|--------------------------------------|------|---|------|
| Safety | 2 | Troubleshooting | 25 |
| Controls | | Periodic Service Chart | |
| Hand Controls | 8 | Using Service Records | 29 |
| Engine Controls | 8 | Removing and Installing Bottom Shield | 29 |
| Differential Lock Wing Nut | 9 | Service Intervals | |
| Spout Control | 9 | 5 Hours | 29 |
| Prestarting Checks | 10 | 10 Hours | 30 |
| Operating The Engine | | 25 Hours | 30 |
| Manual Starting | 11 | Yearly | 30 |
| Electric Starting | 12 | Service/5 Hours | |
| Warming Engine | 14 | Checking Engine Oil Level | 31 |
| Stopping Manual-Start Engine | 14 | Service/10 Hours | |
| Stopping Electric-Start Engine | 15 | Checking Gearbox Oil Level | 32 |
| Operating The Snow Blower | | Lubricating Drive Disk Shaft | 33 |
| Before Using Snow Blower | 16 | Service/25 Hours | |
| Checking Safety Levers | 16 | Changing Engine Oil | 34 |
| Adjusting Spout | 17 | Service/Yearly | |
| Adjusting Chute | 18 | Checking Spark Plug | 35 |
| Adjusting Skids | 18 | Checking Ignition Points | 35 |
| Adjusting Handlebar Height | 18 | Cleaning Gas Tank | 36 |
| Traveling Forward | 18 | Checking Tire Pressure | 36 |
| Traveling in Reverse | 19 | Checking Drive Belts | 36 |
| Locking Differential | 20 | Service/As Necessary | |
| Stopping and Parking | 20 | Lubricating Hex Shaft | 39 |
| Emergency Stopping | 21 | Lubricating Drive Chains | 39 |
| Snow Blowing Tips | 21 | Adjusting Travel Selector Rod | 39 |
| Fuels and Lubricants | | Adjusting Clutch Control Rod | 40 |
| Fuel | 22 | Adjusting Auger Drive Rod | 41 |
| Engine Oil | 22 | Adjusting Throttle Cable | 41 |
| Grease | 23 | Adjusting Carburetor | 43 |
| Gearbox Oil | 23 | Cleaning Gas Tank Cap Vents | 44 |
| Cold Weather Operation | 23 | Storage | 45 |
| Alternative Lubricants | 24 | Accessories | 48 |
| | | Assembly | 49 |
| | | Specifications | |
| | | Snow Blower Specifications | 55 |
| | | Serial Numbers | 56 |

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com