

**TRS24, TRX24,
TRS26, and TRX26
Walk-Behind
Snowblowers**
(Serial No. 100,001—)

John Deere Horicon Works

OMM95308 Issue F0

**(Mark old manual OMM79630, Issue J9 for
machines up to Serial No. 99,999.)**

LITHO IN U.S.A.
ENGLISH

Introduction

THANK YOU for purchasing a John Deere product.

READ THIS MANUAL carefully to learn how to operate and service your snowblower correctly. Failure to do so could result in personal injury or equipment damage.

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your snowblower and should remain with the snowblower when you sell it.

MEASUREMENTS in this manual are U.S. customary units and their metric equivalents.

RIGHT AND LEFT sides are determined by facing in the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS in the Specifications section. Accurately record all the numbers to help trace the snowblower if it is stolen. Your dealer also needs these numbers when you order parts. File numbers in a safe place.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty supplied with your snowblower may not apply outside the U.S.



TRS26 Snowblower

M62529 -JUN-21JUL89

Contents

	Page
Safety	1
Controls	8
Operating the Engine	10
Operating the Snowblower	13
Fuels and Lubricants	20
Troubleshooting	22
Service	24
Storage	42
Assembly	43
Specifications	48
Index	

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

OMM95308 F0-19-05JUN90


COPYRIGHT© 1990
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright 1989 Deere & Company

Safety

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



O53,ALERT -19-26JAN90

T81389 -UN-07DEC68

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



O53,SIGNAL -19-26JAN90


TS187 -19-30SEP88

FOLLOW SAFETY INSTRUCTIONS

Carefully read all safety messages in this manual and on your snowblower safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs.

Learn how to operate the snowblower and how to use controls properly. Do not let anyone operate the snowblower without instruction.

Keep your snowblower in proper working condition. Unauthorized modifications to the snowblower may impair the function and/or safety and affect snowblower life.



MX,SAEL,A -19-05JUN90

M73113 -UN-06DEC89



INSPECT SNOWBLOWER REGULARLY

Check hardware often. Keep it tight.

Keep snowblower clean.

Replace missing parts.

Repair damaged or badly worn parts.

Guards and shields must be in good condition and fastened in place.

Make adjustments before you operate.

MX,SAEL,B -19-05JUN90

PROTECT FROM THROWN OBJECTS

Before snow falls clear work area of objects that might be picked up and thrown by snowblower.


Keep people and pets out of work area.

Do not blow snow toward people, cars, or buildings.

Be extremely careful if you must clear snow from a gravel path:

—Adjust skids lower so scraper blade is well above gravel.

—Be aware that snowblower may pick up gravel in snow. Adjust spout angle carefully to blow this snow safely.



IM41423 -UN-30AUG88

MX,SAEL,C -19-05JUN90

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com