



**NO. 650 SERIES  
TRACTOR DRAWN  
TOOL CARRIER  
WITH TOOL EQUIPMENT**




**JOHN DEERE**

**OPERATORS MANUAL  
NO. 650 SERIES TRACTOR DRAWN  
TOOL CARRIER WITH TOOL  
EQUIPMENT**

OMN261058 J8 English

**OMN261058 J8**

LITHO IN THE U.S.A.  
ENGLISH



## TO THE PURCHASER

This Operator's Manual has been carefully prepared and illustrated to provide the necessary information regarding installation, operation and adjustments so that you may obtain maximum service and satisfaction from your new 650 Series Tool Carrier.

**STUDY THIS MANUAL CAREFULLY AND KEEP IT IN A SAFE PLACE FOR FUTURE REFERENCE.**



If you find that you require information not covered in this manual, consult your John Deere dealer. He will be glad to answer any question that may arise regarding the operation of your tool carrier. Your John Deere dealer has trained mechanics who are kept informed on the best service methods and will render you prompt service if needed.

Occasionally, your tool carrier may need new parts to replace worn parts. If you will furnish your dealer the description and the information which should be recorded at the bottom of this page when the tool carrier is delivered, he can give you prompt and efficient part service.

### JOHN DEERE 650 SERIES TOOL CARRIER

No. of Tool Carrier.....

Date of Purchase.....19.....

*(To be filled in by Purchaser)*

## TABLE OF CONTENTS

	<i>Page</i>
IDENTIFICATION OF PARTS.....	2-3
SPECIFICATIONS.....	4-5
OPERATION AND ADJUSTMENT.....	6-9
Power-Lift Depth Adjustment.....	6
Powr-Trol Depth Adjustment.....	7
Installation of Hydraulic Cylinder.....	7
Transporting Powr-Trol Tool Carrier.....	7
Removal of Hydraulic Cylinder.....	8
Clutch Trip Lever Adjustment.....	8-9
EXTRA EQUIPMENT.....	10-11
Rolling Coulters.....	10
Gauge Wheels.....	10
Hinge Bracket.....	10
Drawbar—for Rod Weeders, Grain Drills and Similar Equipment	11
MAINTENANCE SUGGESTIONS.....	11
ASSEMBLY INSTRUCTIONS.....	12-49
Shipping Bundles.....	12-14
ASSEMBLY—POWER-LIFT TOOL CARRIER.....	15-20
Frame.....	15
Hitch Frame Brace, Lever, and Tie Bars.....	16
Power-Lift Axle, Clutch, and Tie Bars.....	17
Wheels and Power-Lift Depth Adjusting Levers.....	18
Lift Spring and Trip Rope.....	19
Outer Tie Bars.....	20
ASSEMBLY—POWR-TROL TOOL CARRIER.....	21-29
Frame.....	21
Hitch Frame Brace and Powr-Trol Rockshaft.....	22
Powr-Trol Rockshaft and Cross Brace.....	23
Tie Bars and Axles.....	24
Axle Lift Shafts and Lift Pipes.....	25
Wheels and Outer Tie Bars.....	26
Truss Rods and Hydraulic Cylinder Anchor.....	27
Hydraulic Cylinder.....	28
Leveling Tool Carrier.....	29
ASSEMBLY—WHEEL, TIE BAR AND STANDARD SPACING	30-48
No. 651H Powr-Trol Tool Carrier.....	30
No. 652H Powr-Trol Tool Carrier.....	33
No. 652 Power-Lift Tool Carrier.....	36
No. 656H Powr-Trol Tool Carrier.....	39
No. 656 Power-Lift Tool Carrier.....	44
ASSEMBLY—SAFETY REFLECTORS AND WARNING LAMP SOCKET.....	49




Figure 1—No. 652H—12-Foot Power-Trol Tool Carrier with TE-6 Equipment

61325




Figure 2—No. 656—16-Foot Power-Lift Tool Carrier with TE-4 Equipment

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)