

**4230 SERIES
ROW-CROP
CULTIVATOR FOR
MODEL "40" TWO-ROW
UTILITY TRACTOR**



JOHN DEERE

OPERATORS MANUAL

4230 SERIES ROW-CROP CULTIVATOR
FOR MODEL "40" TWO-ROW UTILITY
TRACTOR

OMN34255 (01FEB55) English

OMN34255 (01FEB55)

LITHO IN THE U.S.A.
ENGLISH



YOUR NEW CULTIVATOR

Behind your new cultivator is an organization that has designed and built farm implements for over 115 years. This cultivator was built in a John Deere Factory by experienced men, thus assuring the utmost in design, high-grade workmanship, and thorough inspection, so essential to the production of good cultivators.

High quality materials, precision production methods, and accurately controlled heat-treating assure maximum strength and long life for every part.

This manual has been carefully prepared and illustrated so that you may make the necessary adjustments for adapting your cultivator to work properly in all types of field cultivation. These adjustments such as row spacing and proper leveling of shovels or sweeps are fully covered in this manual. Study the manual carefully and make it your guide.

Occasionally your cultivator may need new parts to replace worn parts or emergency service may be required that is not covered in this manual. If so, we suggest that you take advantage of the facilities offered by your John Deere dealer; which assures you of genuine John Deere parts or other prompt "know-how" service in the field or shop.

If you will furnish your dealer the part number, description, and the information which should be recorded at the bottom of this page, when the cultivator is delivered, he can give you prompt and efficient service.

**JOHN DEERE 4230 SERIES ROW-CROP
CULTIVATOR**

No. of Cultivator

Date Purchased 19.....

(To be filled in by Purchaser)

TABLE OF CONTENTS

	<i>Page</i>
IDENTIFICATION OF CULTIVATOR PARTS.....	2-3
SPECIFICATIONS.....	4
OPERATION.....	5-19
Preparing the Tractor.....	5
Rockshaft Lift Arms.....	6
Depth Control and Height of Lift.....	7
Leveling Front Rigs.....	7
Tilting Front Rigs.....	8
Rig Clamp.....	8
Adjusting Crossarms.....	9
Leveling Shovels or Sweeps.....	10
Adjusting Shank Vertically.....	10
Leveling Sweep Wings.....	10
Spring Trips.....	11
Attaching Cultivator.....	12-15
Detaching Cultivator.....	16-17
Row Spacing.....	18
Shields.....	19
EXTRA EQUIPMENT.....	20
Disk Hillers.....	20
Knife Attachment.....	20
MAINTENANCE SUGGESTIONS.....	22
Shovels and Sweeps.....	22
Sharpening Shovels and Sweeps.....	22
Lubrication.....	22
Rigs.....	22
Tractor Tire Inflation Pressures.....	22
ASSEMBLY.....	23-49
General Instructions.....	23
Overhead View of Cultivators and Shipping Bundles.....	24-37
Extra Shipping Bundles.....	38
Setting Tractor Rear Wheels.....	39
Coupling Fork and Frame.....	40
Quik-Tatch Frame.....	41
Front Rigs.....	42
Lift Shaft and Lift Pipe.....	43
Rear Rigs.....	44
Overhead View of 4232 Cultivator.....	45
Shields.....	46
Setting the Cultivator Correctly.....	48-49




Figure 1—John Deere 4232 Power Lift Row-Crop Cultivator
(Tractor Wheel Removed to Show Cultivator Detail)




Figure 2—Front View—John Deere 4232 Cultivator

43664

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com