



800 INTEGRAL TOOL BAR



JOHN DEERE

OPERATORS MANUAL 800 INTEGRAL TOOL BAR

OMN97517 K0 English



OMN97517 K0

LITHO IN THE U.S.A.
ENGLISH

TO THE PURCHASER

This Operator's Manual has been carefully prepared and illustrated to provide the necessary information regarding installation, operation, and adjustments so that you may obtain maximum service and satisfaction from your new 800 Series Tool Bar.

STUDY THIS MANUAL CAREFULLY AND KEEP IT IN A SAFE PLACE FOR FUTURE REFERENCE.



If you should find that you require information not covered in this manual, consult your John Deere dealer. He will be glad to answer any question that may arise regarding the operation of your tool bar. Your John Deere dealer has trained mechanics who are kept informed on the best service methods and will render you prompt service if needed.

Occasionally, your tool bar may need new parts to replace worn parts. If you will furnish your dealer the description and the information which should be recorded at the bottom of this page when the tool bar is delivered, he can give you prompt and efficient parts service.

**JOHN DEERE 800 SERIES
TOOL BAR**

No. of Tool Bar.....

Date Purchased..... **19**.....

(To be filled in by purchaser)

TABLE OF CONTENTS

	<i>Page</i>
IDENTIFICATION OF PARTS.....	2-3
DESCRIPTION.....	3
SPECIFICATIONS.....	4
OPERATION AND ADJUSTMENT.....	5-7
ASSEMBLY INSTRUCTIONS.....	8-9
Shipping Bundles.....	8
Special Equipment.....	8
Spring Teeth Spacing.....	9

Be Careful



THE LIFE YOU SAVE MAY BE YOUR OWN...

NATIONAL SAFETY COUNCIL




Figure 1—818 Integral Tool Bar with TB203 Equipment

SPECIFICATIONS

TOOL BAR.

The 818 Single Bar is a 84- x 2-inch square solid bar.

ATTACHMENT FOR 818 SINGLE TOOL BAR.

TB203—Coil Spring Tooth Attachment (7 spring teeth and Y850AN double-point chisels)—Regular equipment.

EQUIPMENT.

Six-, eight-, ten-, twelve-, and fourteen-inch sweeps or 11-inch heavy-duty chisels available as special equipment.

LIFT.

Tool bar is raised and lowered by the tractor hydraulic system.

WEIGHTS.

No added weights are required when using this tool bar.

TRACTORS.

This tool bar can be used on John Deere 1010, 435, 330, 430, 320, 420, and 40 Row-Crop, Standard, and Utility Tractors and other comparable tractors with 3-point hitch.

USE OF 818 TOOL BAR AS REAR CULTIVATOR RIG.

The 818 Tool Bar can serve as an 82, 83, or 88 rear rig section of a row-crop cultivator by ordering the necessary standards and shanks.

(Specifications and design subject to change without notice.)

NOTE: Right- and left-hand, referred to in this manual are determined from a position at the rear of the machine facing in the direction of travel.

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com