

## 205 Corn Attachment



## **OPERATORS MANUAL**

205 Corn Attachment

OMN97525 (01APR61) English

OMN97525 (01APR61)

LITHO IN U.S.A. ENGLISH



## TO THE PURCHASER

This manual contains useful information on how to operate your new John Deere 205 Corn Attachment.

A corn attachment must be built to handle a wide range of conditions. Average conditions can be handled by the 205 Corn Attachment with regular equipment. Unusual conditions can be handled by installing special equipment.


Field conditions vary from year to year, from day to day, and even from hour to hour. Different varieties of corn present widely different picking problems. A careful study of adjustments on your corn attachment and what they accomplish under varying conditions will allow you to reap many benefits and economies that a corn attachment can provide.

Your new corn attachment will do quality work in direct proportion to the care you use in operating it. Operate and service the attachment according to the instructions in this manual.

If you need information not covered in this manual, see your John Deere dealer. He has the latest information on how to get the best service from your corn attachment and can give you prompt service in the field or in his shop.

When in need of parts, go to your John Deere dealer. He carries genuine John Deere parts for your 205 Corn Attachment.

Be prepared to give him the serial number of your corn attachment and the year purchased. This information should be recorded below on this page as soon as you have received your corn attachment.




| Serial Number  | ٠. | <br>٠. |  |  |  |  |  | <br> |  |      |      |  |
|----------------|----|--------|--|--|--|--|--|------|--|------|------|--|
| Date Purchased | ٠. | <br>   |  |  |  |  |  | <br> |  | <br> | <br> |  |


You will find the serial number plate on the lefthand main frame as illustrated above.

## **CONTENTS**

|                                                  | Page  |
|--------------------------------------------------|-------|
| SPECIFICATIONS                                   | 4     |
| OPERATION                                        | 5-14  |
| General Instructions                             | 5     |
| Gatherers                                        | 6-8   |
| Stalk Rolls                                      | 9     |
| Trash Knives                                     | 9     |
| Snapping Bar                                     | 10    |
| Conveyor Augers and Trash Mover                  | 11    |
| Roller Chains                                    | 12    |
| Slip Clutch                                      | 12    |
| Safety Stand                                     | 13    |
| Safety Suggestions                               | 13    |
| Suggested Combine Settings for Combining Corn    | 13    |
| Combine Cylinder Speeds and Main Drive Sprockets | 14    |
| LUBRICATION                                      | 15–17 |
| PICKING DIFFICULTIES                             | 18-20 |
| REMOVING CORN ATTACHMENT                         | 21-24 |
| INSTALLING CORN ATTACHMENT                       | 25-36 |
| SERVICE                                          | 37–38 |
| ASSEMBLY                                         | 39-42 |



John Deere 205 Corn Attachment on 40 Self-Propelled Combine



John Deere 205 Corn Attachment on 40 Self-Propelled Combine

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com