730 Series Hi-Crop Tractor (Gasoline, All-Fuel, LP Gas and Diesel) (Serial No. 7300000 and Up)



# **OPERATORS MANUAL**


730 Series Hi-Crop Tractor (Gasoline, All-Fuel, LP Gas and Diesel) (Serial No. 7300000 and Up)


OMR20696R F8 English



OMR20696R F8

LITHO IN U.S.A. ENGLISH





To the Purchaser

We welcome you to our ever-growing family of John Deere Tractor owners. We are confident that the dependable and economical performance of your John Deere Hi-Crop Tractor will prove that you made a wise choice.


The purpose of this manual is to acquaint you with the special features of your new Hi-Crop Tractor. Since, in most respects, it is just like a regular "730" Series Tractor, the instructions in this manual cover only those parts of your Hi-Crop Tractor which are different from the regular "730" Series Tractor.

Refer to the regular "730" Series Operator's Manual (Gasoline and All-Fuel, LP-Gas, or Diesel) which was delivered to you with your new Hi-Crop Tractor for additional information including description and location of controls, and how to start, stop, and operate your tractor with safety. Refer to the manual often for constructive and helpful suggestions on getting the most out of your Hi-Crop Tractor and keeping it running efficiently and economically.


Keep both this manual and the regular manual in a convenient place for quick and easy reference. Use them as a guide whenever questions arise. You have purchased a dependable, sturdy tractor, but only by operating and caring for it properly can you expect to receive the service and long life for which it was designed.

# • TABLE OF CONTENTS •

SPECIFICATIONS	3
Tractor Speeds	·
Dimensions	
Shipping Weight	
LUBRICATION	4-5
Final Drives 4	,
Brakes	
Grease Fittings	
TIRE INFLATION CHART	6
USING THE DRAWBAR	7
WHEEL TREAD ADJUSTMENTS	8-9
GENERAL SERVICE INFORMATION	10–13
Final Drives 10	
Drive Shafts 11	
Rear Axle Shafts 12	
Differential	



1



67 3 3 3 John Deere "730" Series Hi-Crop Tractor (Diesel)

# **SPECIFICATIONS**

Most of the specifications in the regular "730" Series Tractor Operator's Manual apply equally to your "730" Hi-Crop Tractor. The following, however, are different.

Gear	MPH with 13.6-38 Regular Tires	MPH with 13-38 Cane and Rice Tires
First	1-1/3	1-1/2
Second	2	2-1/4
Third	3-1/3	3-1/2
Fourth	4-1/4	4-1/2
Fifth	5-1/3	5-3/4
Sixth	10-1/2	11-1/2
Reverse	3-1/4	3-1/2

#### TRACTOR SPEEDS

### DIMENSIONS

### (With 13.6-38 Rear and 7.50-20 Front Tires)

Wheel Base
Over-All Height
Height to Radiator Cap
Over-All Length
Over-All Rear Width
Front Wheel Tread Adjustment
Rear Wheel Tread Adjustment60, 66, 72, 78, 84, and 90 in. Treads
Clearance
Turning Radius
Drawbar Heights15-1/4, 26-1/4, 33-1/4 in.
Power Take-Off Height

## SHIPPING WEIGHT

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email:

ebooklibonline@outlook.com