

7100 and 7200 Series Magnum Tractor

Service Manual

Table of Contents

	Description	Section No	Form No
General		Tab 1	
General Information - 7100 Series		1001*	8-91581
General Information - 7200 Series		1002*	7-60490
Loctite Product Chart			8-98900
 Engine		 Tab 2	
Engine Troubleshooting		2001	8-91600
Engine Tune-up		2002	8-91611
Engine Removal		2003	8-91621
Tractor Split between Engine and Speed Transmission		2004	8-91631
Tractor Split between Flywheel Housing and Speed Transmission for 7100 Series Transmission S/N AJB005513 and After and all 7200 Series		2004	7-61090
Air Induction System		2010	8-91691
Aftercooler System		2011	8-91701
Specification Details.....		2403*	8-28424
Cylinder Head and Valve Train		2415	8-28432
Cylinder Block		2425	8-28442
Lubrication System		2445	8-28452
Cooling System		2455	8-28462
Turbocharger		2465	8-28470
Turbocharger Failure Analysis		2565	9-78235
 Fuel System		 Tab 3	
Fuel System Specifications		3001	8-91591
Fuel Tank		3004	8-91752
Fuel System and Filters		3410	8-28480
Injection Pump		3412	8-28492
Fuel Injectors		3413	8-28501
 Electrical		 Tab 4	
Wiring Schematics and Troubleshooting Prior to P.I.N. JJA0032439		4001*	7-33230
Wiring Schematics and Troubleshooting P.I.N. JJA0032439 and After		4001E*	8-98491
Wiring Schematics and Troubleshooting - 7200E		4002E*	7-61620
Alternator		4004	8-91793
Neutral Start Switch		4005	8-91801
Starting Motor - Nippondenso 12800-5330		4011	8-95970
Starting Motor - Nippondenso 12800-4341		4230	8-25980
Battery Servicing and Testing		4235	8-20291
 Steering		 Tab 5	
Steering Column and Hand Pump		5001	8-91822
Steering Cylinder - 2 WD and MFD Tractors		5002	8-91832
Steering Axle and lines - 2 WD		5003	8-91840
Emergency Steering System		5010	8-89310

Description	Section No	Form No
Power Train	Tab 6	
Tractor Split between Speed and Range Transmission	6001	8-91851
Tractor Split for Speed Transmission Service, 7100 Series Transmission S/N AJB0055133 and After and all 7200 Series	6001	7-60630
Tractor Split between Range Transmission and Rear Housing	6002	8-91861
Tractor Split for Pinion Shaft or Range transmission Service - 7100 Series Transmission S/N AJB0055133 and After and all 7200 Series	6002	7-60720
MFD Axle Removal	6003	8-91871
Transmission Valve - Prior to Transmission S/N AJB0055133	6004	8-91882
Transmission Valve - Transmission S/N AJB0055133 and After	6004	7-60330
Speed Transmission	6005	8-91891
Speed Transmission - 7100 Series Transmission S/N AJB0055133 and After and all 7200 Series.....	6005	7-60620
Range Transmission	6006	8-91901
Range Transmission - 7100 Series Transmission S/N AJB0055133 and After and all 7200 Series.....	6006	7-60610
Hydraulic Pump Drive	6007	8-91911
Rear Frame	6008	8-91922
Rear Axle and Planetaries	6009	8-91932
PTO - Single Shaft for Models 7130 and 7140 Prior to Transmission S/N AJB00059710 and Dual Shaft PTO for all 7110 and 7120 Models	6010	8-91942
PTO - Single Shaft for 7130 and 7140 Models Transmission S/N AJB00059710 and After, All Models 7150, 7230, 7240 and 7250. Dual Shaft for all 7210 and 7220 Models	6010	7-60250
MFD Clutch Removal without Tractor Split	6011	7-60770
MFD Differential	6012	8-91961
MFD Axle and Planetaries	6013	8-91972
Brakes	Tab 7	
Brake Valve	7001	8-91981
Trailer Brake and Priority Valves	7002	7-61660
Brake Cylinders	7003	8-91952
Parking Brake	7004	7-61380
Hydraulic System	Tab 8	
Hydraulic Troubleshooting - 7100 and 7200 Series	8001*	8-92013
PTO Valve	8002	8-92021
Remote Hydraulic Circuits	8004	8-92042
Hydraulic Filters - 7100 Series	8005	8-92051
Hydraulic Filters - 7200 Series	8005	7-60780
Differential Lock and MFD Solenoid Valves	8006	8-92060
Charge and Lube Pump - 7100 Series	8007	8-91811
Charge and Lube Pump - 7200 Series	8007	7-61040
Hydraulic Pump	8008	8-91990
Electronic Hitch Alignment - 7100 Series	8009	8-92071
Electronic Hitch Alignment - 7200 Series	8009	7-60420
Three Point Hitch	8010	8-92082
Hitch Valve	8011	8-92091
Hydraulic Schematics - 7100 and 7200 Series	8012*	8-94382
Hydraulic Schematics - 7100E and 7200E Series	8012E*	8-98691

* Schematic set Sections.

Chassis	Description	Section No	Form No
		Tab 9	
	Air Conditioning Troubleshooting - 7100 Series	9001	8-92101
	Air Conditioning Troubleshooting - 7200 Series	9001	7-60380
	Air Conditioning Testing - 7100 Series	9002	8-92111
	Air Conditioning Testing - 7200 Series	9002	7-60390
	Air Conditioning System and Compressor - 7100 Series	9003	8-92121
	Air Conditioning System and Compressor - 7200 Series	9003	7-60400
	Air Conditioning Components - 7100 Series	9004	8-92131
	Air Conditioning Components - 7200 Series	9004	7-60410
	Cab Blower	9005	8-92141
	Tractor Seat Air/Oil	9006	8-92151
	Hood, Grille and Side Panels - Radiator and Support	9007	8-92161
	Decal Location - 7100 Series	9008	8-92170
	Decal Location - 7200 Series	9008	7-60820
	Cab Removal	9009	8-92180
	Pedal and Lever Adjustment	9010*	8-92192
	Tractor Seat Air/Air - 7100 Series	9011	8-95560
	Tractor Seat Air/Air - 7200 Series	9011	7-60910

* Schematic set Sections.

Section 1001

GENERAL INFORMATION

TABLE OF CONTENTS

Conversion Factors	3
General Torque Specification Table	
SAE	4
Metric	4
Hydraulic Tubes and Fittings	5
Fluid Capacities and Types	6
Engine Speeds	6
Engine Flywheel	6
Fuses	6
Bulb and Lamp Replacement	6
Steering and Oscillation Stops - MFD	7
Steering and Oscillation Stop Charts - without Fenders	8
Steering and Oscillation Stop Charts - with Fenders	8
Tire Specifications	
Front Tires	9
Rear Tires	9
Service Tools Introduced for 7100 Series	
Transmission Service	10-11
Hydraulic Test Fittings	11
MFD Axle Service	12
Electrical Testing	13

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com