1822, 1844, 2022, 2044 and 2055 Cotton Picker Service Manual

Table of Contents

	Description	Section No.	Form No.
General		Tab 1	0.00000
Loctite Product Chart Engine Specifications -	D466	1020	8-98900 8-62491
Engines - D466 Navist		Tab 2	
Engine Troubleshooting		2010	8-62231
Engine Tune-Up - D46		2015	8-27421
Engine Removal and Ir		2020	8-62190
Cylinder Head and Val	ve Irain	2030	8-27181
Cylinder Block		2040	8-27211 8-27191
Lubrication System		2060 2265	
Turbocharger - T04B	polycia All Engines	2565	8-20190 9-78235
Turbocharger Failure A Cooling System	inalysis - All Engines	2070	9-76233 8-27231
Air Induction and Exha	uet Svetom	2090	8-62510
- 6-590 C	•	2090	6-02510
Engine Specifications		2401	8-26063
Cylinder Head and Val		2415	8-26073
Cylinder Block	ro main	2425	8-26084
Lubrication System		2445	8-26093
After Cooler		2545	8-26120
Cooling System		2455	8-26103
Turbocharger 2465			8-26110
- 6-830 C	ase		
Engine Specifications	400	2403	8-28423
Cylinder Head and Val	ve Train	2415	8-28432
Cylinder Block		2425	8-28442
Lubrication System		2445	8-28452
Cooling System		2455	8-28462
Turbocharger		2465	8-28470
Fuel System - D466 N	lavistor Engines	Tab 3	
Fuel System and Filter		3010	8-27241
Fuel Injection Pump - I	Robert Bosch Type MW	3020	8-27251
Fuel Injectors		3030	8-27261
	ase Engine		
Fuel System and Filter		3410	8-26131
Fuel Injection Pump (C	CAV)	3411	8-97711
Fuel Injectors		3413	8-26152
	ase Engine		
Fuel System and Filter	S	3410	8-28480
Fuel Injection Pump		3412	8-28492
Fuel Injectors		3413	8-28501

Reprinted

1822, 1844, 2022, 2044 and 2055 Cotton Picker Service Manual

Table of Contents

Description	Section No.	Form No.
Electrical	Tab 4	
Electrical Wiring Schematics and Troubleshooting - 202		8-97551
Electrical Wiring Schematics and Troubleshooting - 205		8-98001
Electrical System Troubleshooting - 1822 & 1844	4010	8-62030
Alternator - Bosch	4004	8-91792
Instrument Cluster Troubleshooting	4011	8-62520
Starting Motor - Nippondensa	4011	8-95970
Digital Tachometer Troubleshooting	4012	8-62040
Compactor Troubleshooting	4013	8-62050
Monitor Troubleshooting	4014	8-62061
Cotton Picker Electrical Wiring Diagram - 1822 & 1844	4020	8-62070
Cab Electrical Wiring Diagram - 1822 & 1844	4025	8-62360
Electro-Hydraulic Valve Wiring Diagram - 1822 & 1844	4030	8-62080
Battery Servicing and Testing	4235	8-20291
Starter Motor - 1822 & 1844	4040	8-62530
Alternator System - Motorola	4060	8-62170
Neutral Start Switches	4070	8-62271
Steering	Tab 5	
Steering Axle - 2055	5003	8-99060
Steering System Testing	5010	8-62420
Steering Column and Hand Pump - Ross	5020	8-62430
Steering Column and Hand Pump - Eaton	5021	8-98040
Steering Cylinder	5030	8-62440
Steering Axle -1822, 1844, 2022 & 2044	5040	8-62450
Power Train	Tab 6	
Hydrostatic Propulsion Troubleshooting	6010	8-62380
Foot-N-Inch Valve	6015	8-62550
Hydrostatic Drive Pump Removal and Installation	6017	8-62280
Hydrostatic Drive Pump	6018	7-34820
Hydrostatic Drive Motor	6030	8-62471
Transmission and Drum Drive Assembly, Removal and Ir	nstallation 6035	8-62250
Transmission - 1822, 1844, 2022 & 2044	6040	8-62391
Transmission - 2055	6041	8-99050
Drum Drive Assembly - 1822, 1844, 2022 & 2044	6050	8-62091
Drum Drive Assembly - 2055	6051	8-82770
Final Drive and Pinion Assembly	6060	8-62201
Brakes	Tab 7	
Service and Parking Brake -1822, 1844, 2022 & 2044	7010	8-62211
Service and Parking Brake - 2055	7011	8-99120
Brake Valve and Cylinders	7020	8-62240

1822, 1844, 2022, 2044 and 2055 Cotton Picker Service Manual

Table of Contents

Description	Section No.	Form No.
Hydraulic	Tab 8	
Hydraulic System Schematics and Troubleshooting - 202	2 & 2044 8001	8-97560
Hydraulic System Schematics and Troubleshooting - 20	55 8002	8-98010
Hydraulic System Troubleshooting - 1822 & 1844	8010	8-62100
Hydraulic System Testing - 1822 & 1844	8020	8-62620
Hydraulic Oil Filters	8030	8-62261
Hydraulic Pump Removal and Installation	8037	8-62290
Hydraulic Pump and Compensator	8040	8-62480
Electro-Hydraulic Valves	8050	8-62111
Electro-Hydraulic Manifold Valve - 2055	8051	8-99020
Hydraulic Valves, Cylinders and Motor	8060	8-62181
Destroke Solenoid Valve	8061	8-98770
Height Control Valves and Cylinders - 2055 Model	8062	8-99110
Height Control valves and Cylinders - 2000 Model	0002	0-99110
Accessories	Tab 9	
Servicing the Air Conditioner Compressor		
Sanden Model SD 508 HD	9000	7-35200
Air Conditioner Troubleshooting	9001	7-35210
Air Conditioner System Gauges and Testing	9002	7-37680
Air Conditioner System Service, Recovery,		
Evacuation and Recharging	9003	7-34860
Air Conditioning Components Service for Systems		
with Sanden Compressor	9004	7-34890
Air Conditioner Compressor Removal and		
Installation on Navistar Engines	9030	8-62331
Servicing the York Air Conditioner Compressor		
and System Components	9040	8-62320
Servicing the Cab Blower	9050	8-62300
Operators Seat	9060	8-62310
Fan Assembly	9070	8-62221
Moistener System	9075	8-62571
Basket Assembly	9077	8-62580
Picker Drum Removal and Installation	9080	8-62120
Picker Drum Removal and Installation - 2055 Model	9081	8-99190
Chain Driven Picker Drum Service	9090	8-62130
Gear Driven Picker Drum Service	9091	8-97850
Picker Bar and Spindle Lubrication System	9092	8-98610
Drum Gearboxes and Input Drive Shafts - 2055 Model	9093	8-99100
brum dearboxes and input brive shalls - 2000 Model	9093	0-99100
How It Works	Tab 10	
Digital Tachometer	10030	8-62400
Compactor Control	10050	8-62630
Drum Operation	10070	8-62140
	, , , ,	0"02140

Thank you so much for reading. Please click the "Buy Now!" button below to download the complete manual.



After you pay.

You can download the most perfect and complete manual in the world immediately.

Our support email: ebooklibonline@outlook.com