



## SERVICE MANUAL



**AXIAL-FLOW 7120 [Y8G205001 - ]**  
**AXIAL-FLOW 8120 [Y8G205001 - ]**  
**AXIAL-FLOW 9120 [Y8G205001 - ]**

# Contents

---

## INTRODUCTION

## DISTRIBUTION SYSTEMS..... A

PRIMARY HYDRAULIC POWER SYSTEM..... A.10.A

SECONDARY HYDRAULIC POWER SYSTEM..... A.12.A

ELECTRICAL POWER SYSTEM ..... A.30.A

LIGHTING SYSTEM..... A.40.A

ELECTRONIC SYSTEM ..... A.50.A

FAULT CODES ..... A.50.A

## POWER PRODUCTION ..... B

ENGINE ..... B.10.A

FUEL AND INJECTION SYSTEM..... B.20.A

AIR INTAKE SYSTEM..... B.30.A

EXHAUST SYSTEM..... B.40.A

ENGINE COOLANT SYSTEM ..... B.50.A

LUBRICATION SYSTEM ..... B.60.A

STARTING SYSTEM ..... B.80.A

## POWER TRAIN ..... C

TRANSMISSION Mechanical ..... C.20.B

TRANSMISSION Hydrostatic..... C.20.F

FRONT PTO Mechanical ..... C.42.B

PROCESS DRIVE Primary process drive ..... C.50.B

TRANSMISSION LUBRICATION SYSTEM ..... C.90.A

## TRAVELLING..... D

FRONT AXLE ..... D.10.A

REAR AXLE ..... D.12.A

2WD-4WD SYSTEM Hydrostatic..... D.14.E

STEERING Hydraulic..... D.20.C

SERVICE BRAKE Hydraulic..... D.30.C

PARKING BRAKE Hydraulic ..... D.32.C

WHEELS AND TRACKS Tracks .....	D.50.B
WHEELS AND TRACKS Wheels.....	D.50.C
<b>BODY AND STRUCTURE .....</b>	<b>E</b>
USER CONTROLS AND SEAT .....	E.32.A
SHIELD .....	E.20.A
USER CONTROLS AND SEAT Operator seat .....	E.32.C
USER CONTROLS AND SEAT Instructor seat .....	E.32.D
USER PLATFORM .....	E.34.A
ENVIRONMENT CONTROL Heating, ventilation and air-conditioning.....	E.40.D
SAFETY SECURITY ACCESSORIES Safety .....	E.50.B
<b>TOOL POSITIONING .....</b>	<b>G</b>
LIFTING .....	G.10.A
TILTING .....	G.20.A
LEVELLING .....	G.30.A
<b>CROP PROCESSING .....</b>	<b>K</b>
FEEDING Reel feeding.....	K.25.B
FEEDING Header feeding .....	K.25.D
FEEDING Feeder housing .....	K.25.E
FEEDING Transition cone .....	K.25.K
THRESHING Axial flow threshing .....	K.40.C
SEPARATING Rotary separator .....	K.42.C
STORING AND HANDLING Grain storing .....	K.60.B
CLEANING Primary cleaning.....	K.62.B
CLEANING Tailings return system .....	K.62.C
CLEANING Self-levelling frame .....	K.62.D
RESIDUE HANDLING Straw chopper.....	K.64.C
RESIDUE HANDLING Spreader .....	K.64.D
RESIDUE HANDLING Straw beater .....	K.64.E
UNLOADING Grain unloading.....	K.72.B

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)