

# **CX220C**

## **Hydraulic Excavator**

# Service Manual

**Part Number**  
**7111451**  
1<sup>st</sup> Edition  
English 03/2015





# **SERVICE MANUAL**

**CX220C Standard model**

# Link Product / Engine

---

<b>Product</b>	<b>Market Product</b>	<b>Engine</b>
CX220C Modelo padrão	Latin America	F4GE9684E*J615

# Contents

---

## INTRODUCTION

Engine.....	10
[10.001] Engine and crankcase .....	10.1
[10.202] Air cleaners and lines .....	10.2
[10.216] Fuel tanks .....	10.3
[10.254] Intake and exhaust manifolds and muffler .....	10.4
[10.400] Engine cooling system .....	10.5
Hydraulic systems.....	35
[35.000] Hydraulic systems.....	35.1
[35.102] Pump control valves.....	35.2
[35.106] Variable displacement pump .....	35.3
[35.300] Reservoir, cooler, and filters.....	35.4
[35.304] Combination pump units .....	35.5
[35.352] Hydraulic swing system .....	35.6
[35.353] Hydraulic travel system .....	35.7
[35.354] Hydraulic central joint .....	35.8
[35.355] Hydraulic hand control .....	35.9
[35.356] Hydraulic foot control.....	35.10
[35.359] Main control valve .....	35.11
[35.736] Boom hydraulic system .....	35.12
[35.737] Dipper hydraulic system.....	35.13
[35.738] Excavator and backhoe bucket hydraulic system.....	35.14
Frames and ballasting .....	39
[39.101] Upper frame .....	39.1
[39.103] Swing ring assembly .....	39.2
[39.140] Ballasts and supports .....	39.3

<b>Tracks and track suspension .....</b>	<b>48</b>
[48.130] Track frame and driving wheels .....	48.1
[48.100] Tracks .....	48.2
[48.134] Track tension units .....	48.3
[48.138] Track rollers .....	48.4
<b>Cab climate control .....</b>	<b>50</b>
[50.100] Heating .....	50.1
[50.200] Air conditioning .....	50.2
<b>Electrical systems .....</b>	<b>55</b>
[55.000] Electrical system .....	55.1
[55.015] Engine control system .....	55.2
[55.036] Hydraulic system control .....	55.3
[55.051] Cab Heating, Ventilation, and Air-Conditioning (HVAC) controls .....	55.4
[55.302] Battery .....	55.5
[55.640] Electronic modules .....	55.6
<b>Booms, dippers, and buckets .....</b>	<b>84</b>
[84.910] Boom .....	84.1
[84.100] Bucket .....	84.2
<b>Platform, cab, bodywork, and decals .....</b>	<b>90</b>
[90.116] Fenders and guards .....	90.1
[90.124] Pneumatically-adjusted operator seat .....	90.2
[90.150] Cab .....	90.3

Thank you so much for reading.  
Please click the “Buy Now!”  
button below to download the  
complete manual.



After you pay.

You can download the most  
perfect and complete manual in  
the world immediately.

Our support email:

[ebooklibonline@outlook.com](mailto:ebooklibonline@outlook.com)