

HYDRAULIC EXCAVATOR

SHOP MANUAL

CASE CX47

INDEX

1	SPECIFICATIONS
2	MAINTENANCE
3	SYSTEM
4	DISASSEMBLING
5	TROUBLESHOOTING
6	ENGINE
7	INSTALLATION PROCEDURES FOR OPTIONAL ATTACHMENTS

MAINTENANCE SPECIFICATIONS

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

E/G

OPT

CASE

Book Code No. **S5PJ0002E** ①

00-0-1 ①

INDEX

CX47

<u>Book Code No.</u>			Title	Index No.
S5PJ0102E 2001-10		SPECIFICATIONS	PRELIMINARY REMARKS	PJ01
S5PJ0202E 2001-10			SPECIFICATIONS	PJ02
S5PJ0302E 2001-10			ATTACHMENT DIMENSIONS	PJ03
S5PJ1102E 2001-10		MAINTENANCE	TOOLS	PJ11
S5PJ1202E 2001-10			STANDARD MAINTENANCE TIME TABLE	PJ12
S5PJ1302E 2001-10			MAINTENANCE STANDARDS AND TEST PROCEDURES	PJ13
—				
S5PJ2202E 2001-10		SYSTEM	HYDRAULIC SYSTEM	PJ22
S5PJ2302E 2001-10			ELECTRICAL SYSTEM	PJ23
S5PJ2402E 2001-10			COMPONENTS SYSTEM	PJ24
—				
—				
S5PJ3102E 2001-10		DISASSEMBLING	WHOLE DISASSEMBLING & ASSEMBLING	PJ31
S5PJ3202E 2001-10			ATTACHMENTS	PJ32
S5PJ3302E 2001-10			UPPER SLEWING STRUCTURE	PJ33
S5PJ3402E 2001-10			TRAVEL SYSTEM	PJ34
—				
S5PJ4202E 2001-10		TROUBLESHOOTING	HYDRAULIC SYSTEM	PJ42
S5PJ4302E 2001-10			ELECTRICAL SYSTEM	PJ43
S5PJ4402E 2001-10			ENGINE	PJ44
S5PJ5102E 2001-10		E/G	ENGINE	PJ51
		OPT		
PJ02-00101	PH03-02001			
	PJ02-00101		APPLICABLE MACHINES	

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com