

 **NEW HOLLAND**

D150B

**Workshop
Manual**

Workshop
Manual

Print No. 87693704 A - EU
English - Printed in Italy

D150B CRAWLER

Repair Manual

87693704 A - EU

Table of Contents

Description	Section Number
General	
	Tab 1
Section Index - General	
Standard Torque Specifications	1001
Fluids and Lubricants	1002
Metric Conversion Chart	1003
Engine	
	Tab 2
Section Index- Engine	
Engine and Radiator Removal and Installation	2000
After Cooler	2003
For Engine Repair, see the Engine Repair Manual 87519804	
Fuel System	
	Tab 3
Section Index- Fuel System	
For Fuel System Repair, see the Engine Repair Manual 87519804	
Electrical	
	Tab 4
Section Index - Electrical	
Removal and Installation of Electrical Components	4001
Electrical Specifications and Troubleshooting	4002
Batteries	4003
Instrument Cluster	4005
Tracks	
	Tab 5
Section Index - Tracks	
Inspection of Track Components	5502
Sealed and Lubricated Track (SALT)	5504
Track Frame and Suspension	5506
Idler, Track Adjuster, and Recoil Housing	5508
Sprocket	5509
Track Roller	5511

D150B CRAWLER Repair Manual 87693704 A - EU

Table of Contents (Continued)

Description	Section Number
Power Train	Tab 6
Section Index - Power Train	
Hydrostatic Pumps and Motors System Overview	6000
Removal and Installation of Hydrostatic Pumps and Motors	6001
Hydrostatic Drive Specifications, Pressure Checks, Troubleshooting	6002
Transmission Controller	6003
Final Drives	6007
Brakes	Tab 7
Section Index - Brakes	
Removal and Installation of Brake Components	7001
Brake System Troubleshooting	7002
Hydraulics	Tab 8
Section Index - Hydraulics	
How to Read Hydraulic Schematics	8000
Removal and Installation of Hydraulic Components	8001
Hydraulic System Specifications, Troubleshooting and Pressure Checks	8002
Cleaning the Hydraulic System	8003
Equipment Pump	8004
Equipment Control Valve	8005
Cylinders	8006
Accumulator	8010
Mounted Equipment	Tab 9
Section Index - Mounted Equipment	
Pedals and Levers	9001
Air Conditioning Troubleshooting and System Checks	9003
Air Conditioning System Service	9004
Removal and Installation of Heater and Air Conditioning System Components	9005
Air Conditioning Compressor and Clutch	9006
Dozer Blade	9007
Rollover Protective Structure (ROPS) Cab Structural Frame (CSF)	9008
Air and Mechanical Suspension Seats and Seat Belts	9009
Ripper	9010

D150B CRAWLER
Repair Manual
87693704 A - EU

Table of Contents (Continued)

Description	Section Number
Schematic Set	
Hydraulic and Electrical Schematics	In Rear Pocket

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com