

SERVICE MANUAL

BR6090 Combi

Print No. 87711078B





SERVICE MANUAL



BR6090 COMBI

Contents

INTRODUCTION

HYDRAULIC - PNEUMATIC - ELECTRICAL - ELECTRONIC SYSTEMS A

SECONDARY HYDRAULIC POWER SYSTEM.....	A.12.A
ELECTRICAL POWER SYSTEM	A.30.A
LIGHTING SYSTEM.....	A.40.A
ELECTRONIC SYSTEM	A.50.A
FAULT CODES	A.50.A
LUBRICATION SYSTEM Oiling	A.60.C

ENGINE AND PTO IN B

PTO POWER IN.....	B.90.A
-------------------	--------

TRANSMISSION, DRIVE AND PTO OUT C

PROCESS DRIVE Primary process drive	C.50.B
---	--------

AXLES, BRAKES AND STEERING..... D

TOWED VEHICLE AXLE Tandem axle.....	D.13.C
PARKING BRAKE Mechanical	D.32.B
PULLED-TYPE VEHICLE BRAKE Hydraulic.....	D.36.C
PULLED-TYPE VEHICLE BRAKE Pneumatic	D.36.E
WHEELS AND TRACKS Wheels.....	D.50.C

FRAME AND CAB E

FRAME Primary frame	E.10.B
---------------------------	--------

CROP PROCESSING K

PICKING Picking up.....	K.20.B
FEEDING Round baler feeding.....	K.25.H
FEEDING Rotor feeding.....	K.25.N
CHOPPING Crop cutter	K.30.E
PRESSING Round chain pressing	K.50.D
WRAPPING AND TYING Net/Film wrapping.....	K.55.F
WRAPPING AND TYING Film wrapping	K.55.E

WRAPPING AND TYING Twine wrapping (duckbill) K.55.D
EJECTING Round bale..... K.70.B

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com