

**EH15
CRAWLER
EXCAVATOR**

SERVICE MANUAL

Bur 6-79880NA



SHOP MANUAL

EH15

HYDRAULIC EXCAVATOR

EH15 SHOP MANUAL

TABLE OF CONTENTS

SECTION 1

STANDARD SPECIFICATIONS AND MAINTENANCE

| | | |
|--|-----|------------------------------|
| Section Table of Contents | I | |
| | | Book/Form Number: 6-79600 NA |
| CHAPTER 1 | | |
| GENERAL INFORMATION AND SAFETY | | |
| Table of Contents | 1-1 | |
| | | Book/Form Number: 6-79610 NA |
| CHAPTER 2 | | |
| SPECIFICATIONS | | |
| Table of Contents | 2-1 | |
| | | Book/Form Number: 6-79620 NA |
| CHAPTER 3 | | |
| LOCATION AND WEIGHT OF COMPONENTS | | |
| Table of Contents | 3-1 | |
| | | Book/Form Number: 6-79630 NA |
| CHAPTER 4 | | |
| MAINTENANCE STANDARD AND TEST PROCEDURES | | |
| Table of Contents | 4-1 | |
| | | Book/Form Number: 6-79640 NA |
| CHAPTER 7 | | |
| TORQUE SPECIFICATIONS AND WORKING STANDARD | | |
| Table of Contents | 7-1 | |
| | | Book/Form Number: 6-79650 NA |

SECTION 2

SYSTEMS

| | | |
|---------------------------------|------|------------------------------|
| Section Table of Contents | I | |
| | | Book/Form Number: 6-77660 NA |
| CHAPTER 12 | | |
| HYDRAULIC SYSTEM | | |
| Table of Contents | 12-1 | |
| | | Book/Form Number: 6-79670 NA |
| CHAPTER 15 | | |
| UPPER STRUCTURE | | |
| Table of Contents | 15-1 | |
| | | Book/Form Number: 6-79680 NA |
| CHAPTER 18 | | |
| TRAVEL SYSTEM | | |
| Table of Contents | 18-1 | |
| | | Book/Form Number: 6-79690 NA |
| CHAPTER 21 | | |
| ATTACHMENTS | | |
| Table of Contents | 21-1 | |
| | | Book/Form Number: 6-79700 NA |
| CHAPTER 22 | | |
| CONTROL SYSTEM | | |
| Table of Contents | 22-1 | |
| | | Book/Form Number: 6-79710 NA |
| CHAPTER 25 | | |
| ELECTRICAL SYSTEM | | |
| Table of Contents | 25-1 | |
| | | Book/Form Number: 6-79720 NA |
| CHAPTER 29 | | |
| TROUBLESHOOTING | | |
| Table of Contents | 29-1 | |
| | | Book/Form Number: 6-79730 NA |

SECTION 3

COMPONENTS

| | | |
|---|------|------------------------------|
| Section Table of Contents | .I | |
| | | Book/Form Number: 6-79740 NA |
| CHAPTER 31 | | |
| HYDRAULIC PUMP | | |
| Table of Contents | 31-1 | |
| | | Book/Form Number: 6-79750 NA |
| CHAPTER 33 | | |
| CONTROL VALVE | | |
| Table of Contents | 33-1 | |
| | | Book/Form Number: 6-79760 NA |
| CHAPTER 35 | | |
| PILOT VALVE (ATTACHMENT, STANDARD) | | |
| Table of Contents | 35-1 | |
| | | Book/Form Number: 6-79770 NA |
| CHAPTER 36 | | |
| PILOT VALVE (ATTACHMENT, AB SHIFTER) | | |
| Table of Contents | 36-1 | |
| | | Book/Form Number: 6-79780 NA |
| CHAPTER 37 | | |
| 2-FUNCTION SOLENOID VALVE (WITH RELIEF VALVE) | | |
| Table of Contents | 37-1 | |
| | | Book/Form Number: 6-79790 NA |
| CHAPTER 38 | | |
| SLEWING MOTOR UNIT | | |
| Table of Contents | 38-1 | |
| | | Book/Form Number: 6-79800 NA |
| CHAPTER 39 | | |
| TRAVEL MOTOR UNIT | | |
| Table of Contents | 39-1 | |
| | | Book/Form Number: 6-79810 NA |

SECTION 4

SYSTEM TROUBLESHOOTING

| | | |
|---------------------------------|------|------------------------------|
| Section Table of Contents | .I | |
| | | Book/Form Number: 6-79820 NA |
| CHAPTER 40 | | |
| SWIVEL JOINT | | |
| Table of Contents | 40-1 | |
| | | Book/Form Number: 6-79830 NA |
| CHAPTER 41 | | |
| HYDRAULIC CYLINDERS | | |
| Table of Contents | 41-1 | |
| | | Book/Form Number: 6-79840 NA |

SECTION 5

ENGINE

| | | |
|---------------------------------|------|------------------------------|
| Section Table of Contents | .I | |
| | | Book/Form Number: 6-79850 NA |
| CHAPTER 50 | | |
| ENGINE | | |
| Table of Contents | 50-1 | |
| | | Book/Form Number: 6-79860 NA |

Thank you so much for reading.
Please click the “Buy Now!”
button below to download the
complete manual.



After you pay.

You can download the most
perfect and complete manual in
the world immediately.

Our support email:

ebooklibonline@outlook.com